

PARTS LOCATION A2 (PCB WIRED COMPONENTS SIDE)

C2102	F4	C2507	A2	L2504	A4	TP206	D1	TP702	C3
C2103	F4	C2508	B3	L2506	A4	TP207	D1	TP704	F3
C2104	E4	C2509	A2	R2119	F4	TP208	D3	TP706	F2
C2106	E4	C2514	A2	R2156	F4	TP209	C1	TP801	C1
C2108	E4	C2516	A1	R2176	F4	TP331	C2	TP802	E2
C2111	E4	C2517	A1	R2219	F1	TP332	C1	TP803	F2
C2112	E4	C2518	C1	R2256	F1	TP501	C2	TP804	F2
C2113	E4	C2521	D1	R2276	F1	TP502	C2	TP805	E2
C2116	E4	C2525	A2	R2582	A5	TP503	C2	TP806	E2
C2141	F5	C2530	A2	R2750	F3	TP504	C2	TP901	C4
C2202	F1	C2532	A1	R2753	F2	TP506	B2	TP902	C4
C2203	F1	C2547	D5	R2778	F3	TP508	D2	TP903	C3
C2204	E1	C2549	C5	T2501	A2	TP509	B3	TP904	C3
C2206	E1	C2750	F3	X2001	A1	TP511	C1	TP906	C3
C2208	E1	H2901	B1	X2501	B4	TP520	B4	TP907	D3
C2211	E1	K2101	F5	X2502	A4	TP521	C5	TP908	C3
C2212	E1	K2102	E4	Z2501	B4	TP522	B3	TP909	C3
C2213	E1	K2103	E4	TP102	D3	TP523	C2	TP911	D4
C2216	E1	K2201	F1	TP103	D3	TP524	B3	TP912	C4
C2241	F1	K2202	E1	TP106	D5	TP526	C4	TP914	C4
C2317	C1	K2203	E1	TP107	D4	TP527	B4	TP916	B4
C2322	C1	K2750	F3	TP201	E2	TP528	C4	TP917	C4
C2324	C1	K2751	F2	TP202	D2	TP529	C5	TP918	B4
C2501	B2	L2502	A1	TP203	D2	TP700	E2	TP919	B2
C2506	B3	L2503	B1	TP204	D1	TP701	E2	TP921	B1