

	<b>Page</b>
<b>1 SAFETY INSTRUCTIONS.....</b>	<b>1-1</b>
1.1 INTRODUCTION .....	1-1
1.2 SAFETY PRECAUTIONS .....	1-1
1.3 CAUTION AND WARNING STATEMENTS.....	1-1
1.4 SYMBOLS .....	1-1
1.5 IMPAIRED SAFETY.....	1-2
1.6 GENERAL SAFETY INFORMATION.....	1-2
<b>2 CHARACTERISTICS .....</b>	<b>2-1</b>
2.1 DISPLAY .....	2-1
2.2 SIGNAL ACQUISITION .....	2-1
2.3 CHANNELS A & B .....	2-2
2.4 TIMEBASE.....	2-4
2.5 TRIGGER.....	2-5
2.6 SIGNAL MEMORY (MODELS 95 AND 97 ONLY).....	2-6
2.7 TRACE DISPLAY.....	2-6
2.8 SETUP MEMORY (MODEL 95 ONLY) .....	2-6
2.9 SETUP MEMORY (MODEL 97 ONLY) .....	2-7
2.10 CALCULATION FACILITIES (MODEL 95 ONLY) .....	2-8
2.11 CALCULATION FACILITIES (MODEL 97 ONLY) .....	2-8
2.12 CURSORS (MODELS 95 AND 97 ONLY).....	2-9
2.13 MULTIMETER .....	2-9
2.14 AUTO SETTING.....	2-14
2.15 GENERATOR (MODEL 93 AND 95) .....	2-16
2.16 GENERATOR (MODEL 97 ONLY) .....	2-16
2.17 POWER ADAPTOR /BATTERY CHARGER .....	2-17
2.18 POWER SUPPLY .....	2-18