


NavPilot SPU PCB 001-047-750



IMPORTANT

Jumper JP-2 MUST be configured correctly for your particular application.

JP-2 1 to 2

For use when using the Teleflex AR4202 or Verado rudder reference (or equivalent). Normally used with Outboard Motor installations.

JP-2 3 to 4

For use when using the Furuno FAP6112 rudder reference (or equivalent). Normally used with inboard motor installations.