

Quick Reference Guide

Backlight/Contrast

1. Press **MENU PWIR** while viewing Main Menu to adjust backlight.
2. Press **◀** or **▶** while viewing Main Menu to control contrast level.

Go Direct to a Waypoint

1. Press **GO TO NIRST**.
2. Press **▶** to move to 1st airport letter.
3. Press **▶** or **▶** to change character.
4. Repeat steps 2 & 3 to complete airport name.
5. Press **ENTER**.

Emergency Search

1. Press **GO TO NIRST** twice.
2. Press **ENTER**.
3. View Nav Info.

Customizing Nav Pages

1. While viewing a Nav Info Page, press **ENTER** and hold it until the screen area is highlighted.
2. Press **◀** or **▶** to view Nav Info choices.
3. Press **▶** or **▶** to move highlighted area.
4. Press **ENTER** to save and return to the Nav function.

Panning the Moving Map

1. While viewing the Moving Map, Press **ENTER** and hold until **PAN** appears and replaces map scale.
2. Press the arrow keys to move the map center point.
3. Press **ENTER** to return to normal viewing.

Create a User Waypoint

1. Press **NEW WAYPT**. Your Present Position will be displayed.
2. Press **▶** or **▶** to change characters. Press **◀** or **▶** to move cursor.
3. Press **ENTER** to save and exit.

Button Definitions

- MENU PWIR** Press to turn power ON. Press and hold to turn power OFF.
- ENTER** Press to accept and save changes.
- GO TO NIRST** Press once to view nearest waypoint. Press twice to view nearest 30 waypoints for each type.
- INFO** Press to view information for selected waypoints.
- NEW WAYPT** Press to create new waypoints.
- ▶** Press to move highlight or cursor.
- ▶**

Screen Definition

The screen displays the following information:

- Moving Map or other Information:** Points to the map area showing a route and a star marker.
- GPS status:** Points to the 'GPS' indicator.
- Backlight is ON:** Points to the 'BL' indicator.
- Power Information:** Points to the battery level indicator.
- Battery is charging:** Points to the star icon.
- Battery level if battery is shown:** Points to the battery level percentage.
- External power if lightning bolt shown:** Points to the lightning bolt icon.


Navigation Information

25.9 215
 DIST. R. 0.22
 004 005
 BRG TRK
 #7SS #022
 #UBG #2.50#3.21#5
 #MHV #7.5#
 30 30 # 1
 BL



2345 Turner Rd., S.E.
 Salem, OR 97302
 USA 800-525-6726
 Canada 800-654-3415
 International (503) 391-3411
 FAX (503) 364-2138
 P/N 560-0115-01 August 1995
 © 1995 by II Morrow Inc.
 Printed in the U.S.A.
 All Rights Reserved

Main Menu Function Summary



NAV Function Summary

