



TASTATURBELEGUNG KEYBOARD TABLE

T1	8		T45	ACP	
T2	9	T24	0000		
T3	0	T25	ON/OFF		
T4	NAME	T26	WiFi	T48	C
T5	Q.D			T49	CODE
T6	.	T28	CHECK	T50	▶▶
T7	▶	T29	SET	T51	◀
T8	▶			T52	PAUSE
T9	3	T31	CL	T53	TV
T10	PROGRAM	T32	FINE TUNING	T54	◀◀
T11	5			T55	▶
T12	1			T56	⏻
T13	SAT	T35	OK	T57	?
T14	LP	T36	FINE TUNING	T58	4
T15	COUNT	T37	DATE	T59	● (1)
T16	.			T60	PICTURE
T17	7	T38	◀	T61	▶
T18	PROGRAM			T62	■
T19	↔			T64	
T20	0				
T21	AV/TV				
				T67	● (2)

GEBERPL./REMOTE CONTROL RP20 27506-075.01 310392