

Start Here

Keysight M8030A Multi-Channel BERT

Welcome to Keysight M8030A Multi-Channel BERT

Refer to the following documents before operating the instrument:

- If you have ordered M8030A Multi-Channel BERT as a pre-installed bundle of AXIe chassis and modules (M8030A-BU1 or M8030A-BU2), then start with the *M8020A/M8030A Getting Started Guide* for the basic setup.
- If you have ordered M8030A Multi-Channel BERT modules and AXIe chassis separately then start with the *M8020A/M8030A Installation Guide*, which is available in the CD, shipped along with the order.
- For safety and ESD instructions, refer to *Tips for Preventing Damage to Keysight M8020A/M8030A*.
- For information on M8070A GUI features and measurements, refer to the *M8070A User Guide* and *Online Help*.

Locate M8030A documentation

- On installing the M8070A software, you will find the M8030A documentation by clicking **Start > All Programs > Keysight M8070A > Keysight M8070A Documentation**.
- You can also visit www.keysight.com/find/m8030a to find the latest versions of various manuals and the data sheet for each M8030A module.

Contact Keysight Technologies

For more information on Keysight Technologies' products, applications or services, please contact your local Keysight office. The complete list is available at: www.keysight.com/find/contactus

This information is subject to change without notice.

© Keysight Technologies 2016

Edition 1.0, February 2016

Printed in Malaysia



M8030-91010

www.keysight.com