

Installation Instruction

To update the CX3300 firmware, follow the procedure below.

1. Click the **Utilities** icon at the bottom right corner of the screen, then select the **Close Window** to stop the CX3300 firmware.
2. Copy the downloaded file to CX3300 by using a USB flash memory and unzip the file accordingly, if zipped.
3. Double click the file at a working folder to start the installation.
4. Follow the instruction of the installer.
5. Start the CX3300 firmware by clicking the **CX3300** icon on the desktop.
6. If FPGA updater appears, select the **Start Update** button on the FPGA updater and wait for the update process to complete. (FPGA updater appears only when necessary)
7. Shutdown the CX3300 by clicking the **Shutdown** button on the FPGA updater.

End.