

Agilent Technologies

E5810A LAN/GPIB Gateway for Windows



Rack Mount Installation Note

One rack mount kit contains the hardware to mount a single E5810A or two E5810As, side-by-side.






Rack Mounting One E5810 (see other side to rack mount two E5810s)


Parts needed to install a single E5810 in a rack:


Α	E5810-00021	Rack Ear - Full Rack	1	D	0515-1577	Screw - Machine	4
В	E5810-00022	Rack Ear - Half Rack	1	Ε	0590-0804	Nut, Machine	4
С	0515-1114	Screw, Panhead, M4x10	6				


1) Remove both rubber bumpers from the E5810.




- Using Pozidriv screwdriver, attach Rack Ear-Half Rack (B) to the E5810 with three M4x10 Panhead Screws (C).
- Using Pozidriv screwdriver, attach Rack Ear-Full Rack (A) to the E5810 with three M4x10 Panhead Screws (C).







Using Phillips screwdriver, attach Rack Ears to rack with four Machine Screws (D) and four Machine Nuts (E).




Rack Mounting Two E5810s (see other side to rack mount one E5810)


Parts needed to install two E5810s, side-by-side, in a rack:

Α	0050-2166	Lock Link	2	Е	0515-1577	Screw, Machine	4
В	E5810-00023	Bracket, Rear	1	F	0590-0804	Nut, Machine	4
С	E5810-00021	Rack Ear - Full Rack	2	G	0515-1367	Screw, Flathead, M4x8	2
D	0515-1114	Screw Panhead M4x10	6				


(1) Remove both rubber bumpers from the E5810.



- (2) Using Pozidriv screwdriver, install a Lock Link (A) on each E5810 with a Flathead Screw (G). Then, slide the two E5810s together so the Lock Links Interconnect. See Detail "A"
- (3) Using Pozidriv screwdriver, remove the screw at the rear of each E5810. Then, connect the Rear Bracket (B) to each E5810, using the screws you just removed.



Using Pozidriv screwdriver, attach Rack Ear-Full Rack (C) to each E5810 with six M4x10 Panhead Screws (D).



© Agilent Technologies, Inc. 2002, 2004



Part Number: E5810-99100 Printed in Malaysia E0404 Apr 2004

