



Oscilloscopes Infiniium Communication Mask Test Kit

Perform compliance testing to ANSI, ITU-T and IEEE standards with Infiniium's Communication Mask Template library and electrical communication adapters.



Option 100 Features:

- Over 20 industry standard ANSI T1.102, ITU-T G.703 and IEEE 802.3 communication signal mask templates
- Mask testing for positive and negative pulses
- Electrical communication adapters optimized for use with HP Infiniium oscilloscopes
- FCC Part 68 Option B and C masks for "line buildout" testing of DS1/T1 signals.
- Automatic "isolated ones" triggering for all pulse mask templates
- One-button alignment for best fit of mask templates to test waveforms, virtually eliminating manual oscilloscope adjustments
- Automatic pass/fail comparison of mask templates to corresponding input waveforms
- · Failure highlighting for fast identification of mask failure areas

- Flagging of out-of-specification waveform amplitudes for ANSI T1.102 masks
- Mask failure waveform characterization with features such as color-graded persistence, histograms, drag and drop measurements and eye diagram measurements
- Ability to load custom masks from ASCII text files
- Screen annotation for complete documentation of measurements to electronic files or printers
- Familiar Windows graphical user interface
- Built-in LAN interface for connecting your scope to PCs, network printers and other HP Infiniium oscilloscopes
- HP-IB programmability of mask test features for automated test applications

Communication Mask Test Kit

Take the frustration out of communications testing

Now there's an easier way to prove your products conform to industry standards. Use an HP Infiniium oscilloscope with the Communication Mask Option to get your job done more quickly. HP Infiniium's familiar Windows interface makes it easy for you to

access the masks you need and configure your tests. Plus you'll find a variety of special mask test features that save you time and trouble. The Communication Mask Test Kit comes complete with a library of mask templates and a set of electrical communication adapters to assure convenient, reliable and accurate connections to your device under test.

Communication Mask Template Library

Standard	Mask Template	Data Rate (Mb/s)	Standard	Mask Template	Data Rate (Mb/s)
ANSI T1.102	DS1	1.544	ITU-T G.703	DS1	1.544
	FCC Part 68.308 Options B,C	1.544		E1	2.048
	DS1A	2.048		DS2	6.312
	DS1C	3.152		E2	8.448
	DS2	6.312		E3	34.368
	DS3	44.736		DS3	44.736
	STS1 (pulse)	51.840		E4	139.264
	STS1 (eye)	51.840		STM1E	155.520
	DS4NA (eye)	139.264			
	STS3 (eye)	155.520	IEEE 802.3	10BASE-T	10

Communication mask test

The Communication Mask Template Library comes on a single 3.5" floppy disk for easy installation onto HP Infiniium's hard disk drive. Configuring a mask test is fast and easy, too. The mask test dialog box lets you select the oscilloscope channel and display masks contained in the mask template library. Once your test is configured, you can dismiss the dialog box to maximize waveform viewing area and control your test directly using popup menus. You'll see an on-screen indication of the current mask and its data rate.

Once you've chosen the appropriate mask, simply click on the Align button to automatically perform a fast, exhaustive search for the optimum fit of the mask to the test signal. This virtually eliminates the need for manual adjustments to your oscilloscope. This is an especially valuable feature for production test applications.

You can perform a "compare" test on positive or negative pulses to check the waveform's compliance with the mask standard. You can run the test until a single failure has occurred, a given number of waveforms have been captured, or a specific period of time has elapsed.

Use the mouse or HP Infiniium's keyboard to add labels or notes to your screen images, then save them to the floppy or hard disk. The built-in LAN interface makes it easy to transfer these images to network computers so you can share or document your work. You can also print the waveform to local or network printers.

"Isolated ones" triggering

It is necessary to isolate a pulse for mask testing to eliminate intersymbol interference caused by adjacent pulses. HP Infiniium's Communication Mask Test Option makes this easy through the use of "isolated ones" triggering for pulse mask templates, eliminating the need for sophisticated pattern generators. When you load in a pulse mask, HP Infiniium automatically sets up the trigger to capture an "isolated one" pattern as defined by the particular ANSI or ITU standard.

Communication Mask Test Kit

Connecting to your Device under Test

Product compliance testing requires proper connection to your communications device. Included in the Option 100 kit is a set of electrical termination adapters and adapter cables to assure convenient, reliable and accurate connections to your device under test. The kit also includes system performance accessories and the Mask Template Library software – all packaged in a protective, hardshell case.



HP E2621A 100/110/120-ohm termination adapter

The HP E2621A ac-coupled, balanced adapter allows connection to differential communications signals by terminating the signal into 100, 110 or 120 ohms. It also adapts various connector styles (i.e., bantam, RJ48C and Siemens) to the oscilloscope's 50-ohm BNC input. You can select the termination impedance using the built-in, three-way switch. The AutoProbe interface allows the HP Infiniium oscilloscope to recognize the HP E2621A and read the termination switch setting. Furthermore, HP Infiniium will flag you when the switch setting differs from the standard's required termination impedance.

Characteristics

The HP E2621A complies with the following ANSI T1.102 and ITU-T G.703 Standards:

111.01 11.10 - 01.	a 110 1 a.100 blandardb.
DS1	(1.544 Mb/s)
DS1A	(2.048 Mb/s)
DS1C	(3.152 Mb/s)
DS2	(6.312 Mb/s)
E1	(2.048 Mb/s)

Bandwidth (-3 dB):	<10 kHz to >100 MHz	
Rise Time:	<3.5 ns	
Attenuation:	5X (-14 dB) ± 3% (50 kHz to 30 MHz)	



HP E2622A 75-ohm termination adapter

The HP E2622A dc-coupled, unbalanced adapter allows you to connect communications signals such as DS3 and E3 to the oscilloscope's 50-ohm BNC input. The AutoProbe interface allows HP Infiniium to recognize the HP E2622A and automatically configure itself.

Characteristics

The HP E2622A complies with the following ANSI T1.102 and ITU-T G.703 Standards:

DS3	(44.736 Mb/s)		
DS4NA	(139.264 Mb/s)		
STS1	(51.840 Mb/s)		
STS3	(155.520 Mb/s)		
STM1E	(155.520 Mb/s)		
E1	(2.048 Mb/s)		
E2	(8.448 Mb/s)		
E3	(34.368 Mb/s)		
E4	(139.264 Mb/s)		
Bandwidth (-3 dB):	>1 GHz*		
Rise Time:	<350 ps		
Attenuation:	5X (-14 dB) ± 1.5%		

^{*} Full bandwidth only achievable with HP 54845A 1.5 GHz oscilloscope.





Communication Mask Test Kit

Model Number	Number of Ch.	Bandwidtl	n Sample Rate	Memory Depth	Price
HP 54810A	2	500 MHz	1 GSa/s	32k	\$9,995
HP 54815A	4	500 MHz	1 GSa/s	32k	\$15,995
HP 54820A	2	500 MHz	2 GSa/s	32k	\$12,495
HP 54825A	4	500 MHz	2 GSa/s	32k	\$18,995
HP 54845A	4	1.5 GHz	4 GSa/s - 4 ch. 8 GSa/s - 2 ch.		\$29,995

Ordering Information

1. With the purchase of a new HP Infiniium oscilloscope:

Option 100 Communication Mask Test Kit includes: HP E2626A Mask Template Library floppy disk (on 1.44MB 3.5-inch floppy disk)

HP E2621A 100/110/120-ohm balanced termination adapter with bantam (f) connector

HP E2622A 75-ohm unbalanced termination adapter with BNC (f) connector

HP E2623A Bantam (m) to Siemens (f) adapter cable; for connection to E2621A adapter when a Siemens (f) connection is needed

HP E2624A Dual-bantam (m) to RJ48C (m) adapter cable; for connection of either ransmit or receive T1 signals to HP E2621A adapter

HP E2627A RJ48C (f) to RJ48C (f) adapter/coupler

HP E2628A Bantam (m) to BNC (f); for system verification of HP E2621A adapter and the HP Infinitum oscilloscope

HP E2621A adapter and the HP Infinium oscilloscope
HP E2629A BNC (m) to BNC (f) 50-to-75 ohm adapter; for system
verification of HP E2622A adapter and the HP Infinium oscilloscope
HP 8120-1838 BNC (m) to BNC (m) cable - 30 cm long
Hard-shell case for storage of all kit accessories

2. For existing Infiniium oscilloscope customers:

E2625A Same kit as above; *requires* version 3.0 of the HP Infiniium software

To receive your free HP Infiniium software update to version 3.0, go to the HP Infiniium Customer Care Center page at:

www.hp.com/info/Infiniium_Care1 Choose "Members Only", or "Register" if you're a first time visitor

Individual items included in Option 100 (E2625A) kit:

HP E2626A Mask Template Library floppy disk (*requires* version 3.0 software)

HP E2621A 100/110/120-ohm balanced termination adapter with bantam (f) connector

HP E2622A 75 ohm unbalanced termination adapter with BNC (f) connector

HP E2623A Bantam (m) to Siemens (f) adapter cable - 30 cm long

HP E2624A Dual-bantam (m) to RJ48C (m) adapter cable 35 cm long

HP E2627A RJ48C (f) to RJ48C (f) adapter/coupler

HP E2628A Bantam (m) to BNC (f) adapter; for system verification/calibration of the HP E2621A adapter and the HP Infiniium oscilloscope

HP E2629A BNC (m) to BNC (f) 50-to-75-ohm adapter; for system verification of the HP E2622A adapter and the HP Infiniium oscilloscope

8120-1838 BNC (m) to BNC (m) cable - 30 cm long

Recommended Accessories

E2630A Bantam (m) to bantam (m) patch cable - 180 cm long E2632A Siemens (m) to Siemens (m) patch cable - 1 m long

For more information about HP Infiniium Communication Mask Testing option, HP Infiniium oscilloscopes, HP Infiniium Probes and Accessories, or other Hewlett-Packard Test and Measurement products, and for a current sales office listing, visit our web site at http://www.hp.com/info/infiniium21. You can also contact one of the following centers and ask for a test and measurement sales representative.

United States:

Hewlett-Packard Company Test and Measurement Call Center P.O. Box 4026 Englewood, Colorado 80155-4026 1 800 452 4844

Canada:

Hewlett-Packard Canada Ltd. 5150 Spectrum Way Mississauga, Ontario L4W 5G1 (905) 206 4725

Europe:

Hewlett-Packard European Marketing Centre P.O. Box 999 1180 AZ Amstelveen The Netherlands (31 20) 547 9900

Japan

Hewlett-Packard Japan Ltd. Measurement Assistance Center 9-1, Takakura-Cho, Hachioji-Shi, Tokyo 192, Japan Tel: (81) 426 56 7832 Fax: (81) 426 56 7840

Latin America:

Hewlett-Packard
Latin American Region Headquarters
5200 Blue Lagoon Drive
9th Floor
Miami, Florida 33126
U.S.A.
Tel: (305) 267-4245
(305) 267-4220
Fax: (305) 267-4288

Australia/New Zealand:

Hewlett-Packard Australia Ltd. 31-41 Joseph Street Blackburn, Victoria 3130 Australia 1 800 629 485

Asia Pacific:

Hewlett-Packard Asia Pacific Ltd. 17-21/F Shell Tower, Times Square, 1 Matheson Street, Causeway Bay, Hong Kong Tel: (852) 2599 7777 Fax: (852) 2506 9285

Data subject to change.

© Hewlett-Packard Company 1999
Printed in the U.S.A. 2/99
5968-3833EN