

Installing Agilent License Manager

Where to get Agilent License Manager

Note: Agilent License Manager (ALM) may come pre-installed on your Agilent instrument or with your Agilent product software.

You can install Agilent License Manager from either the:

- Agilent License Manager software download Web page:
<http://www.agilent.com/find/LicenseManager>
- CD/DVD media provided with your Agilent product.

Installation Procedure

Important: You must close other Windows applications, especially all MS Office applications, prior to installing the Agilent License Manager software.

Follow this procedure to install the Agilent License Manager software:

1. If you downloaded Agilent License Manager from the ALM Web page, select **RUN** from the installation display.
2. In the **Welcome** window, click the **Next** button.
3. In the **License Agreement** window, read the license agreement, click the **I accept the terms of the license agreement** option button, and then click the **Next** button. (Note that if you do not accept the license agreement, you can only go back to the **Welcome** window or cancel the installation.)
4. In the **Choose Destination Location** window, click the **Next** button to install ALM in the default folder (C:\Program Files(x86)\Agilent\Agilent License manager\). Agilent recommends that you use the default installation directory.
5. In the **Ready to Install the Program** display, click the **Install** button.
6. In the **InstallShield Wizard Complete** window, click the **Finish** button.

You have successfully installed Agilent License Manager. To confirm the installation, click the Windows **Start** button, and then select:

All Programs > Agilent> Agilent License Manager