

E5070B/E5071B Internal Test/External Test Update Procedure

The purpose of this procedure is to update the internal/external test software of E5070B/E5071B.

● Required Equipment

- E5070B or E5071B (with keyboard and mouse)
- One blank floppy disk (DOS format)

Step 1. Make a Installation Disk

The following is the procedure to make the E5070B/E5071B Internal Test Installation disk:

1. Insert the floppy disk into your computer's FDD
2. Copy these two files to the floppy disk

InternalTest.VBA

ExternalTest.VBA

Step 2. Update the E5070B/E5071B Internal/External Test

The following is the procedure to update the Internal Test:

1. Power on E5070B or E5071B
2. Press [**Save/Recall**].
3. Click **Explorer...** on the menu bar, then the Windows Explorer will appear.
4. Insert the Internal Test Installation Disk into the FDD of the E5070B or E5071B.
5. Double-click the "**3 1/2 Floppy [A:]**" icon on the Explorer window.
6. Copy (overwrite) **InternalTest.VBA** and **ExternalTest.VBA** to the folder:
D:¥Agilent¥Service.
7. Close the Windows Explorer window.