

Installation Note

Agilent Technologies MXA Signal Analyzer Hard Transit Case (Option HTC)



Agilent Technologies

Part Number N9020-90013
Printed in USA September 2006



N9020-90013

Notice.

The information contained in this document is subject to change without notice.

Agilent Technologies makes no warranty of any kind with regard to this material, including but not limited to, the implied warranties of merchantability and fitness for a particular purpose. Agilent Technologies shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance, or use of this material.

Option HTC, Hard Transit Case

Products Affected:	MXA N9020A
Serial Numbers:	All

Introduction

The hard transit case provides an easy way to transport any Agilent MXA signal analyzer and accessories. Space is available for the following accessories: manuals, front impact cover, various cables, and small accessories.

Contents

Quantity	Description	Agilent Part Number
1	Installation Note	This note
1	Hard Transit Case	E4401-80120

WARNING

Do not lift the transit case by the telescoping handle. The handle is designed for pulling the case across smooth surfaces. Do not use the telescoping handle to pull the transit case up stairs, over curbs, or over rough terrain. Under certain circumstances, with improper usage, the telescoping handle may break and the falling case may cause injury.

CAUTION

The handles on the transit case have been tested for a load limit of 100 pounds gross weight. Exceeding the load limit could result in the failure of the handles.

Procedure

1. Refer to Figure 1. Lay the case flat on its feet to open or close it.

Figure 1 **Signal Analyzer in Transit Case**



2. Place the analyzer into the pre-cut cavity. Be sure that the rear of the signal analyzer (1) is on the same side as the wheels (2) on the transit case.
3. Set the instrument handle (3) in a locked position to the rear of the signal analyzer.
4. Before you remove the signal analyzer from the transit case, move the handle to a locked upright position.

5. Refer to Figure 2. The area found under the instrument provides a storage area for items such as power cords, cables, and reference guides. Foam cutouts (4) on both the lid and base provide additional storage space.

Figure 2 **Transit Case Accessory Cutouts**



Procedure

6. Refer to Figure 3. When using the telescoping handle to roll the carrying case, pull up firmly on the hand grip (1) until the telescoping sections are fully extended and securely LOCKED in place.

Figure 3 **Transit Case with Handle Extended**



7. To release the locks and restore the handle to the retracted position, push the lock release button until the locks release.
8. Press down on the hand grip (1) until the handle is in the fully retracted position.

WARNING

Do not lift the transit case by the telescoping handle. The handle is designed for pulling the case across smooth surfaces. Do not use the telescoping handle to pull the transit case up stairs, over curbs, or over rough terrain. Under certain circumstances, with improper usage, the telescoping handle may break and the falling case may cause injury.

CAUTION

The handles on the transit case have been tested for a load limit of 100 pounds gross weight. Exceeding the load limit could result in the failure of the handles.

9. To move the transit case up stairs, over curbs, or over rough terrain, use the four carrying handles. Two carrying handles are located on each end of the transit case. When using the carrying handles, place the telescoping handle in the fully retracted position.