

INFORMATION ONLY – DOES NOT COMMUNICATE  
A MODIFICATION OR SAFETY CONDITION

**4288A-02**

**S E R V I C E N O T E**

---

Supersedes:  
NONE

**Agilent 4288A 1kHz/1MHz Capacitance Meter**

**Serial Numbers: See Solution / Action**

**Power Supply Switch Part Number Change**

**Parts Required: See Solution / Action**

**ADMINISTRATIVE INFORMATION**

SERVICE NOTE CLASSIFICATION: <b>INFORMATION ONLY</b>
AUTHOR: TO    PRODUCT LINE: WN
ADDITIONAL INFORMATION:

© AGILENT TECHNOLOGIES, INC. 2003  
PRINTED IN U.S.A.

August 28, 2003



**Situation:**

The wire assembly (P/N 04288-61631) with power switch of the 4288A was obsoleted and replaced with new parts. Chassis also changed to a new one in time with the assembly.

**Solution/Action:**

When replacing the wire assembly, order appropriate parts depending on the serial number of the 4288A.

**Serial Number: MY41100216 and below**  
**JP1KH00491 and below**

The new wire assembly can't be attached on the existing chassis directly. When replacing any parts in Table 1, replace all parts in Table 1 with the new parts listed in Table 2.

**Table 1 Old Parts**

Part Number	Qty.	Description
04288-61631	1	Wire assembly with power switch
0515-2028	2	Screw to fix wire assembly to chassis

**Table 2 Replacement parts**

Part Number	Qty.	Description
E5091-61634	1	Wire assembly with power switch
04268-01203	1	Angle
0515-1946	2	Screw
0515-0430	2	Screw

**Serial Number: MY41100217 and above**  
**JP1KH00492 and above**

When replacing the wire assembly or angle, use the replacement parts listed in Table 3.

**Table 3 Replacement Parts**

<b>Part Number</b>	<b>Qty.</b>	<b>Description</b>
E5091-61634	1	Wire assembly with power switch
04268-01214	1	Angle
0515-1946	2	Screw
0515-0430	2	Screw
04288-00102	1	Chassis