8665B-04

S E	R	V	Ι	С	Ε		Ν	0	Т	E
						SUPER	SEDES	S: NON	E	
8665B Synthesized Signal Generator										
Serial Numbers: See Duplicate Service Notes										
Return specified transformers to factory for analysis.										
Duplicate Service Notes:										
8644B-04 Serials: 3546A00973 / 3546A01081										
8645A-05 Serials: 3546A00554 / 3546A00569 8664A-05 Serials: 3546A01174 / 3546A01358										
8665A-06 Serials: 3546A00850 / 3546A00873										
8665A-06 S	enais. 554		2516	401000						
8665A-06 S 8665B-04 S		6A00891 /	3546	A01000						
	Serials: 354				nnel					
8665B-04 S	erials: 354				nnel					
8665B-04 S To Be Perf	erials: 354	Agilent-(			nnel					
8665B-04 S To Be Perf Parts Requ	ormed By: ired: Descrip	Agilent-(	Qualif	ied Perso	nnel					

Continued

DATE: November 1997

## ADMINISTRATIVE INFORMATION

SERVICE NOTE CLASSIFICATION:								
MODIFICATION RECOMMENDED								
ACTION CATEGORY:	<ul> <li>☐ IMMEDIATELY</li> <li>■ ON SPECIFIED FAILURE</li> <li>☐ AGREEABLE TIME</li> </ul>	STANDARDS: LABOR 2.0 Hours						
LOCATION CATEGORY:	CUSTOMER INSTALLABLE	SERVICE     RETURN     USED     RETURN       INVENTORY:     SCRAP     PARTS:     SCRAP       SEE TEXT     SEE TEXT     SEE TEXT						
AVAILABILITY:	PRODUCT'S SUPPORT LIFE	AGILENT RESPONSIBLE UNTIL: May 2000						
AUTHOR: MW	ENTITY: 5320	ADDITIONAL INFORMATION:						

© 1997 AGILENT TECHNOLOGIES PRINTED IN U.S.A.



## Situation:

This transformer, in the affected serial number range listed above, has demonstrated a potential reliability problem at the factory, and might blow the main line fuse (P/N 2110-0083) if a properly grounded power cable is not used.

## Solution / Action:

It is recommended that any transformer from a power supply that blows its line fuse in the affected instruments be replaced, and the old transformer be returned to the factory for analysis. Warranty is extended for the fuse failure and associated transformer replacement until 1 May, 2000 on all instruments specified above.

Please contact MID Source Support at (707)577-6803 for instructions on returning the transformer.