E8257D-07

# SERVICE NOTE

Supersedes: None

## E8257D PSG Analog Signal Generator

Serial Numbers: [0000A00000 / 9999Z99999]

Power offset in the Agilent N7800A Test Management Environment Software for power measurements > 0 dBm

To Be Performed By: Agilent-Qualified Personnel or Customer

**Parts Required:** 

P/N Description Qty.

None

### ADMINISTRATIVE INFORMATION

SERVICE NOTE CLA	SSIFICATION:		
MODIFICATION RECOMMENDED			
ACTION CATEGORY:	X IMMEDIATELY [[]] ON SPECIFIED FAILURE [[]] AGREEABLE TIME	STANDARDS: LABOR: 1.0 Hour	rs
LOCATION CATEGORY:	X CUSTOMER INSTALLABLE [[]] ON-SITE [[]] SERVICE CENTER	SERVICE [[]] RETURN INVENTORY: [[]] SCRAP [[]] SEE TEXT	USED [[]] RETURN PARTS: [[]] SCRAP [[]] SEE TEXT
AVAILABILITY:	PRODUCT'S SUPPORT LIFE	AGILENT RESPONSIBLE UNTIL:	August 2006
AUTHOR: RDS	PRODUCT LINE: 15		
ADDITIONAL INFORM	MATION:		

© AGILENT TECHNOLOGIES, INC. 2005 PRINTED IN U.S.A.



Page 2 of 3 E8257D-07

#### **Situation:**

The 20 GHz PSGs use an E4413A Power Sensor to measure Maximum Leveled Power and Power Level Accuracy. This power sensor contains two sets of Calibration Factors, one for powers  $\leq 0$  dBm and the other for powers > 0 dBm. Due to a software defect the Calibration Factors for powers > 0 dBm are not being used for higher powers. This will result in the measured power being offset.

#### **Solution/Action:**

Until the software is fixed a manual measurement is required for Maximum Leveled Power and Power Level Accuracy. The measured data will be recorded in this service note and attached to the Agilent N7800A Test Management Environment Software report.

#### Manual Maximum Power Measurement

- 1. Zero and calibrate the E4413A power sensor.
- 2. Connect the sensor directly to the PSG RF Output (no cables).
- 3. Set the E8257D frequency to 100 MHz.
- 4. Enter the test frequency via the E4419A/B front panel (Frequency/A Freq).
- 5. Set the E8257D amplitude to the maximum power in **Table 1.** The maximum power is dependent upon what options the E8257D contains.

Table 1

Table 1		
Opts	250 kHz to 3.2 GHz	>3.2 GHz to 20 GHz
Std	13	13
1EA	16	20
1E1	11	11
UNW	11	13
1EH	13	13
UNW & 1EH	10	13
1EA & UNW	11	20
1EA & 1EH	13	20
1EA & UNW & 1EH	10	20
1E1 & 1EA	15	18
1E1 & 1EA & UNW	10	18
1E1 & UNW	10	11
1E1 & 1EH	11	11
1E1 & UNW & 1EH	9	11
1E1 & UNW & 1EH & 1EA	9	18

- 6. Increment the E8257D amplitude by 0.3 dB, this is to accommodate the measurement uncertainty of the measurement.
- 7. Check for the E8257D leveling. If the unit is leveled then the test passed. If the unit is unleveled, then the test failed.
- 8. Repeat steps 4 through 7 for E8257D frequencies of 10 GHz and 20 GHz.
- 9. Record your results below by initialing the appropriate cell in **Table 2**.

Table 2

Frequency	Pass	Fail
100 MHz		
10 GHz		
20 GHz		

Page 3 of 3 E8257D-07

#### Manual Power Level Accuracy

- 1. Zero and calibrate the E4413A power sensor.
- 2. Connect the sensor directly to the PSG RF Output (no cables).
- 3. Set the E8257D frequency to 95.1 MHz and the amplitude to 0 dBm.
- 4. Enter the test frequency via the E4419A/B front panel (Frequency/A Freq).
- 5. Measure the E8257D amplitude.
- 6. Subtract the measured value from the E8257D front panel setting.
- 7. Enter the difference in **Table 3**.

Table 3

Frequency	0 dBm	10 dBm	Max power (See Table 1)
95.1 MHz			
10.0501 GHz			
19.9501 GHz			

- 8. Increment the amplitude of the E8257D to the next power in **Table 3** and repeat steps 5 through 7. Repeat this step until all powers have been tested for this frequency.
- 9. Increment the E8257D frequency to the next frequency in **Table 3** and repeat steps 4 through 8.
- 10. Compare the result to the specifications in **Table 4**

Table 4

Frequency	>+10 dBm	+10 dBm to -10 dBm
250 kHz to 2 GHz	± 0.6	±0.6
>2 GHz to 20 GHz	± 0.8	± 0.8

11. Record your results below by initialing the appropriate cell in **Table 5.** 

Table 5

Frequency	Pass	Fail
95.1 MHz		
10.0501 GHz		
19.9501 GHz		

12. Attach the completed service note to the Agilent N7800A Test Management Environment Software report.