


# HK 3480 REAR-PANEL CONNECTIONS



- |   |                                     |                                |
|---|-------------------------------------|--------------------------------|
| <b>1</b> Phono Ground                   | <b>8</b> Video 2 Audio/Video Inputs | <b>15</b> Accessory Outlets    |
| <b>2</b> Phono Inputs                   | <b>9</b> Video 3 Audio/Video Inputs | <b>16</b> Power Cable          |
| <b>3</b> CD Audio Inputs                | <b>10</b> Preamp Out                | <b>17</b> Remote IR Out        |
| <b>4</b> Tape Monitor Play/In           | <b>11</b> Main In                   | <b>18</b> Remote IR In         |
| <b>5</b> Tape Monitor Record/Out        | <b>12</b> Subwoofer Out             | <b>19</b> Video Monitor Output |
| <b>6</b> Video 1 Audio/Video Play/In    | <b>13</b> Speaker 1 Terminals       | <b>20</b> AM Antenna           |
| <b>7</b> Video 1 Audio/Video Record/Out | <b>14</b> Speaker 2 Terminals       | <b>21</b> FM Antenna           |