
Contents

About This Document.....	1
1 Components of the BTS3012 System	1-1
2 BTS3012 Cabinet.....	2-1
2.1 Structure of the BTS3012 Cabinet.....	2-2
2.2 Physical Structure of the BTS3012.....	2-3
2.3 Cable Distribution of the BTS3012.....	2-5
2.4 Engineering Specifications for the BTS3012	2-8
3 BTS3012 Auxiliary Equipment.....	3-1
3.1 Sidepower.....	3-2
3.2 EMU.....	3-5
3.3 EAC-2.....	3-5
3.4 BTS3012 Sensors.....	3-5
4 Boards and Modules of the BTS3012.....	4-1
4.1 List of the BTS3012 Boards and Modules.....	4-3
4.2 DATU.....	4-4
4.2.1 Functions of the DATU.....	4-5
4.2.2 Working Environment of the DATU.....	4-5
4.2.3 Indicators and Ports on the DATU.....	4-5
4.2.4 DIP Switches on the DATU.....	4-7
4.2.5 Specifications of the DATU.....	4-9
4.3 DCCU.....	4-9
4.3.1 Functions of the DCCU.....	4-10
4.3.2 Working Principles of the DCCU.....	4-10
4.3.3 Ports on the DCCU.....	4-11
4.3.4 Specifications of the DCCU.....	4-12
4.4 DCMB.....	4-12
4.4.1 Functions of the DCMB.....	4-12
4.4.2 Specifications of the DCMB.....	4-13
4.5 DCOM.....	4-13
4.5.1 Functions of the DCOM.....	4-13
4.5.2 Working Environment of the DCOM.....	4-13
4.5.3 Working Principles of the DCOM.....	4-14

4.5.4 Ports on the DCOM	4-14
4.5.5 Specifications of the DCOM.....	4-15
4.6 DCSU.....	4-16
4.6.1 Functions of the DCSU.....	4-16
4.6.2 Ports on the DCSU.....	4-16
4.6.3 DIP Switches on the DCSU.....	4-18
4.6.4 Specifications of the DCSU.....	4-20
4.7 DCTB.....	4-21
4.7.1 Functions of the DCTB.....	4-21
4.7.2 Ports on the DCTB.....	4-21
4.7.3 Specifications of the DCTB.....	4-22
4.8 DDPU.....	4-23
4.8.1 Functions of the DDPU.....	4-23
4.8.2 Working Environment of the DDPU.....	4-23
4.8.3 Working Principles of the DDPU.....	4-24
4.8.4 Indicators and Ports on the DDPU.....	4-25
4.8.5 Specifications of the DDPU.....	4-28
4.9 DEMU.....	4-28
4.9.1 Functions of the DEMU.....	4-29
4.9.2 Working Environment of the DEMU.....	4-29
4.9.3 Working Principles of the DEMU.....	4-30
4.9.4 Indicators and Ports on the DEMU.....	4-31
4.9.5 DIP Switches on the DEMU.....	4-32
4.9.6 Specifications of the DEMU.....	4-35
4.10 DELC.....	4-36
4.10.1 Functions of the DELC.....	4-36
4.10.2 Working Environment of the DELC.....	4-36
4.10.3 Ports on the DELC.....	4-37
4.10.4 Specifications of the DELC.....	4-37
4.11 DFCB.....	4-38
4.11.1 Functions of the DFCB.....	4-38
4.11.2 Working Environment of the DFCB.....	4-39
4.11.3 Working Principles of the DFCB.....	4-39
4.11.4 Indicators and Ports on the DFCB.....	4-41
4.11.5 Specifications of the DFCB.....	4-43
4.12 DFCU.....	4-44
4.12.1 Functions of the DFCU.....	4-44
4.12.2 Working Environment of the DFCU.....	4-45
4.12.3 Working Principles of the DFCB.....	4-45
4.12.4 Indicators and Ports on the DFCU.....	4-47
4.12.5 Specifications of the DFCU.....	4-50
4.13 DMLC.....	4-51

4.13.1 Functions of the DMLC.....	4-51
4.13.2 Working Environment of the DMLC.....	4-51
4.13.3 Ports on the DMLC.....	4-52
4.13.4 Specifications of the DMLC.....	4-53
4.14 DSAC.....	4-54
4.14.1 Functions of the DSAC.....	4-54
4.14.2 Working Environment of the DSAC.....	4-54
4.14.3 Ports on the DSAC.....	4-55
4.14.4 Specifications of the DSAC.....	4-56
4.15 DTMU.....	4-56
4.15.1 Functions of the DTMU.....	4-57
4.15.2 Working Environment of the DTMU.....	4-57
4.15.3 Working Principles of the DTMU.....	4-58
4.15.4 Indictors and Ports on the DTMU.....	4-59
4.15.5 DIP Switches on the DTMU.....	4-63
4.15.6 Specifications of the DTMU.....	4-66
4.16 DTRB.....	4-66
4.16.1 Functions of the DTRB.....	4-66
4.16.2 Working Principles of the DTRB.....	4-67
4.16.3 Specifications of the DTRB.....	4-67
4.17 DTRU.....	4-68
4.17.1 Functions of the DTRU.....	4-68
4.17.2 Working Environment of the DTRU.....	4-69
4.17.3 Working Principles of the DTRU.....	4-70
4.17.4 Indicators and Ports on the DTRU.....	4-75
4.17.5 Specifications of the DTRU.....	4-80
4.18 FAN Box.....	4-80
4.18.1 Functions of the FAN Box.....	4-81
4.18.2 Working Principles of the FAN Box.....	4-81
4.18.3 Indicators and Ports on the FAN Box.....	4-81
4.18.4 Specifications of the FAN Box.....	4-82
5 BTS3012 Cables.....	5-1
5.1 List of the BTS3012 Cables.....	5-3
5.2 Power Cables and PGND Cables of the BTS3012.....	5-10
5.2.1 Power Cables of the BTS3012.....	5-10
5.2.2 PGND Cables of the BTS3012.....	5-13
5.2.3 Equipotential Cable of the BTS.....	5-14
5.3 Power Cables on the BTS3012 Busbar.....	5-14
5.3.1 Power Cable Between the BTS3012 Busbar and the DAFU Subrack.....	5-15
5.3.2 Power Cable Between the BTS3012 Busbar and the DTRU Subrack.....	5-16
5.3.3 Power Cable Between the BTS3012 Busbar and the FAN Subrack.....	5-18
5.3.4 Power Cable Between the BTS3012 Busbar and the Common Subrack.....	5-19

5.4 Transmission Cables of the BTS3012.....	5-20
5.4.1 E1 Cable of the BTS3012/BTS3012AE.....	5-21
5.4.2 Optical Cable of the BTS3012/BTS3012AE.....	5-23
5.4.3 Ethernet Cable of the BTS3012/BTS3012AE.....	5-24
5.4.4 E1 Signal Transfer Cable of the BTS3012.....	5-26
5.5 Signal Cables of the BTS3012.....	5-28
5.5.1 Lightning Protection Failure Alarm Cable of the BTS3012.....	5-30
5.5.2 Lightning Protection Failure Alarm Cable Between BTS3012 Combined Cabinets.....	5-31
5.5.3 Power Detection Cable of the BTS3012/BTS3012AE.....	5-32
5.5.4 Cable for the Combiner on the DTRU of the BTS3012/BTS3012AE.....	5-33
5.5.5 Signal Cable Between BTS3012/BTS3012AE Combined Cabinets.....	5-34
5.5.6 Signal Cable Between BTS3012/BTS3012AE Cabinet Groups.....	5-37
5.5.7 Signal Cable Between the BTS3012 and the BTS312.....	5-39
5.5.8 Boolean Value Output Cable of the BTS3012.....	5-41
5.5.9 Boolean Value Input Cable of the BTS3012.....	5-42
5.5.10 EAC Signal Cable of the BTS3012.....	5-45
5.5.11 Dedicated Monitoring Signal Cable of the BTS3012.....	5-46
5.5.12 Environment Monitoring Signal Cable of the BTS3012.....	5-48
5.5.13 RET Control Signal Cable of the BTS3012/BTS3012AE.....	5-50
5.5.14 Signal Cables Between the DCTB and the DAFU Subrack in the BTS3012.....	5-51
5.5.15 TOP Signal Cable Between the DCCU/DCSU and the DCTB of the BTS3012.....	5-54
5.5.16 Signal Cable between the DCSU and the DTRB in the BTS3012/BTS3012AE.....	5-58
5.5.17 Boolean Value Signal Transfer Cable of the BTS3012.....	5-62
5.5.18 FAN Subrack Signal Transfer Cable of the BTS3012.....	5-65
5.5.19 Diversity Receive Short-Circuiting Cable of the BTS3012/BTS3012AE.....	5-68
5.5.20 Four-In-One Short-Circuiting Cable of the BTS3012/BTS3012AE.....	5-68
5.5.21 Signal Cable Between the DFCE and the DFCE in the BTS3012/BTS3012AE.....	5-69
5.5.22 Signal Transfer Cable Between BTS3012 Combined Cabinets.....	5-70
5.6 RF Cables of the BTS3012.....	5-74
5.6.1 RF Signal Cables of the BTS3012/BTS3012AE.....	5-74
5.6.2 Indoor 1/2-Inch Jumper of the BTS3012.....	5-75
5.7 Signal Cable Between the BTS3012 and the Auxiliary Equipment.....	5-76
5.7.1 Signal Cable for the External Environment Alarm Box of the BTS3012/BTS3012AE/BTS3006C.....	5-76
5.7.2 Power Cable Between the Sidepower and the BTS3012.....	5-77
5.7.3 Alarm Signal Cable Between the Sidepower and the BTS3012.....	5-78

Figures

Figure 1-1 BTS3012 system	1-1
Figure 2-1 BTS3012 cabinet.....	2-2
Figure 2-2 Fully configured BTS3012 cabinet	2-3
Figure 2-3 Cable distribution on the cabinet front (configured with the DDPU).....	2-5
Figure 2-4 Cable distribution on the cabinet front (configured with the DFCU).....	2-6
Figure 2-5 Internal cable distribution on the cabinet top.....	2-7
Figure 3-1 Structure of the Sidepower.....	3-2
Figure 3-2 Positive input copper bar of the Sidepower.....	3-3
Figure 3-3 Negative input copper bar of the Sidepower.....	3-3
Figure 3-4 Output ports on the Sidepower.....	3-4
Figure 3-5 Wiring terminals of the door sensor.....	3-6
Figure 3-6 Wiring terminals of the water sensor.....	3-6
Figure 3-7 Wiring terminals of the smoke sensor.....	3-6
Figure 3-8 Wiring terminals of the infrared sensor.....	3-7
Figure 3-9 Wiring terminals of the humidity/temperature sensor.....	3-7
Figure 4-1 Working environment of the DATU.....	4-5
Figure 4-2 DATU panel.....	4-6
Figure 4-3 Layout of the DIP switches on the DATU.....	4-8
Figure 4-4 Working principles of the DCCU.....	4-10
Figure 4-5 DCCU panel.....	4-11
Figure 4-6 Working environment of the DCOM.....	4-14
Figure 4-7 Working principles of the DCOM.....	4-14
Figure 4-8 DCOM panel.....	4-15
Figure 4-9 DCSU panel.....	4-17
Figure 4-10 Layout of the DIP switches on the DCSU.....	4-18
Figure 4-11 DCTB panel.....	4-22
Figure 4-12 Working environment of the DDPU.....	4-24
Figure 4-13 Working principles of the DDPU.....	4-25
Figure 4-14 DDPU panel.....	4-26
Figure 4-15 Working environment of the DEMU.....	4-29
Figure 4-16 Working principles of the DEMU.....	4-30
Figure 4-17 DEMU panel.....	4-31
Figure 4-18 Layout of the DIP switches on the DEMU.....	4-33

Figure 4-19	Working environment of the DELC.....	4-36
Figure 4-20	DELC panel.....	4-37
Figure 4-21	Working environment of the DFCB.....	4-39
Figure 4-22	Functional structure of the DFCB.....	4-40
Figure 4-23	DFCB panel.....	4-41
Figure 4-24	Working environment of the DFCU.....	4-45
Figure 4-25	Functional structure of the DFCU.....	4-46
Figure 4-26	DFCU panel.....	4-48
Figure 4-27	Working environment of the DMLC.....	4-52
Figure 4-28	DMLC panel.....	4-53
Figure 4-29	Working environment of the DSAC.....	4-55
Figure 4-30	DSAC panel.....	4-55
Figure 4-31	Working environment of the DTMU.....	4-58
Figure 4-32	Working principles of the DTMU.....	4-59
Figure 4-33	DTMU panel.....	4-60
Figure 4-34	Layout of the DIP switches on the DTMU.....	4-64
Figure 4-35	Working principles of the DTRB.....	4-67
Figure 4-36	Working environment of the DTRU.....	4-69
Figure 4-37	Working principles of the DTRU.....	4-70
Figure 4-38	Transmit independency mode.....	4-71
Figure 4-39	PBT mode.....	4-71
Figure 4-40	Wideband combination mode.....	4-72
Figure 4-41	Transmit diversity mode.....	4-72
Figure 4-42	Receive independency mode.....	4-73
Figure 4-43	Receive diversity mode.....	4-74
Figure 4-44	Four-way receive diversity mode.....	4-75
Figure 4-45	DTRU panel (type A).....	4-76
Figure 4-46	DTRU panel (type B).....	4-77
Figure 4-47	Panel of the FAN Box.....	4-82
Figure 5-1	Structure of the external power cable.....	5-11
Figure 5-2	Structure of the power cable from the cabinet top to the Busbar.....	5-11
Figure 5-3	Installation positions of the cabinet top cables.....	5-12
Figure 5-4	Structure of the PGND cable.....	5-13
Figure 5-5	Structure of the equipotential cable.....	5-14
Figure 5-6	Structure of the power cable from the Busbar to the DAFU subrack.....	5-15
Figure 5-7	Structure of the power cable between the Busbar and the DTRU subrack.....	5-17
Figure 5-8	Structure of the power cable between the Busbar and the FAN subrack.....	5-18
Figure 5-9	Structure of the power cable between the Busbar and the common subrack.....	5-20
Figure 5-10	Structure of the 75-ohm E1 cable.....	5-21
Figure 5-11	Structure of the 120-ohm E1 cable.....	5-22
Figure 5-12	Structure of the optical cable.....	5-24
Figure 5-13	Structure of the Ethernet cable.....	5-25

Figure 5-14 Structure of the E1 signal transfer cable.....	5-26
Figure 5-15 Structure of the lightning protection failure alarm cable.....	5-30
Figure 5-16 Structure of the lightning protection failure alarm cable between combined cabinets.....	5-32
Figure 5-17 Structure of the power detection cable.....	5-33
Figure 5-18 Structure of the cable for the combiner on the DTRU.....	5-34
Figure 5-19 Structure of the signal cable between combined cabinets.....	5-35
Figure 5-20 Structure of the signal cable between cabinet groups.....	5-37
Figure 5-21 Appearance of the combined-cabinet cable.....	5-40
Figure 5-22 Structure of the Boolean value output cable.....	5-41
Figure 5-23 Structure of the Boolean value output cable.....	5-43
Figure 5-24 Structure of the EAC-2 signal cable.....	5-46
Figure 5-25 Structure of the dedicated monitoring signal cable.....	5-47
Figure 5-26 Structure of the environment monitoring signal cable.....	5-49
Figure 5-27 Structure of the RET control signal cable.....	5-50
Figure 5-28 Structure of the signal cable between the DCTB and the DAFU subrack.....	5-51
Figure 5-29 Structure of the TOP signal cable between the DCCU/DCSU and the DCTB.....	5-55
Figure 5-30 Structure of the signal cable between the DCSU and the DTRB.....	5-59
Figure 5-31 Structure of the Boolean value signal transfer cable.....	5-62
Figure 5-32 Structure of the FAN subrack signal transfer cable.....	5-66
Figure 5-33 Structure of the diversity receive short-circuiting cable.....	5-68
Figure 5-34 Structure of the four-in-one short-circuiting cable.....	5-69
Figure 5-35 Structure of the signal cable between the DFCB and the DFCU.....	5-70
Figure 5-36 Structure of the signal transfer cable between combined cabinets.....	5-71
Figure 5-37 Structure of the RF RX signal cable and the RF TX signal cable.....	5-74
Figure 5-38 Structure of the indoor 1/2-inch jumper.....	5-75
Figure 5-39 Structure of the signal cable for the external environment alarm box	5-76
Figure 5-40 Structure of the power cable between the Sidepower and the BTS3012.....	5-77
Figure 5-41 Structure of the alarm signal cable between the Sidepower and the BTS3012.....	5-78

Tables

Table 2-1 Description of Cable Distribution in the Cabinet.....	2-7
Table 2-2 Dimensions (appearance)	2-9
Table 2-3 Weight of the cabinet	2-9
Table 2-4 Specifications for the input power	2-9
Table 2-5 Power consumption	2-10
Table 2-6 Power consumption	2-10
Table 3-1 Input ports on the Sidepower.....	3-3
Table 3-2 Output ports on the Sidepower.....	3-4
Table 4-1 Boards and modules of the BTS3012.....	4-3
Table 4-2 Indicators on the DATU.....	4-6
Table 4-3 Ports on the DATU.....	4-7
Table 4-4 DIP switches on the DATU.....	4-8
Table 4-5 Specifications of the DATU.....	4-9
Table 4-6 Ports on the DCCU.....	4-11
Table 4-7 Specifications of the DCCU.....	4-12
Table 4-8 Specifications of the DCMB.....	4-13
Table 4-9 Ports on the DCOM.....	4-15
Table 4-10 Specifications of the DCOM.....	4-16
Table 4-11 Ports on the DCSU panel.....	4-17
Table 4-12 Settings of SW1.....	4-19
Table 4-13 Settings of SW11.....	4-19
Table 4-14 Settings of SW2–SW5	4-19
Table 4-15 Settings of SW6 and SW7.....	4-19
Table 4-16 Settings of SW8.....	4-20
Table 4-17 Settings of SW9 and SW10.....	4-20
Table 4-18 Specifications of the DCSU.....	4-21
Table 4-19 Ports on the DCTB.....	4-22
Table 4-20 Specifications of the DCTB.....	4-22
Table 4-21 Indicators on the DDPU.....	4-26
Table 4-22 Ports on the DDPU.....	4-27
Table 4-23 Specifications of the DDPU.....	4-28
Table 4-24 Indicators on the DEMU.....	4-31
Table 4-25 Ports on the DEMU.....	4-32

Table 4-26 SW_THE DIP switches.....	4-33
Table 4-27 SW_AE DIP switches.....	4-33
Table 4-28 SW_BKE DIP switches.....	4-34
Table 4-29 SW12A/SW12B/SW24A/SW24B DIP switches.....	4-34
Table 4-30 SW_AV DIP switches.....	4-35
Table 4-31 Specifications of the DEMU.....	4-35
Table 4-32 Ports on the DELC.....	4-37
Table 4-33 Specifications of the DELC.....	4-38
Table 4-34 Indicators on the DFCB panel.....	4-42
Table 4-35 Ports on the DFCB panel.....	4-42
Table 4-36 Specifications of the DFCB.....	4-43
Table 4-37 Indicators on the DFCU panel.....	4-48
Table 4-38 Ports on the DFCU panel.....	4-49
Table 4-39 Specifications of the DFCU.....	4-50
Table 4-40 Ports on the DMLC panel.....	4-53
Table 4-41 Specifications of the DMLC.....	4-54
Table 4-42 Ports on the DSAC panel.....	4-56
Table 4-43 Specifications of the DSAC.....	4-56
Table 4-44 Indicators on the DTMU.....	4-60
Table 4-45 Ports on the DTMU.....	4-63
Table 4-46 Settings of DIP switches on the DTMU.....	4-64
Table 4-47 Specifications of the DTRB.....	4-66
Table 4-48 Specifications of the DTRB.....	4-68
Table 4-49 Indicators on the DTRU.....	4-77
Table 4-50 Ports on DTRU (type A).....	4-79
Table 4-51 Ports on DTRU (type B).....	4-79
Table 4-52 Specifications of the DTRU (type A).....	4-80
Table 4-53 Specifications of the DTRU (type B).....	4-80
Table 4-54 Indicators on the FAN Box.....	4-82
Table 4-55 Ports on the FAN Box.....	4-82
Table 4-56 Specifications of the FAN Box.....	4-83
Table 5-1 List of the BTS3012 Cables.....	5-3
Table 5-2 Installation positions of the cabinet top cables.....	5-12
Table 5-3 Installation positions of the PGND cable.....	5-13
Table 5-4 Installation positions of the equipotential cable	5-14
Table 5-5 Pins assignment for the power cable between the Busbar and the DAFU subrack.....	5-16
Table 5-6 Installation positions of the power cable between the Busbar and the DAFU subrack.....	5-16
Table 5-7 Pin assignment for the power cable between the Busbar and the DTRU subrack.....	5-17
Table 5-8 Installation positions of the power cable between the Busbar and the DTRU subrack.....	5-17
Table 5-9 Pin assignment for the power cable between the Busbar and the FAN subrack.....	5-19
Table 5-10 Installation positions of the power cable between the Busbar and the FAN subrack.....	5-19
Table 5-11 Pins assignment for the power cable between the Busbar and the common subrack.....	5-20

Table 5-12	Installation positions of the power cable between the Busbar and the common subrack.....	5-20
Table 5-13	Pin assignment for the E1 cable.....	5-22
Table 5-14	Installation positions of the E1 cable.....	5-23
Table 5-15	Installation positions of the optical cable.....	5-24
Table 5-16	Pins assignment for the Ethernet cable.....	5-25
Table 5-17	Installation positions of Ethernet cables.....	5-26
Table 5-18	Pin assignment for the E1 signal transfer cable.....	5-27
Table 5-19	Installation positions of the E1 signal transfer cable.....	5-28
Table 5-20	Pin assignment for the lightning protection failure alarm cable.....	5-30
Table 5-21	Installation positions of the lightning protection failure alarm cable	5-31
Table 5-22	Pins assignment for the lightning protection failure alarm cable between combined cabinets.....	5-32
Table 5-23	Installation positions of the lightning protection failure alarm cable of the combined cabinets....	5-32
Table 5-24	Installation positions of the power detection cable.....	5-33
Table 5-25	Installation positions of the cable for the combiner on the DTRU.....	5-34
Table 5-26	Pins assignment for the signal cable between combined cabinet.....	5-35
Table 5-27	Installation positions of the signal cable between combined cabinets.....	5-37
Table 5-28	Pins assignment for the signal cable between cabinet groups.....	5-38
Table 5-29	Installation positions of the signal cable between cabinet groups.....	5-39
Table 5-30	Pin assignment for the combined-cabinet signal cable.....	5-40
Table 5-31	Installation positions of the combined-cabinet signal cable.....	5-41
Table 5-32	Pin assignment for the Boolean value output cable.....	5-41
Table 5-33	Installation positions of the Boolean value output cable.....	5-42
Table 5-34	Pin assignment for the Boolean value input cable.....	5-43
Table 5-35	Installation positions of the Boolean value input cable.....	5-45
Table 5-36	Installation positions of the EAC signal cable	5-46
Table 5-37	Pin assignment for the dedicated monitoring signal cable.....	5-47
Table 5-38	Installation positions of the dedicated monitoring signal cable.....	5-48
Table 5-39	Pin assignment for the environment monitoring signal cable.....	5-49
Table 5-40	Installation positions of the environment monitoring signal cable.....	5-50
Table 5-41	Installation positions of the RET control signal cable.....	5-50
Table 5-42	Pins assignment for the signal cable between the DCTB and the DAFU subrack.....	5-52
Table 5-43	Installation positions of the signal cables between the DCTB and the DAFU subrack.....	5-53
Table 5-44	Pin assignment for W1.....	5-55
Table 5-45	Pins of W2.....	5-57
Table 5-46	Installation positions of the signal cable between the DCCU/DCSU and the DCTB TOP.....	5-58
Table 5-47	Pin assignment for the signal cable between the DCSU and the DTRB.....	5-59
Table 5-48	Installation positions of the signal cable between the DCSU and the DTRB.....	5-62
Table 5-49	Pin assignment for the Boolean value signal transfer cable.....	5-63
Table 5-50	Installation positions of the Boolean value signal transfer cable.....	5-65
Table 5-51	Pin assignment for W1.....	5-66
Table 5-52	Pins of W2.....	5-67
Table 5-53	Installation positions of the FAN subrack signal transfer cable	5-67

Table 5-54 Installation positions of the diversity receive short-circuiting cable.....	5-68
Table 5-55 Installation positions of the four-in-one short-circuiting cable.....	5-69
Table 5-56 Installation positions of the signal cable between the DFCB and the DFCU.....	5-70
Table 5-57 Pin assignment for the signal transfer cable between combined cabinets.....	5-71
Table 5-58 Installation positions of the signal transfer cable between combined cabinets.....	5-73
Table 5-59 Installation positions of the RF signal cables.....	5-75
Table 5-60 Installation positions of the indoor 1/2-inch jumper.....	5-76
Table 5-61 Installation positions of the signal cable for the external environment alarm box.....	5-77
Table 5-62 Installation positions of the power cable between the Sidepower and the BTS3012.....	5-78
Table 5-63 Pin assignment for the alarm signal cable between the Sidepower and the BTS3012.....	5-79
Table 5-64 Installation positions of the alarm signal cable between the Sidepower and the BTS3012.....	5-79