



Networking

Card Services for DOS

Client Access for Windows cannot run in DOS, so this is not a good choice. What you may have had in mind was using a DOS based point enabler. That will work to enable your IBM 5250 Emulation PC Card and is on the [other](#) page.



[IBM 5250 Emulation Home Page](#)

