HRRS-10kV SERIES

High Resistance, 10kV Decade Substituter User and Service Manual



Copyright © 2011 IET Labs, Inc. Visit www.ietlabs.com for manual revision updates

HRRS-10kV im/March 2011





IET LABS, INC. Standards • Decades • Strobes • Sound Level Meters • Bridges www.ietlabs.com 534 Main Street, Westbury, NY 11590 TEL: (516) 334-5959 • (800) 899-8438 • FAX: (516) 334-5988

WARRANTY

We warrant that this product is free from defects in material and workmanship and, when properly used, will perform in accordance with applicable IET specifications. If within one year after original shipment, it is found not to meet this standard, it will be repaired or, at the option of IET, replaced at no charge when returned to IET. Changes in this product not approved by IET or application of voltages or currents greater than those allowed by the specifications shall void this warranty. IET shall not be liable for any indirect, special, or consequential damages, even if notice has been given to the possibility of such damages.

THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING BUT NOT LIMITED TO, ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE.



OBSERVE ALL SAFETY RULES WHEN WORKING WITH HIGH VOLTAGES OR LINE VOLTAGES.

Dangerous voltages may be present inside this instrument. Do not open the case Refer servicing to qualified personnel

HIGH VOLTAGES MAY BE PRESENT AT THE TERMINALS OF THIS INSTRUMENT

WHENEVER HAZARDOUS VOLTAGES (> 45 V) ARE USED, TAKE ALL MEASURES TO AVOID ACCIDENTAL CONTACT WITH ANY LIVE COMPONENTS.

USE MAXIMUM INSULATION AND MINIMIZE THE USE OF BARE CONDUCTORS WHEN USING THIS INSTRUMENT.

Use extreme caution when working with bare conductors or bus bars.

WHEN WORKING WITH HIGH VOLTAGES, POST WARNING SIGNS AND KEEP UNREQUIRED PERSONNEL SAFELY AWAY.



DO NOT APPLY ANY VOLTAGES OR CURRENTS TO THE TERMINALS OF THIS INSTRUMENT IN EXCESS OF THE MAXIMUM LIMITS INDICATED ON THE FRONT PANEL OR THE OPERATING GUIDE LABEL.

Table of Contents

Chapter 1: Introduction
1.1 Overview
Chapter 2: Specifications
Specifications
Ordering Information
Chapter 3: Operation
3.1 Initial Inspection and Setup
3.2 Dial Setting
3.3 Environmental Conditions
3.4 Storage
Chapter 4: Maintenance
4.1 Maintainability and Reliability
4.2 Preventive Maintenance
4.3 Verification of Performance
4.3.1 Calibration Interval
4.3.2 General Considerations
4.3.3 Calibration Procedure
4.4 Schematic
4.5 Replaceable Parts

Figures and Tables

Figure 1-1: HRRS-10kV Series High-Resistance, Decade Substituter1
Figure 2-1: HRRS-10kV sample label
Figure 4-1: HRRS-10kV Series Schematic Diagram6
Table 4-1: Replaceable Parts 7
Figure 4-2: Replaceable Parts7

This page is intentionally left blank

Chapter 1 INTRODUCTION

1.1 Overview

The High Resistance, 10 kV Decade Substituter (**HRRS-10kV** Series, Figure 1.1) is a family of instruments that answers the need of the calibration and test community for decades and working standards that go up to $10 \text{ T}\Omega$, offering a broad choice of high-range, excellent performance resistance sources. High values of resistance are available for use at high voltages, without sacrificing accuracy, stability, and temperature and power coefficients of resistance.

The HRRS-10kV Series employs state-of-the-art precision resistors of various types. It is designed specifically for operation at high voltage, with very low leakage to minimize degradation of accuracy.

The standard models offer a choice of one to nine decades. The panels are clearly labeled showing the step size and maximum allowable applied input for each decade. Custom requirements outside of the standard models can be satisfied.

The binding posts are insulated with Kel-F highresistance, non-moisture-absorbing material to ensure low leakage.

With a resolution as low as 10 Ω and a maximum available resistance of 10 T Ω , the HRRS-10kV Series may be used for exacting precision high-value resistance applications that require voltages of up to 10 kV.

Applications include calibration of meters and megohmmeters, and checking of electrochemical and biomedical sensors and instruments. These instruments are useful wherever high resistances are required, such as in testing high-impedance amplifiers and the insulation of low-power circuits.



Figure 1-1: HRRS-10kV Series High-Resistance, High-Voltage Decade Substituter

Chapter 2 SPECIFICATIONS

For convenience to the user, the pertinent specifications are given in an **OPERATING GUIDE** affixed to the case of the instrument. Figure 2.1 shows a typical example.

SPECIFICATIONS -

Desistance	Total decade Accuracy		/	Max voltage	Maximum	Temperature	Voltage	Stability		
Resistance per step	resistance	Q	В	F	per step (V)	Voltage (V)	coefficient (±ppm/ºC)	coefficient (±ppm/V)	(±ppm/yr)	Resistor Type
10 Ω	100 Ω	0.01%	0.03%	0.1%	2.5	25	15	0	10	Wirewound, non-inductive
100 Ω	1 kΩ	0.01%	0.03%	0.1%	8	80	5	0	10	Wirewound, non-inductive
1 kΩ	10 kΩ	0.01%	0.03%	0.1%	23	230	5	0	10	Wirewound, non-inductive
10 kΩ	100 kΩ	0.01%	0.03%	0.1%	70	700	5	0	10	Wirewound, non-inductive
100 kΩ	1 MΩ	0.01%	0.03%	0.1%	230	2300	5	0	10	Wirewound, non-inductive
1 MΩ	10 MΩ	0.01%	0.03%	0.1%	1000	10,000	15	0.2	25	High-voltage film
10 MΩ	100 MΩ	0.03%	0.1%	1%	5000	10,000	15	0.2	50	High-voltage film
100 MΩ	1 GΩ	0.1%	0.2%	1%	10,000	10,000	25	1.5	100	High-voltage film
1 GΩ	10 GΩ	0.2%	0.5%	1%	10,000	10,000	25	5	500	High-voltage film
10 GΩ	100 GΩ	0.5%	1%	1%	10,000	10,000	25	5	500	High-voltage film
100 GΩ	1 ΤΩ	0.5%	1%	1%	10,000	10,000	100	5	500	High-voltage film
1 ΤΩ	10 TΩ	3%	5%	10%	10,000	10,000	300	5	500	High-voltage film

Zero Resistance

 $<3 \text{ m}\Omega$ per decade

Environmental Conditions

Operating Conditions: 10°C to 23°C; <50% RH **Storage Conditions:** -40°C to 70°C

Terminals

Two five-way binding posts on 2 special, lowleakage, Kel-F insulating sockets, and one metal ground binding post electrically connected to the case

Mechanical:

Model	Dimensions	Weight
3-4 Decade	43.2 cm W x 14.2 cm H x 13.5 cm D	3.4 kg
Units	(17" x 5.6" x 5.3")	(7.5 lbs)
5-7 Decade	48.2 cm W x 22.2 cm H x 33 cm D	5 kg
Units	(19" x 8.75" x 13")	(11 lbs)
8-9 Decade	43.7 cm W x 30.7 cm H x 20.3 cm D	7.7 kg
Units	(17.2" x 12.1" x 8")	(17 lbs)

ORDERING INFORMATION

Model	Total Resistance	Number of Decades	Resolution
HRRS-*-3-100k-10kV	111 MΩ	3	100 kΩ
HRRS-*-3-1M-10kV	1.11 GΩ	3	1 MΩ
HRRS-*-3-10M-10kV	11.1 GΩ	3	10 MΩ
HRRS-*-3-100M-10kV	111 GΩ	3	100 MΩ
HRRS-*-3-1G-10kV	1.11 ΤΩ	3	1 GΩ
HRRS-*-3-10G-10kV	11.1 ΤΩ	3	10 GΩ
HRRS-*-4-10k-10kV	111.1 MΩ	4	10 kΩ
HRRS-*-4-100k-10kV	1.111 GΩ	4	100 kΩ
HRRS-*-4-1M-10kV	11.11 GΩ	4	1 MΩ
HRRS-*-4-10M-10kV	111.1 GΩ	4	10 MΩ
HRRS-*-4-100M-10kV	1.111 ΤΩ	4	100 MΩ
HRRS-*-4-1G-10kV	11.11 ΤΩ	4	1 GΩ
HRRS-*-5-1k-10kV	111.11 MΩ	5	1 kΩ
HRRS-*-5-10k-10kV	1.111 1 GΩ	5	10 kΩ
HRRS-*-5-100k-10kV	11.111 GΩ	5	100 kΩ
HRRS-*-5-1M-10kV	111.11 GΩ	5	1 MΩ
HRRS-*-5-10M-10kV	1.111 1 ΤΩ	5	10 MΩ
HRRS-*-5-100M-10kV	11.111 ΤΩ	5	100 MΩ
HRRS-*-6-10-10kV	11.111 1 MΩ	6	10 Ω
HRRS-*-6-100-10kV	111.111 MΩ	6	100 Ω
HRRS-*-6-1k-10kV	1.111 11 GΩ	6	1 kΩ
HRRS-*-6-10k-10kV	11.111 1 GΩ	6	10 kΩ
HRRS-*-6-100k-10kV	111.111 GΩ	6	100 kΩ
HRRS-*-6-1M-10kV	1.111 11 ΤΩ	6	1 MΩ
HRRS-*-6-10M-10kV	11.111 1 ΤΩ	6	10 MΩ

Model	Total Resistance	Number of Decades	Resolution
HRRS-*-7-10-10kV	111.111 1 MΩ	7	10 Ω
HRRS-*-7-100-10kV	1.111 111 GΩ	7	100 Ω
HRRS-*-7-1k-10kV	11.111 11 GΩ	7	1 kΩ
HRRS-*-7-10k-10kV	111.111 1 GΩ	7	10 kΩ
HRRS-*-7-100k-10kV	1.111 111 ΤΩ	7	100 kΩ
HRRS-*-7-1M-10kV	11.111 11 ΤΩ	7	1 MΩ
HRRS-*-8-10-10kV	1,111.111 1 MΩ	8	10 Ω
HRRS-*-8-100-10kV	11.111 111 GΩ	8	100 Ω
HRRS-*-8-1k-10kV	111.111 11 GΩ	8	1 kΩ
HRRS-*-8-10k-10kV	1,111.111 1 GΩ	8	10 kΩ
HRRS-*-8-100k-10kV	11.111 111 ΤΩ	8	100 kΩ
HRRS-*-9-10-10kV	11,111.111 1 MΩ	9	10 Ω
HRRS-*-9-100-10kV	111.111 111 GΩ	9	100 Ω
HRRS-*-9-1k-10kV	1,111.111 11 GΩ	9	1 kΩ
HRRS-*-9-10k-10kV	11,111.111 1 GΩ	9	10 kΩ

*To specify accuracy, replace * with "Q," "B," or "F" as required.

Options

- -RM: Rack mountable case for standard 19" rack
- -K: Kelvin-type 4-terminal posts
- -RO: Rear output

		Accuracy Max voltage Maximum Temperature Voltage Chability			Zero Resistance										
Resistance per step	Total decade resistance	Q	в	F	per step (V)	Voltage (V)	coefficient (±ppm/ºC)	coefficient (±ppm/V)	Stability (±ppm/yr)	Resistor Type	<3 mΩ per decade Environmental Conditions				
10 Ω	100 Ω	0.01%	0.03%	0.1%	2.5	25	15	0	10	Wirewound, non-inductive	Operating Conditions: 10°C to 23°C; <50% RH				
100 Ω	1 kΩ	0.01%	0.03%	0.1%	8	80	5	0	10	Wirewound, non-inductive	Storage Conditions: -40°C to 70°C				
1 k Ω	10 kΩ	0.01%	0.03%	0.1%	23	230	5	0		Wirewound, non-inductive	Terminals				
10 k Ω	100 kΩ	0.01%	0.03%	0.1%	70	700	5	0		Wirewound, non-inductive	Two five-way binding posts on 2 special, low-				
100 k Ω	1 MΩ	0.01%	0.03%	0.1%	230	2300	5	0	10	Wirewound, non-inductive	leakage, Kel-F insulating sockets, and one metal ground binding post electrically connected to the case				
1 MΩ	10 MΩ	0.01%	0.03%	0.1%	1000	10 k	15	0.2	25	High-voltage film					
10 MΩ	100 MΩ	0.03%	0.1%	1%	5000	10 k	15	0.2	50	High-voltage film					
100 MΩ	1 GΩ	0.1%	0.2%	1%	10 k	10 k	25	1.5		High-voltage film	Keep unit in a sealed environment when not in use. Maintain binding post area clean for minimum electrical leakage.				
1 G Ω	10 GΩ	0.2%	0.5%	1%	10 k	10 k	25	5		High-voltage film					
10 GΩ	100 GΩ	0.5%	1%	1%	10 k	10 k	25	5		High-voltage film					
100 G Ω	1 TΩ	0.5%	1%	1%	10 k	10 k	100	5		High-voltage film					
1 Τ Ω	10 TΩ	3%	5%	10%	10 k	10 k	300	5	500	High-voltage film					
WARNING MODEL: HRRS-B-6-10M-10kV SN: B2-1104509 Observe all safety rules when working with high voltages or line voltages. Connect the (G) terminal to earth ground in order to maintain the case at a safe voltage. Whenever hazardous voltages (> 45 V) are used, take all measures to avoid accidental contact with any live components: a) Use maximum insulation and minimize the use of bare conductors. b) Remove power when adjusting switches. c) Post warning signs and keep personnel safely away. Image: Comparison of the comparison of th															

Figure 2-1: HRRS-10kV sample label

Chapter 3 OPERATION

3.1 Initial Inspection and Setup

This instrument was carefully inspected before shipment. It should be in proper electrical and mechanical order upon receipt.

An **OPERATING GUIDE** is attached to the case of the instrument to provide ready reference to specifications.

3.2 Dial Setting

Whenever the dials are used in positions 0-9, the resulting resistance is read directly. Both the decimal point and the steps are clearly marked on the panel.

For additional flexibility and range, each decade provides a "10" position setting. This "10" position on any one decade equals the "1" position on the next higher decade. It adds about 11% to the nominal total decade resistance.

To determine the resistance obtained when one or more "10" settings are used, simply add "1" to the next higher decade. For example, a setting of 3-6-10-0-10 Ω becomes:

and a setting of 10-10-10-10-10.10 Ω becomes:

тот	1	1	1	1	1	1.0
.10						1.0
10					1	0.0
10				1	0	0.0
10			1	0	0	0.0
10		1	0	0	0	0.0
10	1	0	0	0	0	0.0

3.3 Environmental Conditions

For optimal accuracy, the decade box should be used in an environment of 23°C. It should be allowed to stabilize at that temperature after any significant temperature variation.

Humidity should be maintained at laboratory conditions. This is especially important if high resistances are involved.

3.4 Storage

If this instrument is to be stored for any lengthy period of time, it should be sealed in plastic and stored in a dry location. It should not be subjected to temperature extremes beyond the specifications. Extended exposure to such temperatures can result in an irreversible change in resistance, and require recalibration.

Chapter 4 MAINTENANCE

4.1 Maintainability and Reliability

It is possible to maintain Model HRRS-10kV indefinitely. It is reliable due to its closed design and sealed switches and resistors. The unit is resistant to electromagnetic interference (EMI) because of its metal enclosure.

4.2 Preventive Maintenance

Keep the unit in a clean environment. This will help prevent possible contamination.

The Model HRRS-10kV is packaged in a closed case and uses completely sealed switches. This limits the entry of contaminants and dust to the inside of the switches. If it is maintained in a clean or air-conditioned environment, cleaning will seldom be required.

The front panel should be periodically cleaned to eliminate any leakage paths from near or around the binding posts. To clean the front panel:

Wipe the front panel clean using alcohol and a lint-free cloth

4.3 Verification of Performance

4.3.1 Calibration Interval

The **HRRS-10kV** Series instruments should be verified for performance at a calibration interval of twelve (12) months. This procedure may be carried out by the user if a calibration capability is available, by IET Labs, or by a certified calibration laboratory.

If the user should choose to perform this procedure, then the considerations below should be observed.

4.3.2 General Considerations

It is important, whenever testing the HRRS-10kV Series Decade Units, to be aware of the capabilities and limitations of the test instruments used. A resistance bridge may be employed, and there are direct-reading resistance meters or digital multimeters available that can verify the accuracy of these units, especially when used in conjunction with standards that can serve to confirm or improve the accuracy of the testing instrument

Such test instruments must have a 4:1 TUR capability for each value calibrated. Note that the accuracy varies for different decades. A number of commercial bridges and meters exist that can perform this task; consult IET Labs.

It is important to allow both the testing instrument and the HRRS-10kV Substituter to stabilize for a number of hours at the nominal operating temperature of 23°C, and at nominal laboratory conditions of humidity. There should be no temperature gradients across the unit under test.

4.5 Replaceable Parts

Model Ref	IET Pt No	Description
1	32-21	Binding Post, Red
2	32-20	Binding Post, Black
3	32-21A	Binding Post, Green
4	32-19	Binding Post, Gold
5	HARS-X-4300-KNB	Knob Assembly
Not Shown	HRRS-6500-B-10-10kV	10 Ω /step Decade Switch Assembly
Not Shown	HRRS-6500-B-100-10kV	100 Ω /step Decade Switch Assembly
Not Shown	HRRS-6500-B-1k-10kV	1 k Ω /step Decade Switch Assembly
Not Shown	HRRS-6500-B-10k-10kV	10 k Ω /step Decade Switch Assembly
Not Shown	HRRS-6500-B-100k-10kV	100 k Ω /step Decade Switch Assembly
Not Shown	HRRS-6500-B-1M-10kV	1 M Ω /step Decade Switch Assembly
Not Shown	HRRS-6500-B-10M-10kV	10 M Ω /step Decade Switch Assembly
Not Shown	HRRS-6500-B-100M-10kV	100 M Ω /step Decade Switch Assembly
Not Shown	HRRS-6500-B-1G-10kV	1 G Ω /step Decade Switch Assembly
Not Shown	HRRS-6500-B-10G-10kV	$10 \text{ G}\Omega$ /step Decade Switch Assembly
Not Shown	HRRS-6500-B-100G-10kV	$100 \text{ G}\Omega$ /step Decade Switch Assembly
Not Shown	HRRS-6500-B-1T-10kV	$1 \text{ T}\Omega$ /step Decade Switch Assembly

Table 4-1: Replaceable Parts




Figure 4-2: Replaceable Parts