



Calibre : 9232 / 1950

Function : Hour, Minute & Second hands, Date, day



Illustration



A. Set the time - Hour, Minute



B. Set the Date




Quick Correction of Date :

1. Pull the crown out to position 2 .
2. Turn the crown clockwise step-by-step to the desired date.
3. Push the crown back to position 1 .

!! Attention !! : please Do Not set it between 21:00 and 00:30 midnight

D. Set the Day



Battery : 371 – SR920SW