


JVC




Home Docking Kit

SIRIUS

KS-K6003



INSTALLATIONS



LVT1196-001A
[J]

Safety Precautions

CAUTION:

Take the following precautions to keep the unit in proper working order:

- Installation must be performed according to this installation manual. JVC PnP is not responsible for issues arising from installations not performed according to the procedures in this manual.
- Use only the included power supply.
- Do not install the unit where it will be exposed to high levels of humidity, moisture, or dust.

NOTE: Use of the included antenna inside a home requires placement at a North-, West-, or East-facing window (depending on where you live). If a proper window location is not available, the antenna must be placed outside the home, away from any overhead obstructions.

Box Contents

After you unpack your Home Docking Kit, make sure everything here is included:

Home Docking Cradle



SIRIUS® Antenna



Power Supply



AC Power Cord



Audio Cord



For the latest information about this and other JVC PnP products, visit the JVC Web site at <<http://www.jvcmobile.com>>. If anything is missing or damaged, or if your Home Docking Kit fails to operate, notify your shipper immediately. It is recommended that you keep the original packaging in case you need to ship your Home Docking Kit in the future.

Installation in a Home




CAUTION:

Do not put JVC PnP in the home docking cradle until you have completed the installation.

1 Plug the audio cable's mini connector into the back of the cradle—AUDIO OUT.



2 Plug the audio cable's white (L ch) and red (R ch) connectors into your audio system.






CAUTION:

Do not plug the AC cord into a wall outlet until you have completed the installation.

3 Plug the AC cord into the power supply.



4 Plug the power supply into the back of the cradle—DC 12V.



To be continued...

- 5** Plug the antenna into the back of the cradle—
ANT until it is firmly secured.



- 6** Place the antenna near a window.

- Use the map on the next page as a general placement guideline—some experimentation may be needed to obtain the best results.



SIRIUS Satellite map

Due to the paths of SIRIUS satellites over the US, the best location for the antenna in your home depends on where you live. Use the map below as a general placement guideline.

In major US cities, you may also be able to receive the signal from SIRIUS ground repeaters, which may allow you to place the antenna away from a window. In all cases, since the antenna is weather-proof you can also locate it outside if necessary, clear of any overhead obstructions. (This is especially important if your house has an extended roof or extended window frame structures.)

Area **1**: Place the antenna at an EAST-facing window.


Area **2**: Place the antenna OUTSIDE, away from any overhead obstructions.

Area **3**: Place the antenna at a WEST-facing window.

Area **4**: Place the antenna at a NORTH- or EAST-facing window.

Area **5**: Place the antenna at a NORTH-facing window.

Area **6**: Place the antenna at a WEST- or NORTH-facing window.





<http://www.jvcmobile.com>

Visit us on-line for

Technical Support & Customer Satisfaction Survey.

US RESIDENTS ONLY

Having TROUBLE with operation?

USA ONLY

Call 1-800-252-5722

<http://www.jvc.com>

We can help you!

JVC

VICTOR COMPANY OF JAPAN, LIMITED

