

JVC

RK-C20BL/RK-C20BLG PLASMA DISPLAY STAND

ASSEMBLY INSTRUCTIONS
(TO BE RETAINED BY CUSTOMER)

IMPORTANT NOTES

- THIS STAND MUST BE USED ONLY WITH THE FOLLOWING JVC TV's PD-42V31, PD-35B50, PD-42B50, PD-42Z50 & PD-50Z50
- DO NOT USE ANY SCREWS OTHER THAN THOSE PROVIDED
- DO NOT USE SOLVENTS FOR CLEANING THIS STAND. USE A DAMP CLOTH TO REMOVE ANY HANDLING OR PACKAGING MARKS
- DO NOT ATTEMPT TO MOVE THE ASSEMBLY WITH TV ATTACHED AS THIS MAY RESULT IN PERSONAL INJURY AND OR DAMAGE TO YOUR EQUIPMENT.

AEM4201-001A-U

A		x 6	G		x 4
B		x 6	H		x 4
C		x 6			
D		x 4			x 1
E		x 3			
F		x 2			x 1

Also Required

K x 1

1

2

3

