JVC SERVICE MANUAL COLOUR TELEVISION



BASIC CHASSIS

CL-M

Supplement

The following item for the AV-N2043(SF/B) model was changed from AV-N2043(SF) model.

Therefore, this service manual describes only the items which differ from those of the AV-N2043(SF) service manual.

For details other than those described in this manual, please refer to the AV-N2043(SF) service manual (No.51561 May. 1999).

Since the picture tube was changed, we have issued the SERVICE MANUAL for AV-N2043(SF/B).

HOW TO IDENTIFY MODELS

Identify that the model name "AV-N2043SF/B" is printed on the margin of the rating label affixed to the rear cover.

■ DIFFERENCE LIST

• USING PW BOARD

Model PWB A'SSY	AV-N2043(SF)	AV-N2043(SF/B)	Remark
MAIN PWB	SCL-1271A-CK	SCL-1292A-CK	Not interchangeable

• EXPLODED VIEW PARTS LIST (Page 30)

		Parts No.		D (N	
	Ref. No.	AV-N2043(SF)	AV-N2043(SF/B)	Parts Name	Remarks
⚠	V01	A48KXR064X41	A48LRV020X09528	PICTURE TUBE	Not interchangeable
⚠	L01	QQW0039-001	QQW0061-001	DEG COIL	↑
⚠	6	CM23113-006	CM23113-016	RATING LABEL	^

PACKING PARTS LIST (Back cover)

CP30902-058(R) POSS LABEL Addition

• PRINTED WIRING BOARD PARTS LIST (Page 32-35)

	Symbol No.	Parts No.			
		SCL-1271A-CK (AV-N2043(SF))	SCL-1292A-CK (AV-N2043(SF/B))	Parts Name	Description
	R1432-33	QRE121J-4R7Y	QRE121J-6R8Y	CR	6.8 Ω 1/2W
	R1529	QRG029J-391		OM R.	Delete
⚠	C1527	QFZ0151-514	QFZ0197-374	MPP CAP	0.37 µ F 250V J
	L1551	QQLZ018-540	QQLZ018-460	HEATER CHOKE	
	S1751-55	QSP1A11-C18Z	QSW0619-003Z	PUSH SWITCH	

