

JVC

SERVICE MANUAL

COLOUR TELEVISION

BASIC CHASSIS

JK II

AV28WT5EPB AV28WT5EKB

Supplement

The following item for the AV28WT5EPB / AV28WT5EKB models were changed from AV28WT5EPS / AV28WT5EKS models.

Therefore, this service manual describes only the items which differ from those of the AV28WT5EPS / AV28WT5EKS service manual.

For details other than those described in this manual, please refer to the AV28WT5EPS / AV28WT5EKS Service Manual (No.51776 Jan. 2001).

■ OUTLINE

Since the cabinet colour was changed, we have issued the SERVICE MANUAL for AV28WT5EPB / AV28WT5EKB.

■ DIFFERENCE LIST

● EXPLODED VIEW PARTS LIST (Page 42)

| △ | Ref. No. | Parts No. | | Parts Name | Remarks |
|---|----------|----------------------|----------------------|----------------------|---------------------|
| | | AV28WT5EPS | AV28WT5EPB | | |
| | | AV28WT5EKS | AV28WT5EKB | | |
| △ | 7 | LC11020-001C-U | LC11020-002A-U | AV BOARD | Not interchangeable |
| △ | 11 | CM12582-A05-E | CM12582-B04-E | REAR COVER | ↑ |
| △ | 13 | LC20433-008A-U | LC20433-009A-U | RATING LABEL | ↑ |
| △ | 14 | LC20434-008A-U (EPS) | LC20434-009A-U (EPB) | RATING LABEL | ↑ |
| | | LC20091-023A-U (EKS) | LC20091-037A-U (EKB) | | |
| | 16 | CM48125-010 | CM48125-005 | JVC MARK | ↑ |
| △ | 100 | CM12677-00Y-E | CM12677-A0Z-E | F. CABINET ASS'Y | ↑ |
| △ | 101 | CM22898-020-E | CM22898-015-E | DOOR (SERVICE) | ↑ |
| △ | 105 | CM36225-014-E | CM36225-A10-E | POWER KNOB (SERVICE) | ↑ |

● PACKING PARTS LIST (Page 55)

| △ | Ref. No. | Parts No. | | Parts Name | Remarks |
|---|----------|---------------------|---------------------|--------------|---------------------|
| | | AV28WT5EPS | AV28WT5EPB | | |
| | | AV28WT5EKS | AV28WT5EKB | | |
| | 2 | AEM1052-031-E (EPS) | AEM1052-060-E (EPB) | EURO LABEL | Not interchangeable |
| | | AEM1052-029-E (EKS) | AEM1052-059-E (EKB) | | |
| | 5 | RM-C54-1C (EPS) | RM-C50-1C (EPB) | REMOCON UNIT | ↑ |
| | | RM-C55-1C (EKS) | RM-C51-1C (EKB) | | |

● REMOTE CONTROL UNIT PARTS LIST (Page 40)

| △ | Ref. No. | Parts No. | | Parts Name | Remarks |
|---|----------|-------------------------------|-------------------------------|---------------|---------------------|
| | | RM-C54-1C (FOR AV28WT5EPS) | RM-C50-1C (FOR AV28WT5EPB) | | |
| | | RM-C55-1C (FOR AV28WT5EKS) | RM-C51-1C (FOR AV28WT5EKB) | | |
| | 1 | 2AA030733 | 2AA027770 | BATTERY COVER | Not interchangeable |
| | 2 | 2AA030732 (EPS) | 2AA027761 (EPB) | SLIDE COVER | ↑ |
| | | 2AA030740 (EKS) | 2AA027762 (EKB) | | |

JVC

VICTOR COMPANY OF JAPAN, LIMITED

HOME AV NETWORK BUSINESS UNIT 12, 3-chome, Moriya-cho, Kanagawa-ku, Yokohama, Kanagawa-prefecture, 221-8528, Japan

AV28WT5EPB-U #999
AV28WT5EKB-U #999



Printed in Japan
VP 0109
DP2051