

JVC

SERVICE MANUAL

COLOUR TELEVISION

BASIC CHASSIS

JK II

AV28WT5EPS AV24WT5EPS
AV28WT5EIS AV24WT5EIS
AV28WT5EKS AV24WT5EKS

Supplement

We have changed the production country for some parts. As a result, some parts No. have been changed. Therefore, this service manual describes only these parts No..

For others, please use the service manual for AV28WT5EPS/AV28WT5EIS/AV28WT5EKS/
AV24WT5EPS/AV24WT5EIS/AV24WT5EKS (No.51776, Jan. 2001).

■ **DIFFERENCE LIST (28" MODELS)**

● **USING PW BOARD & REMOTE CONTROL UNIT (AV28WT5EPS/AV28WT5EIS) (Page 40)**

Model	AV28WT5EPS/AV28WT5EIS		Remark
	Before	After	
PWB A'SSY			
MAIN PWB	SJK-1712A-U2	←	Not change
POWER & DEF PWB	SJK-2512A-U2	SJK-2512A-H3	Interchangeable
CRT SOCKET PWB	SJK-3512A-U2	SJK-3512A- H3	↑
FRONT CONTROL PWB	SJK-8512A-U2	SJK-8512A- H3	↑
AV SEL. PWB	SJK0S712A-U2	SJK0S712A- H3	↑
REMOTE CONTROL UNIT	RM-C54-1C/RM-C55-1C	RM-C54H-1C/RM-C55H-1C	Not interchangeable

● **USING PW BOARD & REMOTE CONTROL UNIT (AV28WT5EKS) (Page 40)**

Model	AV28WT5EKS		Remark
	Before	After	
PWB A'SSY			
MAIN PWB	SJK-1912A-U2	←	Not change
POWER & DEF PWB	SJK-2512A-U2	SJK-2512A-H3	Interchangeable
CRT SOCKET PWB	SJK-3512A-U2	SJK-3512A- H3	↑
FRONT CONTROL PWB	SJK-8512A-U2	SJK-8512A- H3	↑
AV SEL. PWB	SJK0S912A-U2	SJK0S912A- H3	↑
REMOTE CONTROL UNIT	RM-C55-1C	RM-C55H-1C	Not interchangeable

● **EXPLODED VIEW PARTS LIST (AV28WT5EPS/AV28WT5EIS/AV28WT5EKS) (Page 42)**

△	Ref. No.	Parts No.		Parts Name
		Before	After	
△	7	LC11020-001B-U	LC11020-001C-U	AV BOARD
△	100	CM12677-00Y-E	CM12677-A0Y-E	F. CABINET ASS'Y

● **PACKING PARTS LIST (AV28WT5EPS/AV28WT5EIS/AV28WT5EKS) (Page 55)**

△	Ref. No.	Parts No.		Parts Name
		Before	After	
	1	AEM1002-B67-E	AEM1002-C67-E	EURO BOX (AV28WT5EPS/AV28WT5EIS)
	1	AEM1002-C50-E	AEM1002-C67-E	EURO BOX (AV28WT5EKS)

■ **DIFFERENCE LIST (24" MODELS)**

● **USING PW BOARD & REMOTE CONTROL UNIT (AV24WT5EPS/AV24WT5EIS) (Page 41)**

Model	AV24WT5EPS/AV24WT5EIS		Remark
	Before	After	
PWB A'SSY			
MAIN PWB	SJK-1713A-U2	←	Not change
POWER & DEF PWB	SJK-2513A-U2	SJK-2513A-H3	Interchangeable
CRT SOCKET PWB	SJK-3513A-U2	SJK-3513A- H3	↑
FRONT CONTROL PWB	SJK-8513A-U2	SJK-8513A- H3	↑
AV SEL. PWB	SJK0S713A-U2	SJK0S713A- H3	↑
REMOTE CONTROL UNIT	RM-C54-1C/RM-C55-1C	RM-C54H-1C/RM-C55H-1C	Not interchangeable

● **USING PW BOARD & REMOTE CONTROL UNIT (AV24WT5EKS) (Page 41)**

Model	AV24WT5EKS		Remark
	Before	After	
PWB A'SSY			
MAIN PWB	SJK-1913A-U2	←	Not change
POWER & DEF PWB	SJK-2513A-U2	SJK-2513A-H3	Interchangeable
CRT SOCKET PWB	SJK-3513A-U2	SJK-3513A- H3	↑
FRONT CONTROL PWB	SJK-8513A-U2	SJK-8513A- H3	↑
AV SEL. PWB	SJK0S913A-U2	SJK0S913A- H3	↑
REMOTE CONTROL UNIT	RM-C55-1C	RM-C55H-1C	Not interchangeable

● **EXPLODED VIEW PARTS LIST (AV24WT5EPS/AV24WT5EIS/AV24WT5EKS) (Page 56)**

△	Ref. No.	Parts No.		Parts Name
		Before	After	
△	7	LC11010-002B-U	LC11010-002D-U	AV BOARD
△	14	LC20434-007A-U	LC20896-001A-U	RATING LABEL [AV28WT5EPS]
△	100	CM12673-00H-E	CM12673-A0H-E	F. CABINET ASS'Y

● **PACKING PARTS LIST (AV24WT5EPS/AV24WT5EIS/AV24WT5EKS) (Page 69)**

△	Ref. No.	Parts No.		Parts Name
		Before	After	
	1	AME1002-C50-E	AME1002-D50-E	EURO BOX
△	7	LCT0899-001A-U	LCT0899-001B-U	INST BOOK [AV24WT5EKS]
	11	2824WT5-HSAEI	2824WT5-HSBEI	S. DIAGRAM [AV24WT5EPS]

JVC

VICTOR COMPANY OF JAPAN, LIMITED

HOME AV NETWORK BUSINESS UNIT 12, 3-chome, Moriya-cho, Kanagawa-ku, Yokohama, Kanagawa-prefecture, 221-8528, Japan

28WT5EPS-HU	#999	24WT5EPS-HU	#999
28WT5EIS-HU	#999	24WT5EIS-HU	#999
28WT5EKS-HU	#999	24WT5EKS-HU	#999



Printed in Japan
VP 0109
DP2051