

# JVC

# SERVICE MANUAL

## COLOUR TELEVISION

# AV28R10EKSL/A

BASIC CHASSIS

JK

## Supplement

The following item for the AV28R10EKSL/A model was changed partly from AV-28WFR1EKS/A model. Therefore, this service manual describes only the items which differ from those of the AV-28WFR1EKS/A service manual.

For details other than those described in this manual, please refer to the AV-28WFR1EKS/A service manual (No.51695B Nov. 2000) and AV-28WFT1EKS service manual (No.51695 Mar. 2000).

### ■ OUTLINE

This model is colour variant model of AV-28WFR1EKS/A.

### ■ DIFFERENCE LIST

#### ● USING PW BOARD (Page 35)

PWB A'SSY \ Model	AV-28WTR1EKS	AV-28WFR1EKS/A	AV28R10EKSL/A
MAIN PWB	SJK-1904A-U2	SJK-1906A-U2	←
DOLBY PWB	SJK0D501A-U2	←	←→ SJK0D501A-H3
POWER & DEF PWB	SJK-2504A-U2	SJK-2508A-U2	←→ SJK-2508A-H3
CRT SOCKET PWB	SJK-3502A-U2	SJK-3503A-U2	←→ SJK-3503A-H3
FRONT CONTROL PWB	SJK-8504A-U	SJK-8506A-U2	←→ SJK-8506A-H3
AV SEL. PWB	SJK-0S902A-U2	SJK0S905A-U2	←→ SJK0S905A-H3

Note ←→ Mark : Interchangeable

● EXPLODED VIEW PARTS LIST

(Page 36)

△	Ref. No.	Parts No.		Parts Name
		AV-28WFR1EKS/A	AV28R10EKSL/A	
△	11	LC20091-030A-U	LC20091-050A-U	RATING LABEL
△	100	LC10662-017A-U	LC10662-016A-U	FRONT CABI ASS'Y
	101	LC20256-021A-U	LC20265-020A-U	DOOR(SERVICE)
	103	LC30578-007A-U	LC30578-010A-U	POWER KNOB(SERVICE)

● PACKING PARTS LIST

(Page 59)

△	Ref. No.	Parts No.		Parts Name
		AV-28WFR1EKS/A	AV28R10EKSL/A	
	2	AEM1052-037-E	AEM1052-082-E	EUROLABEL
		_____	LCT1036-001A-U	INST SHEET
		_____	LC31729-001A	PROTECT SHEET
		_____	AEM4091-003A-E	PROTECT SHEET

**JVC**

VICTOR COMPANY OF JAPAN, LIMITED

HOME AV NETWORK BUSINESS UNIT 12, 3-chome, Moriya-cho, Kanagawa-ku, Yokohama, Kanagawa-prefecture, 221-8528, Japan

