JVC SERVICE MANUAL

COLOUR TELEVISION

AV28R100EKSL/A

BASIC CHASSIS

JK

Supplement

The following item for the AV28R100EKSL/A model was changed partly from AV-28WFR1EKS/A model. Therefore, this service manual describes only the items which differ from those of the AV-28WFR1EKS/A service manual.

For details other than those described in this manual, please refer to the AV-28WFR1EKS/A service manual (No.51695F Oct. 2001).

■ OUTLINE

This model is colour variant model of AV-28WFR1EKS/A.

DIFFERENCE LIST

• EXPLODED VIEW PARTS LIST (Page 6)

Δ	Ref. No.	Parts No.		
		AV-28WFR1EKS/A	AV28R100EKSL/A	Parts Name
\triangle	2	LC10717-002C-U	LC10717-010C-U	AV BOARD
	9	LC10664-002B-U	LC10664-003B-U	REAR COVER
	11	LC20091-030A-U	LC20091-051A-U	RATING LABEL
	15	LC40354-001C-C	LC40354-003A-C	JVC MARK
	26	WJY0001-004A	WJY0001-011A	E-BRAIDED ASSY
	27	CHGB0017-0B	WJY0013-002A	BRAIDED SUB ASSY
⚠	100	LC10662-008C-U	LC10662-017A-U	FRONT CABI ASS'Y
	101	LC20265-011B-U	LC20265-021B-U	(SERVICE)DOOR
	103	LC300578-006A-U	LC300578-007A-U	(SERVICE)POWER KNOB
	105	LC31109-005A-U	LC31109-006A-U	CONTROL SHEET

• PACKING PARTS LIST (Page 19)

Δ	Ref. No.	Parts No.		
		AV-28WFR1EKS/A	AV28R100EKSL/A	Parts Name
	2	LCT0623-001A-U	LCT0623-001B-U	INST BOOK
	8	AEM1002-A68-E	AEM1002-B68-E	PACKING CASE
	9	AEM1052-037-E	AEM1052-083-E	EURO LABEL

