

JVC

SERVICE MANUAL

COLOUR TELEVISION

BASIC CHASSIS

JK

AV-29RSB(AU)

This service manual mainly consists of the following items:

- The items which differ from those for the AV-29RSB service manual.
- The initial value for each setting item.


For details other than those described in this manual, please refer to the following service manual.

Reference Service Manual: AV-29RSB Service Manual (No. 51726, May 2000)

Note: The page in parentheses shows the one for the AV-29RSB service manual (No. 51726, May 2000).



HOW TO IDENTIFY MODEL

While referring to the illustration given below, identify model name on the rating label affixed to the rear cover.



PARTS DIFFERENCE TABLE

The different parts between AV-29RSB and AV-29RSB(AU) are described below:

▲	REF. NO.	AV-29RSB	AV-29RSB(AU)	PART NAME	DESCRIPTION
		PART No.	PART No.		
■ EXPLODED VIEW PARTS LIST (Page 36)					
▲	13	QMP40D0-200J5 or QMP40D0-200J3 	QMP2980-185J5 	POWER CORD	
▲	16	LC20377-001B-H	LC20377-013B-H	RATING LABEL	
■ PACKING PARTS LIST (Page 49)					
	—	—	BT-56001-2	WARRANTY CARD	
	—	—	BT-56002-2	SERVICE CENTER LIST	

SPECIFICATIONS (Page 2)

Item		CONTENTS
Dimensions (W × H × D)		732mm × 588mm × 508mm
Mass		50kg
TV RF System		B, G, I, D, K, K1, M
Colour System		PAL, SECAM, NTSC3.58, NTSC4.43
Stereo System		A2 / NICAM (B,G)
Teletext System		FLOF (Fastext), WST (World standard system)
Receiving Frequency		VHF (L) 46.25MHz ~ 168.25MHz VHF (H) 175.25MHz ~ 463.25MHz UHF 471.25MHz ~ 863.25MHz CATV Mid (X-Z, S1-S10), Super (S11-S20), Hyper (S21-S41) bands receivable
Intermediate Frequency		VIF Carrier 38.0MHz SIF Carrier 33.5MHz(4.5MHz), 32.5MHz(5.5MHz), 32.0MHz(6.0MHz), 31.5MHz(6.5MHz)
Colour Sub Carrier Frequency		PAL 4.43MHz SECAM 4.40625MHz, 4.25MHz NTSC 3.58MHz / 4.43MHz
Power Input		AC110 ~ 240V, 50/60Hz
Power Consumption		233W (Max) / 163W (Avg)
Picture Tube		Visible size : 68cm measured diagonally
High Voltage		32.0kV ±1.5kV (at zero beam current)
Speaker & Audio Output		Closed dome speaker with TWIN PORT BASS system L / R : 15W+15W (10cm round x 2, +3.5cm round x 2) Center : 5W (4 x 12cm oval x 1)
Video Audio Input terminals		
Video1	S-Video	Y: 1Vp-p Positive (Negative sync provided, when terminated with 75Ω) C: 0.286Vp-p (Burst signal, when terminated with 75Ω)
	Video	1Vp-p 75Ω (RCA pin jack)
	Audio (L/R)	500mVrms (-4dBs), High impedance (RCA pin jack)
Video2	Video	1Vp-p 75Ω (RCA pin jack)
	Audio (L/R)	500mVrms (-4dBs), High impedance (RCA pin jack)
Video3	Video/Y	Composite video 1Vp-p 75Ω (RCA pin jack) Component video 1Vp-p 75Ω (RCA pin jack)
	Cb	Component video B-Y 0.7Vp-p 75Ω (RCA pin jack)
	Cr	Component video R-Y 0.7Vp-p 75Ω (RCA pin jack)
	Audio (L/R)	500mVrms (-4dBs), High impedance (RCA pin jack)
Video4 (Front terminal)	S-Video	Y: 1Vp-p Positive (Negative sync provided, when terminated with 75Ω) C: 0.286Vp-p (Burst signal, when terminated with 75Ω)
	Video	1Vp-p 75Ω (RCA pin jack)
	Audio (L/R)	500mVrms (-4dBs), High impedance (RCA pin jack)
Video Audio Output terminal		
	Video	1Vp-p 75Ω (RCA pin jack)
	Audio (L/R)	500mVrms (-4dBs), High impedance (RCA pin jack)
Aerial Input Terminal		75Ω Unbalanced, Coaxial
Headphone Jack		Stereo mini jack (3.5ø)
AV Compu Link terminal		AV Compu Link II, mini jack (3.5ø)
Remote Control Unit		RM-C110 (AA/R06 / UM-3 dry battery × 2)

Design & specifications are subject to change without notice.

SPECIFIC SERVICE INSTRUCTIONS

SETTING OF SYSTEM CONSTANT SET (Page 10)

Table 1

CONTENTS	VARIABLE RANGE	INITIAL SETTING VALUE
COLOUR	<input type="checkbox"/> MULTI <input type="checkbox"/> TRIPLE <input type="checkbox"/> PAL <input type="checkbox"/>	MULTI
MSP	<input type="checkbox"/> YES <input type="checkbox"/> NO <input type="checkbox"/>	YES
SUPER BASS	<input type="checkbox"/> YES <input type="checkbox"/> NO <input type="checkbox"/>	YES
CENTER SPEAKER	<input type="checkbox"/> YES <input type="checkbox"/> NO <input type="checkbox"/>	YES
TEXT	<input type="checkbox"/> YES <input type="checkbox"/> NO <input type="checkbox"/>	YES
BLUE BACK MUTE	<input type="checkbox"/> YES <input type="checkbox"/> NO <input type="checkbox"/>	NO
VOLUME LIMIT	<input type="checkbox"/> YES <input type="checkbox"/> NO <input type="checkbox"/>	YES
COLOUR AUTO	<input type="checkbox"/> YES <input type="checkbox"/> NO <input type="checkbox"/>	NO
TILT	<input type="checkbox"/> YES <input type="checkbox"/> NO <input type="checkbox"/>	YES
C-TRAP	<input type="checkbox"/> 1 <input type="checkbox"/> 0 <input type="checkbox"/>	1
E.M.C.	<input type="checkbox"/> YES <input type="checkbox"/> NO <input type="checkbox"/>	NO
N/S WHITE BACK	<input type="checkbox"/> YES <input type="checkbox"/> NO <input type="checkbox"/>	NO
7 LED SPEED	<input type="checkbox"/> 00 <input type="checkbox"/> 10 <input type="checkbox"/> 20 <input type="checkbox"/> ... <input type="checkbox"/> 1250 <input type="checkbox"/> 1270 <input type="checkbox"/> 1260 <input type="checkbox"/>	100

USER SETTING CONDITIONS (Page 10)

Table 2

PICTURE SETTING		FEATURES	
PICTURE MODE	BRIGHT	SLEEP TIMER	OFF
CONTRAST	CENTER	ON TIMER	PR1 0:00
BRIGHT	CENTER	BLUE BACK	ON
SHARP	CENTER	CHILD LOCK	OFF
COLOUR	CENTER	CHANNEL GUARD	--
TINT	CENTER	AUTO SHUT OFF	OFF
WHITE BALANCE	COOL	VIDEO-3 SETTING	COMPONENT
PICTURE FEATURES		INSTALL	
A.A.C	ON	LANGUAGE	ENGLISH
AUTO VNR	AUTO	AUTO PROGRAM	--
COLOUR SYSTEM	TV: According to preset CH VIDEO: AUTO PAL	EDIT / MANUAL	PRESET CH only Others: blank
ZOOM	REGULAR	DEMO	
ECO SENSOR	OFF	DEMO	OFF
PICTURE TILT	CENTER	OTHERS	
SOUND SETTING		VOLUME	Appropriate sound level
SETERO / I • II	<input type="radio"/>	CHANNEL PRESET	Refer to Operating Instructions.
BASS	CENTER	CHANNEL POSITION	1 POSITION
TREBLE	CENTER	SUB POWER	ON
BALANCE	CENTER	ON SCREEN DISPLAY	POSITION INDICATION
AI VOLUME	ON	TV/VIDEO	TV
BBE	ON	SOUND SYSTEM	B/G
SPATIALIZER	OFF		
SUPER BASS	ON		

SERVICE ADJUSTMENTS

■ Initial Setting Value

■ SETTING OF VSM PRESET (Page 19)

[INITIAL SETTING VALUES OF VSM PRESET (SUB MENU 5. VSM PRESET)]

ITEM \ PICTURE MODE	BRIGHT	STANDARD	SOFT
1. BRIGHT	+0	+0	+0
2. CONT	+17	+0	-4
3. COLOR	+0	+0	-1
4. SHARP	+0	+0	-3
5. TINT	+0	+0	+0

: Do not adjust.

■ SETTING OF WHITE BALANCE PRESET (Page 20)


[SETTING OF WHITE BALANCE PRESET (SUB MENU 6. WB PRESET)]

ITEM \ WHITE BALANCE	COOL	MID	WARM
1. R DRIVE	0	-3	+26
2. B DRIVE	0	-23	-27

: Do not adjust.

■ VIDEO / CHROMA CIRCUIT ADJUSTMENT (Page 20)

CONTENTS		PAL	SECAM	NTSC 3.58	NTSC 4.43
1. CUTOFF	R	-60			
	G	-60			
	B	-60			
2. DRIVE	R	+0			
	B	+0			
3. BRIGHT	TV	0	+3	+1	—
	VIDEO	-1	+2	+2	—
	COMPONENT	-2			
4. CONT	TV	-15	0	0	—
	VIDEO	0	0	0	—
	COMPONENT	+2			
5. COLOUR	TV / VIDEO	+10	+18	+0	0
	COMPONENT	+8		+17	
6. TINT	TV	+6	+6	+7	0
	VIDEO	+6	+6	+14	0
	COMPONENT	+6		0	
7. BLACK OFFSET	R-Y	—	0	—	—
	B-Y	—	0	—	—
8. SHARP	TV	-14	-13	-12	—
	VIDEO	-8	-7	-9	—
	COMPONENT	-10			

 : Do not adjust.

Adjustment of SUB COLOUR-II (Page 23)

Adjustment part	Description
5. COLOUR	
PAL COLOUR	Value (A) in the figure: Set to -3V (W & G) .
SECAM COLOUR	Value (A) in the figure: Set to -5V (W & G) .
NTSC 3.58 COLOUR	Value (A) in the figure: Set to +3V (W & G) .

Adjustment of SUB TINT-II (Page 24)

Adjustment part	Description
6. TINT	
NTSC 3.58 TINT	Value (B) in the figure: Set to +4V (W & Cy) .

■ DEFLECTION CIRCUIT ADJUSTMENT (Page 26)

[DEFLECTION ADJUSTMENTS INITIAL SETTING VALUE (SUB MENU 4. DEF)]

Setting item	Adjustment name	Initial setting value					
		REGULAR		ZOOM		16:9	
		50Hz	60Hz	50Hz	60Hz	50Hz	60Hz
1. V-SHIFT	Vertical shift	-5	-1	0	+1	0	0
2. V-SIZE	Vertical size	+7	-1	+36	+35	-39	-39
3. SUBTITLE	Subtitle	0	+1	-7	+7	0	0
4. H-CENT	Horizontal center	-10	+5	-1	-1	0	-1
5. H-SIZE	Horizontal size	-12	-1	-4	-4	0	-1
6. EW-PIN	Side pin correction	-3	+1	-4	-4	+2	0
7. TRAPEZ	Trapezoidal distortion correction	+4	-2	0	-1	0	+1
8. EW.COR.L	Corner pin correction Low side	-2	0	-1	-1	+1	+1
9. EW.COR.H	Corner pin correction High side	-2	0	0	0	+1	+1
10. V.S-COR	Vertical size correction	+13	0	0	0	0	0
11. V-LIN	Vertical Linearity	+2	-1	-1	-1	+1	0
12. H-BLK-R	Horizontal Blanking Right	0	0	0	0	+77	0
13. H-BLK-L	Horizontal Blanking Left	0	0	0	0	+2	0
14. V-EHT	V size correction level caused by EHT change	-4	0	0	0	0	0
15. H-EHT	H size correction level caused by EHT change	-3	0	0	0	0	0
16. EHT-GAIN	Size correction gain caused by EHT change	+3	0	0	0	0	0

: Do not adjust.

■ AUDIO CIRCUIT ADJUSTMENT (Page 30)

[AUDIO ADJUSTMENTS INITIAL SETTING VALUE (SUB MENU 3. AUDIO)]

Setting item	Variable range	Fixed value
1. ERROR LIMIT	000H ~ FF0H	100H
2. A2 ID THR	00H ~ FFH	14H
3. BASS	-17 ~ +17	+0
4. TREBLE	-17 ~ +17	+0

: Do not adjust.



JVC

VICTOR COMPANY OF JAPAN, LIMITED

TELEVISION RECEIVER DIVISION 1106 Heta, Iwai-city, Ibaraki-prefecture, 306-0698, Japan

