


# OPERATING INSTRUCTIONS


## CONNECTIONS




### FRONT & REAR PANEL DIAGRAMS




**AV-21F3PX  
AV-20N3PX  
AV-14F3PX  
Rear Panel**



**AV-21F3PX/AV-20N3PX/AV-14F3PX Front Panel**




**AV-21F1P  
AV-20N1P  
AV-14F1P  
Rear Panel**



**AV-21F1P/AV-20N1P/AV-14F1P Front Panel**

### INDOOR ANTENNA CONNECTION

For models AV-14F1P and AV-14F3PX you can attach the supplied indoor antenna for better reception.



#### To Install rod aerial:

Install into the top-rear aerial holder. Once installed, it cannot be removed. You can connect an indoor antenna included.

- 1) Connect the indoor antenna to the Matching adaptor and connect the Matching adaptor to the TV RF input.
- You will receive the best reception, or best picture, if you use connect your TV to an outdoor antenna of a cable output.