


OPERATING INSTRUCTIONS

CONNECTIONS





FRONT & REAR PANEL DIAGRAMS




AV-21F3PX/AV-20N3PX/AV-14F3PX Front Panel

**AV-21F3PX
AV-20N3PX
AV-14F3PX
Rear Panel**




AV-21F1P/AV-20N1P/AV-14F1P Front Panel

**AV-21F1P
AV-20N1P
AV-14F1P
Rear Panel**



INDOOR ANTENNA CONNECTION

For models AV-14F1P and AV-14F3PX you can attach the supplied indoor antenna for better reception.



To Install rod aerial:

Install into the top-rear aerial holder. Once installed, it cannot be removed. You can connect an indoor antenna included.

- 1) Connect the indoor antenna to the Matching adaptor and connect the Matching adaptor to the TV RF input.
- You will receive the best reception, or best picture, if you use connect your TV to an outdoor antenna of a cable output.