

SECTION 4 CHARTS AND DIAGRAMS

4.1 BOTTOM SCHEMATIC DIAGRAM

5

4


3

2


1

03

BOTTOM



- NOTE** 1. How to find the page showing the continuative schematic diagram.
 Example) To SYSCON : Refer to the GR-DVP3EG service manual (No. 86631).
 To SYSCON : Refer to this service manual.
2. The mark ★ means modified points.
3. When ordering parts, be sure to order according to the Part Number indicated in the Parts List.




y20134001a_rev0.1



4.2 BOTTOM CIRCUIT BOARD

FOIL SIDE(B)


0 3 BOTTOM PWB
YB10329-01-02



COMPONENT SIDE(A)




03 BOTTOM PWB
YB10329-01-02



4.3 EJECT CIRCUIT BOARD

FOIL SIDE(B)

06 EJECT PWB
YB10329-01-02



COMPONENT SIDE(A)

06 EJECT PWB
YB10329-01-02

