MODEL	NAME
213-CON	Analog Output Connector
237-BAN-3A	Triax to Banana Plug
237-BNC-TRX	3-Lug Female Triax to Male BNC Connector with guard disconnected
237-TRX-BAR	3-Lug Triax Female to Female (Barrel) Adapter
237-TRX-NG	Triax Male-Female Adapter with guard disconnected
237-TRX-T	3-Slot Male to Dual 3-Lug Female Triax Tee Adapter
237-TRX-TBC	3-Lug Female Triax Bulkhead Connector
2182-325A	Silver Solder for use with 2182-KIT
2182-KIT	Low-Thermal Connector with Strain Relief (LEMO)
2188	Low-Thermal Calibration Shorting Plug
2499-DIGIO	Digital I/O Expansion Module SMA Connector
2500INT-SMA 2500INT-FC/PC	FP/PC Connector Connector
2500INT-FC/APC	FP/APC Connector
4851	BNC Shorting Plug
5904	20nF/20mS Adapter (not calibrated to mainframe)
5951	Remote Input Coupler
7001-PNL	Metal Plate
7011-KIT-R	Female 96-Pin Connector Kit
7011-MTR	Bulkhead Mount 96-Pin Male Connector
7011-ST	Extra Screw Terminal Board
7012-ST	Extra Screw Terminal Board
7013-ST	Extra Screw Terminal Board
7014-ST	Extra Screw Terminal Board
7015-ST	Extra Screw Terminal Board
7018-ST	Extra Screw Terminal Board
7074-CIT	Contact Extraction Tool
7074-HCT	Hand Crimping Tool
7074-KIT	75-Pin Mass Terminated Plug w/Contacts
7074-MTR	75-Pin Mass Terminated Receptacle w/Contacts
7074-RTC	Relay Test Shorting Connector
7078-CIT	Contact Insertion/Extraction Tool
7078-HCT	Hand Crimping Tool for 7078-KIT, 7169-KIT
7078-KIT	Connector Kit
7078-MTR 7078-TRX-BNC	Mass Terminated Receptacle, Bulkhead Mount 3-Slot Male Triax to BNC Adapter
7078-TRX-GND	3-Slot Male Triax to BNC Adapter (guard removed)
7078-TRX-TBC	3-Lug Female Triax Bulkhead Connector w/Cap
7152-HCT	Hand Crimp Tool for 7152-KIT, 7152-MTR
7152-KIT	6-Position M-Series Plug w/Contacts
7152-MTR	6-Position M-Series Receptacle w/Sockets
7164-KIT	50-Pin Mass Terminated Connector
7164-MTR	50-Pin Mass Terminated Bulkhead Mount Receptacle
7169-KIT	20-Pin Mass Terminated Connector
7169-MTR	Mass Terminated Bulkhead Mount Receptacle
7703-306A	DB50 Male Connector Kit
7709-308A	DB25 Male Connector Kit
7712-SMA-N	Female SMA to Male N-Type Adapter
7755	50Ω Feed-Through Terminator
7788	50-Pin D Subconnector Kit
7789	50-Pin Male and 25-Pin Male D-Shell Connector Kit
7790	50-Pin Male, 50-Pin Female, and 25-Pin Male IDC D-Shell Connector Kit
8610	Low Thermal Shorting Plug
8680	RTD Probe Adapter
BG-18	Dual Banana to BNC Coaxial Adapter
CAP-18	Protective Shield/Cap
CAP-31	Protective Shield/Cap
CS-400	DB25 Male Solder Cup
CS-458	Interlock Connector Kit BNC Barrel
C8-565 C8-631	3-Lug Male Triax Cable Mount Connector
CS-680	3-Lug Female Bulkhead Connector
CS-846	Screw Terminal Test Lead Connector
CS-970	High Voltage Bulkhead Connector
55 710	man rounge buildlead conficetor

#### **USE WITH:**

	-
213 7072 7072 JW 2001 DMMc	÷
7072, 7072-HV, 2001, DMMs	
237, 6517A, 7078-TRX cables	
This interconnect	÷
Triax interconnect 236, 237, 238, 7072, 7072-HV	
	÷
7072, 7072-HV, 7078-TRX cables	
7072, 7072-HV, 7078-TRX cables	
2182	
2182, SC-93	
2182	
SourceMeter Instruments	
2500INT Integrating Sphere	
2500INT Integrating Sphere	
2500INT Integrating Sphere	
230-1, 7077	_
590	
Model 82-WIN	_
7001	
7011-C, 7012-C, 7013-C, 7015-C, 7018-C	
7011-KIT-R, 7011-C, 7012-C, 7013-C, 7015-C, 7018-C	
7011-5	
7012-8	
7013-S	
7014	
7015-S	
7018-5	
7074-KIT, 7074-MTR, 7152-KIT, 7152-MTR	
7074-KIT, 7074-MTR, 7152-KIT, 7152-MTR	
7074-D, 7074-MTR	
7074-D, 7074-KIT, 7074-MTC	
7074-D	
7078-KIT, 7078-MTR, 7152-KIT, 7152-MTR, 7169-KIT,	
7169-MTR	
7078-KIT, 7169-KIT	
7071, 7071-4, 7074-D, 7078-MTR	
7078-KIT, 7078-MTC	
486, 487, 4801, 6514, 6517A, 7072, 7072-HV	
236, 237, 238, 4801, 6517A, 7051, 7072, 7072-HV	÷
7078-TRX cables	_
7152-KIT, 7152-MTR 7152-7152-MTP	÷
7152, 7152-MTR 7152, 7152 KIT, 7152 MTC, 2, 7152 MTC, 10	
7152, 7152-KIT, 7152-MTC-2, 7152-MTC-10	÷
7164-D, 7164-M, 7164-MTR 7164 D, 7164 M, 7164 MTC 10	
7164-D, 7164-M, 7164-MTC-10 7169A	į,
7169A, 7169-MTC-3	
7701, 7703, 7705, 7709	-
7701, 7707, 7709	
7711, 7712	i.
RG 58 Cable, 776	
7703, 7705, 77XX, modules with D sub connectors	į,
7701, 7709	i
7701, 7709 7701, 7703, 7705, 7707, 7709	
7701, 7709 7701, 7703, 7705, 7707, 7709 2000, 2001, 2002, 2010	_
7701, 7709 7701, 7703, 7705, 7707, 7709 2000, 2001, 2002, 2010 2001, 2002, 2010	
7701, 7709 7701, 7703, 7705, 7707, 7709 2000, 2001, 2002, 2010 2001, 2002, 2010 230, 20XX Series, 24XX Series, 2700, 2750	
7701, 7709 7701, 7703, 7705, 7707, 7709 2000, 2001, 2002, 2010 2001, 2002, 2010 230, 20XX Series, 24XX Series, 2700, 2750 BNC, 2-lug triax connectors	
7701, 7709 7701, 7703, 7705, 7707, 7709 2000, 2001, 2002, 2010 2001, 2002, 2010 230, 20XX Series, 24XX Series, 2700, 2750 BNC, 2-lug triax connectors 3-lug triax connectors	
7701, 7709 7701, 7703, 7705, 7707, 7709 2000, 2001, 2002, 2010 2001, 2002, 2010 230, 20XX Series, 24XX Series, 2700, 2750 BNC, 2-lug triax connectors 3-lug triax connectors CA-126-1 cable, 213	
7701, 7709 7701, 7703, 7705, 7707, 7709 2000, 2001, 2002, 2010 2001, 2002, 2010 230, 20XX Series, 24XX Series, 2700, 2750 BNC, 2-lug triax connectors 3-lug triax connectors CA-126-1 cable, 213 6517-ILC-3	
7701, 7709 7701, 7703, 7705, 7707, 7709 2000, 2001, 2002, 2010 2001, 2002, 2010 230, 20XX Series, 24XX Series, 2700, 2750 BNC, 2-lug triax connectors 3-lug triax connectors CA-126-1 cable, 213 6517-1LC-3 BNC interconnect	
7701, 7709 7701, 7703, 7705, 7707, 7709 2000, 2001, 2002, 2010 2001, 2002, 2010 230, 20XX Series, 24XX Series, 2700, 2750 BNC, 2-lug triax connectors 3-lug triax connectors CA-126-1 cable, 213 6517-ILC-3 BNC interconnect SC-22 Cable	
7701, 7709 7701, 7703, 7705, 7707, 7709 2000, 2001, 2002, 2010 2001, 2002, 2010 230, 20XX Series, 24XX Series, 2700, 2750 BNC, 2-lug triax connectors 3-lug triax connectors CA-126-1 cable, 213 6517-II.C-3 BNC interconnect SC-22 Cable Fixtures, 6487, 6517A, etc.	
7701, 7709 7701, 7703, 7705, 7707, 7709 2000, 2001, 2002, 2010 2001, 2002, 2010 230, 20XX Series, 24XX Series, 2700, 2750 BNC, 2-lug triax connectors 3-lug triax connectors CA-126-1 cable, 213 6517-ILC-3 BNC interconnect SC-22 Cable	



**Model 213-CON Analog Output Connector:** Quick disconnect analog output connector for Model 213 Quad Voltage Source. Screw terminals provided for connection of test leads.

For use with: 213



**Model 237-BAN-3A Triax to Banana Plug:** Triax cable center conductor terminated in a safety banana plug (guard and shield open). For connecting DMMs and other banana jack instruments to a

banana plug (guard and shield open). For connecting DMMs and other banana jack instruments to a matrix or fixture.

### For use with: 7072, 7072-HV, DMMs



**Model 237-BNC-TRX:** Male BNC to 3-lug female triax adapter (guard disconnected). Terminates triax cable in BNC plug. High voltage rating for use with 237 and 7072-HV.

For use with: 237, 6517A, 7078-TRX Cables



**Model 237-TRX-BAR:** 3-lug triax barrel for use with triax interconnect.

For use with: Triax interconnect




www.keithley.com

1.888.KEITHLEY (U.S. only)



**Model 237-TRX-NG:** 3-slot triax to 3-lug female triax (guard removed) for non-guarded measurements. High voltage rating for use with 237, 7072-HV, etc.





**Model 237-TRX-T:** 3-slot male to dual 3-lug female triax tee adapter for use with 7078-TRX cables and 7072/7072-HV Semiconductor Matrix Cards. High voltage rating for use with Model 237 SMU.

For use with: 7072, 7072-HV, 7078-TRX cables



**Model 237-TRX-TBC:** 3-lug female triax bulkhead connector with cap for assembly of custom panels and interface connections. High voltage rating for use with 237, 7072-HV, etc. Uses miniature coax cable, not triax cable, at soldered end. Bulkhead is outer shield.

### For use with: 7072, 7072-HV, 7078-TRX cables

**Model 2182-325A:** Silver solder for making connections in experiments with the Model 2182. 20 ft roll.

### For use with: 2182




Model 2182-KIT Low-Thermal Connector with Strain Relief: Connector kit for building a custom input cable for the Model 2182 Nanovoltmeter. Includes a low-thermal (LEMO) connector and a strain relief.

For use with: 2182, SC-93



Model 2188 Low-Thermal Calibration Shorting Plug: A low-resistance, low-thermal shorting plug required to calibrate the Model 2182 Nanovoltmeter. Made of a LEMO connector with its pin connectors shorted together using copper wire and Sn/Ag4 silver solder.

For use with: 2182



**Model 2499-DIGIO:** Digital I/O expansion module that plugs onto the DB-9 connector of a SourceMeter. Expands the three digital I/O lines of the SourceMeter to 16 lines. The SOT, EOT/BUSY, 5V, GND, and Interlock signals are passed through.

For use with: SourceMeter Instruments



**Model 2500INT-SMA:** SMA connector for 2500-INT Integrating Sphere.

For use with: 2500-INT



Model 2500INT-FC/PC: FC/PC connector for 2500-INT Integrating Sphere. For use with: 2500-INT



**Model 2500INT-FC/APC:** FC/APC connector for 2500-INT Integrating Sphere.

For use with: 2500-INT



Model 4851: BNC shorting plug. For use with: 230-1, 7077

**Connectors**, adapters, and tools





Model 5904: 20nF/20mS adapter. Extends range of Model 590/100k.

For use with: 590



**Model 5951 Remote Input Coupler:** Includes the remote input coupler, five 1.2m low noise BNC cables (Model 4801), two 1m IEEE-488 cables (Model 7007-1), one 2m shielded IEEE-488 cable (Model 7007-2), and three 0.6m RG-58C BNC-to-BNC cables (Model 7051-2).

### For use with: Model 82-WI




**Model 7001-PNL:** Metal plate used to cover an empty card slot on the rear panel of a Model 7001.


For use with: 7001



**Model 7011-KIT-R:** 96-pin female DIN connector with solder eyelets and strain relief. This kit can be used for assembly of custom cables to connect with the connectors on the 7011-C, 7012-C, 7013-C, 7015-C, and 7018-C switch cards. Also connects with the 7011-MTR bulkhead mount male connector. **For use with: 7011-C, 7012-C, 7013-C, 7015-C, 7018-C** 




Model 7011-MTR: 96-pin male DIN connector with solder eyelets for bulkhead mount. Connects with the 7011-KIT-R and the 7011-MTC-2. For use with: 7011-KIT-R, 7011-C, 7012-C, 7013-C, 7015-C, 7018-C



**Model 7011-ST:** Extra quick disconnect screw terminal board. One 7011-ST is included with each 7011-S. **For use with: 7011-S** 


**Model 7012-ST:** Extra quick disconnect screw terminal board. One 7012-ST is included with each 7012-S.

For use with: 7012-S




**Model 7013-ST:** Extra quick disconnect screw terminal board. One 7013-ST is included with each 7013-S.

For use with: 7013-S




**Model 7014-ST:** Extra quick disconnect isothermal screw terminal board with cold junction sensor. One 7014-ST is included with each 7014.

For use with: 7014



**Model 7015-ST:** Extra quick disconnect screw terminal board. One 7015-ST is included with each 7015-S.

For use with: 7015-S



**Model 7018-ST:** Extra quick disconnect screw terminal board. One 7018-ST is included with each 7018-S.

For use with: 7018-S



1.888.KEITHLEY (U.S. only)




**Model 7074-CIT:** Contact extraction tool for removal of contacts from 7074-MTC cables and connectors.

For use with: 7074-KIT, 7074-MTR, 7152-KIT, 7152-MTR




**Model 7074-HCT:** Contact crimping pliers for assembly of cables and connectors using 7074-MTR or 7074-KIT

For use with: 7074-KIT, 7074-MTR, 7152-KIT, 7152-MTR



**Model 7074-KIT:** 75-pin plug assembly with strain relief and 80 contacts for assembly of custom cable and harnesses compatible with 7074-D multiplexer card and 7074-MTR mass terminated receptacle.

### For use with: 7074-D, 7074-MTR



**Model 7074-MTR:** 75-pin bulkhead mount receptacle with 80 contacts for custom interface and patch panels compatible with 7074-MTC and 7074-KIT.

For use with: 7074-D, 7074-KIT, 7074-MTC



**Model 7074-RTC:** Relay test connector. The 7074-RTC adapts column inputs with jumper interconnects necessary when running relay test software supplied with the 707A mainframe.

### For use with: 7074-D




**Model 7078-CIT:** Contact insertion and extraction tool for assembly and maintenance of 7078-MTC cables and connectors.

For use with: 7078-KIT, 7078-MTR, 7152-KIT, 7152-MTR, 7169-KIT, 7169-MTR




**Model 7078-HCT:** Contact crimping pliers for assembly of cables and connectors using 7078-MTR or 7078-KIT.

For use with: 7078-KIT, 7169-KIT



**Model 7078-KIT:** 38-pin plug assembly with strain relief and 40 contacts for assembly of custom cable and harnesses compatible with Model 7071 8×12 Matrix Card, Model 7071-4 Dual 4×12 Matrix Card, Model 7074-D Eight 1×12 Multiplexer Card, and 7078-MTR Mass Terminated Receptacle. Requires 7078-HCT, recommend 7078-CIT.

For use with: 7071, 7071-4, 7074-D, 7078-MTR



**Model 7078-MTR:** 38-pin bulkhead mount receptacle with 40 contacts for custom interface and patch panels compatible with 7078-MTC and 7078-KIT. Requires 7078-HCT; recommend 7078-CIT.

For use with: 7078-KIT, 7078-MTC

**Connectors**, adapters, and tools

## 1.888.KEITHLEY (U.S. only)



**Model 7078-TRX-BNC:** 3-slot male triax to BNC adapter for use with 7072 Semiconductor Matrix Card and 4801 cables.

For use with: 486, 487, 4801, 6514, 6517A, 7072, 7072-HV



**Model 7078-TRX-GND:** 3-slot male triax to BNC adapter (guard removed) for adapting non-guard-ed measurements to 236, 237, or 238 SMUs, 7072 or 7072-HV Semiconductor Matrix Cards, or 8006 or 8008 Test Fixtures.

## For use with: 236, 237, 238, 4801, 6517A, 7051, 7072, 7072-HV



**Model 7078-TRX-TBC:** 3-lug female triax bulkhead connector with cap for assembly of custom panels and interface connections.

For use with: 7078-TRX Cables



**Model 7152-HCT:** Contact crimping pliers for assembly of cables and connectors using 7152-MTR or 7152-KIT.

For use with: 7152-KIT, 7152-MTR



**Model 7152-KIT:** 6-pin plug assembly with strain relief and contacts for assembly of custom cable and harnesses compatible with Model 7152 4×5 Low Current Matrix Card and 7152-MTR Mass Terminated Receptacle. Requires 7152-HCT; recommend 7074-CIT and 7074-HCT.

### For use with: 7152, 7152-MTR



**Model 7152-MTR:** 6-pin bulkhead mount receptacle with contacts for custom interface and patch panels compatible with 7152-MTC and 7152-KIT. Requires 7152 HCT; recommend 7074-CIT and 7074-HCT.

For use with: 7152, 7152-KIT, 7152-MTC-2, 7152-MTC-10




**Model 7164-KIT:** 50-pin D-Sub connector for assembly of custom cables and harnesses compatible with Models 7164-D and 7164-M 20-Channel Scanner Cards.

### For use with: 7164-D, 7164-M, 7164-MTR



**Model 7164-MTR:** 50-pin mass terminated receptacle for custom interface and patch panels compatible with 7164-MTC.

For use with: 7164-D, 7164-M, 7164-MTC-10



**Model 7169-KIT:** 20-pin connector body and contacts for assembly of custom cables and harnesses compatible with Model 7169A 20-Channel Form C Switch Card. Requires 7078-HCT; recommend 7078-CIT. Note: Three 7169-KITs are required for complete connection to the 7169A card.

For use with: 7169A







**Model 7169-MTR:** 20-pin bulkhead connector body and contacts for custom interface and patch panels compatible with Model 7169 20-Channel Form C Switch Card. Requires 7078-HCT; recommend 7078-CIT.

For use with: 7169A, 7169-MTC-3



**Model 7703-306A:** DB50 male connector kit (solder cup) with shell.

For use with: 7701, 7703, 7705, 7709



Model 7709-308A: DB25 male connector kit (solder cup) with shell. For use with: 7701, 7707, 7709



**Model 7712-SMA-N:** Female SMA to Male N-Type Adapter.

For use with: 7711, 7712



**Model 7755 50Ω Feed-Through Terminator:** BNC-to-BNC adapter for terminating RG58 cable in its characteristic impedance. VSWR <1.1, DC–250MHz.

For use with: RG58 Cable, 776



**Model 7788:** 50-pin D subminiature connector kit. To mate with 50-pin connector on Model 7703 and 7705.

For use with: 7703, 7705, 77XX modules with D sub connectors



**Model 7789:** 50 pin/25 pin (both male) D-Shell Kit (one of each) for 7701 or 7709 Integra modules (mating connectors are supplied with these modules when purchased).

For use with: 7701, 7709



**Model 7790:** 50 pin male, 50 pin female, 25 pin male IDC D-Shell Connector Kit (one each). For use with: 7701, 7703, 7705, 7707 or 7709 Integra modules



**Model 8610 Low Thermal Shorting Plug:** For calibration lab use, this plug provides a very low thermal offset short at front or rear inputs.

For use with: 2000, 2001, 2002, 2010

**Connectors**, adapters, and tools







**Model 8680 RTD Probe Adapter:** Provides a means of connecting RTD probes terminated in either a 4-wire instrumentation connector or bare wires to safety input jacks on a 0.5 inch spacing. Use with Model 8681, 8693, 8695, or 8696.

For use with: 2001, 2002, 2010



**BG-18:** Dual banana to BNC coaxial adapter for adapting connection on instrument with dual banana jack.

For use with: 230, 20XX Series, 24XX Series, 2700, 2750



**CAP-18:** Protective shield/cap for BNC connectors.

For use with: BNC Connectors



**CAP-31:** Protective shield/cap for 3-lug triax connectors.

For use with: 3-Lug Triax Connectors



CS-400: DB25 male, solder cup. For use with: C126-1 Cable, 213



**CS-458:** Interlock connector kit to mate with 6517-ILC-3.

For use with: 6517-ILC-3



CS-565: BNC barrel. For use with: BNC interconnect



**CS-630:** 3-lug female triax bulkhead connector for soldered connections. Mates with CS-631.

For use with: Fixtures, 6487, 6517A, etc.



**CS-631:** 3-slot male triax cable mount connector for use with SC-22 cable. Mates to Models 236, 237, 238, 486, 487, 7072, and 8006.

For use with: SC-22 Cable



**CS-846:** Eight position connector with screw terminals for connection to test leads.

For use with: 230X, 2510, 2510-AT



CS-970: High voltage bulkhead connector. For use with: 248, 248-SHV Cable

**Connectors**, adapters, and tools

