

Electronics Division Box 1246 2876 Culver Ave. Dayton, Ohio 45401 Telephone (513) 296-0330

Operating Instructions

For Model

124 A & B

GRAN TRAK 20

Atari/Kee

<u> </u>	51.2			START 2			SR 2				5	5 V	
LLP	SL1	× SL5	St3	L RP	×	START	RLP	SRI	X SR5	SR 3	ARP	ON	OFF
×	x	x SL4	×	x	K	×	x	x	x S _. R4	×	×		
	S L 6	x	SL7			COIN		SR6	×	8R 7		PO1	WER
	×		×			k		×		x	×	ÓN	OFF

- 1. Insert program cards A & B in the slots appropriately marked.
- 2. CAUTION: a) For Kee Games Twin Racer only, remove the two diodes on the digital board power supply whose anodes go to GND. Kee DOES NOT use the center tap of the AC secondary.
 - b) Connec: a jumper from ±5V (+5V available at end of power resistor nearest edge of board on digital computer board), to Pin 20 of remote connector to power turn circuit of 124A program card.
- 3. Insert analog board into test fixture.
- 4. Insert digital board into remote connector making sure that Pin 1 is at red dot end of 22 Pin remote connector.
- 5. Connect 2 speakers to 2 red wires on 124A and GND (black wire).
- 6. Push coin switch once for one car, twice for two cars.
- 7. Push start 1 switch for 1 car, or start 2 for 2 cars.
- 8. Switch on 124A card selects car 1 or 2 to be driven. (only one car can be driven at any one time).
- 9. Car 1 (white)

SR6 - gas

SR3 - third gear

SR5 - steering right

SRI - first gear

SR4 - reverse

SL5 - steering left

SR2 - second gear

SR7 - brake

10. Car 2 (gray)

SI6 - gas

SL3 - third gear

SR5 - steering right

SL1 - first gear SL2 - second gear SL4 - reverse SL7 - brake SL5 - steering left