

Electronics Division
Box 1246 • 2271 Arbor Blvd.
Dayton, Ohio 45439
Telephone (513) 299-0990

## **Operating Instructions**

For Model

274D

Bally----MPU

needs 274 A & E

SL2					START 2			SR2			5V		
LLP	SL1	x SL5	SL3	LRP	x	X .	RLP	SR1	x SR5	SR3	RRP	ON OFF	
×	x	x SL4	×	×	x	×	x	×	X SR4	x	x		
	SL6	×	SL7			COIN		SR6	×	SR7		POWER	
	x		×			×		×		×	x	ON OFF	

NOTE: This card can be used in console alone or with 274E to control MPU.

## A. FOR TF-650

- 1. Insert 274A into Port A.
- 2. Connect 274D to J-1 & J-4 of MPU Board.
- 3. Connect 274A remote connector to 274D P-4.
- 4. The 4 switches---CDT, 1P, 2P, 3P & 4P show credit and the 4 player scores. All switches should be toward P4 end of board to start.
- 5. The 3 switches---U1, U2, U3 & U4 select the lamp outputs of MPU board and display them on LEDS 0-15 (above P-1) (See Lamp Driver schematic of game.)
- 6. Use jumper from pin 1 of J-3 to ground to execute MPU test per Bally Instructions "Self Diagnostic Test"
- 7. LEDS 0-15 (above P4 display Solenoid outputs.)

## B. IN CONSOLE

- 1. Remove connectors to J-1 & J-4 on MPU Board.
- 2. Connect 274D to MPU Board.
- .3. Connect cable that went to J-4 on MPU Board to P-4 on 274D card.
- 4. Exercise MPU Board per "Self Diagnostic Test" Procedures in Bally Instruction Book.
- 5. 274E card may be plugged into either J2 or J3 to exercise the MPU cabinet or Playfield switches. (see these respective Bally drawings and 274A & E instruction sheets)