



Duplex Unit
DU-400

PARTS LIST

DU40070770
842DU400120


Contents

1. DU-400	Page 4
List 1 - DU-400	Page 5

Legend

+	These parts are component parts or sub-assemblies of the assembly appearing immediately above them.
++	These parts are component parts or sub-assembly marked with a + appearing immediately above them.
ISP	Initial service parts which primarily appear on the ISP list supplied by the manufacturer.
GSP	General service parts which appear on the GSP list supplied by the manufacturer.

1. DU-400



List 1 - DU-400

Ref. No.	Part Code	Description	Applicable Models	SP	Q'ty
01-001	3HM02070	BASE MAIN		-	1
01-002	3HM02210	FLAG EXIT		X	1
01-003	3HM02470	SENSOR PAPER		X	3
01-004	3HM02370	SPRING EXIT		X	1
01-005	3HM02120	COVER CABLE 1		-	1
01-006	3HM02130	COVER CABLE 2		-	1
01-008	3HM02200	FLAG SENSOR		X	1
01-010	3HM02500	BEARING TURN		X	2
01-011	5SNSP0013717	BUSH A		X	3
01-013	3HM02160	GUIDE SLIDE		-	1
01-014	3HM02300	PLATE ROOF		-	1
01-015	3HM02050	SHAFT SLIDE		-	1
01-016	3HM02090	BASE UPPER		-	1
01-017	5SNSP0013726	ROLLER DIAGONAL		X	2
01-018	3HM02340	SPRING ROLLER		X	6
01-019	3HM02410	CONN. CORD I/O		X	1
01-020	3HM02150	HOLDER DR		-	1
01-022	3HM02110	COVER PWB		-	1
01-023	3HM02510	PWB CONTROL		X	1
01-024	3HM02380	BRUSH DISCHARGER		X	1
01-025	3HM02080	BASE BOTTOM		X	1
01-026	3HM02290	BKT MOTOR		-	1
01-027	3HM02220	GEAR SLIDE		X	1
01-028	3HM02260	PULLEY FEED 1		X	2
01-029	3HM02430	BELT S2M144		X	2
01-030	5SNSP0013718	BUSH E		X	3
01-031	3HM02030	ROLLER FEED 3		X	1
01-032	3HM02270	PULLEY FEED 2		X	1
01-033	3HM02450	BELT S2M308		X	1
01-034	3HM02020	ROLLER FEED 2		X	1
01-035	5SNSP0013722	GEAR CLUTCH		X	1
01-036	3HM02140	SPACER FEED		-	1
01-037	3HM02440	BELT S2M192		X	1
01-038	3HM02010	ROLLER FEED 1		X	1
01-039	3HM02420	BELT S2M134		X	1
01-040	3HM02250	PULLEY IDOL		X	1
01-042	3HM02240	GEAR TURN 2		X	1
01-043	3HM02040	ROLLER TURN		X	1
01-045	3HM02230	GEAR TURN 1		X	1

Ref. No.	Part Code	Description	Applicable Models	SP	Q'ty
01-046	3HM02320	PLATE SW		X	1
01-047	3HM02520	SW INTERLOCK		X	1
01-048	3HM02310	PLATE EARTH 1		X	1
01-049	5SNSP0013723	GEAR HELICAL 2		X	1
01-050	5SNSP0013724	GEAR IDLE A4		X	1
01-051	3HM02280	DUCT HARNESS		-	1
01-052	3HM02490	MOTOR 2 740		X	1
01-053	3HM02480	MOTOR 1 700		X	1
01-054	3HM02330	SPRING SOLENOID		-	1
01-055	3HM02170	ARM FLAPPER		-	1
01-056	3HM02180	LINK SOLENOID		-	1
01-058	3HM02460	SOLENOID IN		X	1
01-059	3HM02190	FLAG IN		X	1
01-060	3HM02350	SPRING IN		X	1
01-061	3HM02060	COVER REAR		X	1
01-062	5SNSP0013712	ROLLER PINCH		X	4
01-064	5SNSP0013964	BAND COVER		-	1
01-065	3HM02100	COVER OPEN		X	1
01-066	3HM02530	ROLLER DIAGONAL A		X	1
01-067	3HM02540	SPRING ROLLER A		X	1
P001	3HM77010	PACKING ASSY		X	1