



PRINTER OPTIONS

EF-1

PARTS CATALOGUE

EF-1 Parts Catalogue

Table of Contents

Exploded View (Fig.1).....3


Introduction

The figures which follow depict the major assemblies of the printer or option, broken down into components. Following each figure are the list giving the following information:

- 'Ref No.'Reference number which corresponds to the parts in the figure
- 'Part code'.....Part code which identifies the part
- 'Part description'A brief description of the part
- 'Quantity'.....Quantity of the part used in the printer or option

Only the parts highlighted in BOLD should be ordered. All other parts are for reference only and are not stocked.

Fig.1 - Exploded View



Ref No.	Part Code	Description	Quantity
02-000	EF-1	ENVELOPE FEEDER	1
02-001	5SNSP0008507	FRAME SUB ASSY	1
02-001A	5SNSP0008508	FRAME	1
02-001B	5SNSP0008509	PLATE CONTROL	1
02-002	5SNSP0008510	HOOK	2
02-003	5SNSP0008511	BUTTON RELEASE	2
02-004	5SNSP0008512	GEAR Z12	1
02-005	5SNSP0008513	GEAR Z23-Z63	2
02-006	5SNSP0008514	GEAR Z27-Z58	1
02-007	5SNSP0008515	GEAR Z26A	1
02-008	5SNSP0008516	GEAR Z26B	1
02-009	5SNSP0008517	GEAR Z18	1
02-010	5SNSP0008518	GEAR Z19	1
02-011	5SNSP0008520	BUSHING A	2
02-012	5SNSP0008521	BUSHING B	1
02-013	5SNSP0008523	SPRING B	2
02-014	5SNSP0008524	SPRING CLUTCH	1
02-015	5SNSP0008525	ROLLER ASSY A	1
02-016	5SNSP0008528	ROLLER ASSY B	1
02-017	5SNSP0008554	PAD MOTOR	1
02-018	5SNSP0008555	DC MOTOR ASSY	1
02-019	5SNSP0008556	SENSOR ASSY A	1
02-020	5SNSPO008558	PWB MAIN	1
02-021	5SNSP0008536	LEVER SENSOR	1
02-022	5SNSP0008827	SPRING EARTH	1
03-001	5SNSP0008532	PLATE CENTER	1
03-002	5SNSP0008533	PLATE GUIDE R	1
03-003	5SNSP0008534	PLATE GUIDE L	1
03-004	5SNSP0008535	RACK	2
03-005	5SNSP0008519	GEAR Z16	1
04-001	5SNSP0008537	ARM ASSY	1
04-001A	5SNSP0008538	ARM	1
04-001B	5SNSP0008539	SHAFT WEIGHT	1
04-002	5SNS130008543	SEPARATER ASSY	1
04-002A	5SNSP0008544	HOLDER SEPARATER	1
04-002B	5SNSP0008545	PAD SEPARATER	1
04-003	5SNSP0008542	HOLDER WEIGHT	1
04-004	5SNSP0008546	SHAFT LATCH	1
04-005	5SNSP0008560	SPRING PAD	1
04-006	5SNSP0008557	SENSOR ASSY B	1
04-007	5SNSP0008522	SPRING A	1
04-008	5SNSP0008541	CHANNEL SENSOR	1
05-001	5SNSP0008547	COVER TOP ASSY	1
05-001A	5SNSP0008548	COVER TOP	1
05-001B	5SNSP0008549	HOLDER CONNECTOR	1

Ref No.	Part Code	Description	Quantity
05-001C	5SNSP0008559	PWB CONNECTOR ASSY	1
05-002	5SNSP0008550	COVER UNDER	1
05-003	5SNSP0008551	TRAY STACKER	1
05-004	5SNSP0008552	COVER RIGHT	1
05-005	5SNSP0008553	COVER LEFT	1
05-006	5MVVSEF1**1	LABEL SERIAL	1