



PRINTER OPTIONS

DF-30

PARTS CATALOGUE

DF-30 Parts Catalogue

Table of Contents

DF-30 Overall (Fig.0).....	3
Attachment Parts (Fig.1).....	5
External Covers/Panels #1 (Fig.2a).....	7
External Covers/Panels #2 (Fig.2b).....	9
Stapler Tray Main Body #1 (Fig.3a).....	11
Stapler Tray Main Body #2 (Fig.3b).....	13
Stapler Tray Main Body #3 (Fig.4).....	16
Tray Drive Assembly (Fig.5)	18
Tray Assembly (Fig.6).....	20
Swing Guide Assembly (Fig.7).....	22
Stapler Tray Assembly #1 (Fig.8a).....	24
Stapler Tray Assembly #2 (Fig.8b).....	27
Upper Feed Assembly (Fig.9).....	29
Center Guide Assembly (Fig.10).....	31
Stapler Assembly (Fig.11).....	33
PCB Assembly Location (Fig.12).....	35

Introduction

The figures which follow depict the major assemblies of the printer or option, broken down into components. Following each figure are the list giving the following information:

'Ref No.' Reference number which corresponds to the parts in the figure
'Part code'..... Part code which identifies the part
'Part description' A brief description of the part
'Quantity'..... Quantity of the part used in the printer or option

Only the parts highlighted in **BOLD** should be ordered. All other parts are for reference only and are not stocked.




Fig.0 - DF-30 Overall

Ref No.	Part Code	Description	Quantity
05-001	5SNSADF30E05	TRAY DRIVE ASSY	
06-001	5SNSADF30E06	TRAY ASS'Y	
07-001	5SNSADF30E07	SWING GUIDE ASS'Y	
08-001	5SNSADF30E08	STAPLER TRAY ASS'Y	
09-001	5SNSADF30E09	UPPER FEEDER ASS'Y	
10-001	5SNSADF30E10	CENTER GUIDE ASS'Y	
11-001	5SNSADF30E11	STAPLER ASS'Y	




Fig.1 - Attachment Parts

Ref No.	Part Code	Description	Quantity
01-001	5SNSADF30E01	ATTACHMENT PARTS	
01-002	5SNSP0011793	GUIDE	
01-003	5SNSP0011796	RAIL GUIDE	
01-004	5SNSP0011797	SCREW TRAY M4	
01-005	5SNSP0011798	CABLE INTERFACE	
01-006	5SNSP0011801	GROUND ADAPTOR UNIT	
01-007	5SNSP0011802	BRACKET	
01-008	5SNSP0012305	CABLE AC Japan	
01-008	5SNSP0012309	CABLE AC France	
01-008	5SNSP0012306	CABLE AC USA	
01-008	5SNSP0012307	CABLE AC UK	
01-008	5SNSP0012308	CABLE AC AUSTRALIA	
01-008	5SNSP0012309	CABLE AC GERMANY	
13-001	5SNSADF30E13	TRAY ASSY	
13-002	5SNSP0011799	TRAY	
13-003	5SNSP0011800	SHEET REFLECTING	
51-001	5SNSADF30E51	UNIT RAIL	
51-002	5SNSP0011794	RAIL	
51-003	5SNSP0011795	SCREW STEPPED M4	




Fig.2a - External Covers/Panels #1

Ref No.	Part Code	Description	Quantity
02-001	5SNSADF30E02	EXTERNAL COVERS PANELS	
02-002	5SNSP0011803	GUIDE HURDLE TOP	
02-003	5SNSP0011804	CAP COVER FRONT	
02-004	5SNSP0011805	CAP COVER REAR	
19-001	5SNSADF30E19	PLATE SHUTTER	
19-002	5SNSP0011820	DAMPER	
19-003	5SNSP0011821	DAMPER SHUTTER	
19-004	5SNSP0011846	GASKET	
19-005	5SNSP0011849	PLATE SHUTTER	
19-006	5SNSP0012292	CLAMP CABLE	
20-001	5SNSADF30E20	SLIDE GUIDE ASS'Y	
20-002	5SNSP0011826	GUIDE SLIDE	
20-003	5SNSP0011827	COVER SLIDE FRONT	
20-004	5SNSP0011833	COVER SLIDE REAR	
23-001	5SNSADF30E23	GUIDE HURDLE UNIT	
23-002	5SNSP0011818	SHUTTER HURDLE	
23-003	5SNSP0011819	SPRING LEAF	
23-004	5SNSP0011822	GUIDE HURDLE LOWER	
23-005	5SNSP0011823	PLATE HURDLE	
23-006	5SNSP0012286	CABLE	
23-007	5SNSP0011824	PHOTO-INTERRUPTER	
23-008	5SNSP0011825	PLATE HURDLE 2	
23-009	5SNSP0011841	SPRING LEAF	
23-010	5SNSP0011842	PLATE	




Fig.2b - External Covers/Panels #2

Ref No.	Part Code	Description	Quantity
02-005	5SNSP0011806	COVER CASTER	
02-006	5SNSP0011807	COVER FRONT	
02-007	5SNSP0011808	COVER LOWER FRONT	
02-008	5SNSP0011809	COVER LOWER REAR	
02-009	5SNSP0011810	COVER REAR	
02-010	5SNSP0012287	SCR RS M4*8	
02-011	5MVVSDF30*01	LABEL	
14-001	5SNSADF30E14	LATCH FRONT	
14-002	5SNSP0011851	LATCH FRONT	
14-003	5SNSP0011843	MAGNET	
15-001	5SNSADF30E15	LATCH REAR	
15-002	5SNSP0011852	LATCH REAR	
16-001	5SNSADF30E16	COVER DOOR	
16-002	5SNSP0011811	LABEL OPERATION	
16-003	5SNSP0011850	COVER FRONT	
17-001	5SMSADF30E17	TOP DOOR ASS'Y	
17-002	5SNSP0012285	WASHER	
17-003	5SNSP0011812	SPRING COMPRESSION	
17-004	5SNSP0011813	SPRING TORSION	
17-005	5SNSP0011814	LATCH	
17-006	5SNSP0011815	PIECE PRESSURE	
17-007	5SNSP0011847	TOP DOOR	
18-001	5SNSADF30E18	TOP COVER ASS'Y	
18-002	5SNSP0011816	SPRING TORSION	
18-003	5SNSP0011817	ARM SENSOR	
18-004	5SNSP0011848	TOP COVER	
18-005	5SNSP0012289	FILM	
21-001	5SNSADF30E21	RIGHT GUIDE ASS'Y	
21-002	5SNSP0011834	ROLLER A	
21-003	5SNSP0011835	HINGE	
21-004	5SNSP0011836	LATCH	
21-005	5SNSP0011837	RIGHT GUIDE	
21-006	5SNSP0011838	SPRING TORSION	
21-007	5SNSP0011839	SPRING TORSION	
21-008	5SNSP0011840	SPRING TENSION	
22-001	5SNSADF30E22	LATCH REAR UNIT	
22-002	5SNSP0011844	FLAG SENSORE	
22-003	5SNSP0011845	SPRING TENSION	

Ref No.	Part Code	Description	Quantity
03-001	5SNSADF30E03	STAPLER TRAY MAIN BODY 1	
03-002	5SNSP0011854	SPRING LEAF	
03-003	5SNSP0011855	MOUNT SLIDE	
03-004	5SNSP0011856	HOLDER SLIDER	
03-005	5SNSP0011857	HOLDER	
03-006	5SNSP0011858	MOUNT SENSOR	
03-008	5SNSP0011860	SPRING LEAF	
03-009	5SNSP0011861	SPRING COMPRESSION	
03-010	5SNSP0011862	BRACKET	
03-012	5SNSP0011864	DUCT SWENSOR	
03-013	5SNSP0011865	SENSOR	
03-016	5SNSP0011868	CLIP CABLE	
03-019	5SNSP0011824	PHOTO-INTERRUPTER	
03-025	5SNSP0011878	CABLE SENSOR	
03-026	5SNSP0011879	CONNECTOR SNAP TIGHT	
03-027	5SNSP0011880	MICROSWITCH	
03-028	5SNSP0011881	MICROSWITCH	
03-032	5SNSP0011887	PLATE GEAR	
03-069	5SNSP0012287	SCREW RS M4*8*	
03-071	5SNSP0011931	CLIP CABLE	
24-001	5SNSADF30E24	UNIT BOTTOM FRAME FRONT	
24-002	5SNSP0011885	CASTER	
24-004	5SNSP0011936	CASTER	
24-005	5SNSP0011937	BOLT	
24-006	5SNSP0012295	SCREW	
24-007	5SNSP0012301	BOTTOM FLAME FRONT	
25-001	5SNSADF30E25	UNIT BOTTOM FRAME REAR	
25-007	5SNSP0012302	BOTTOM FLAME REAR	
26-001	5SNSADF30E26	UNIT BOTTOM FRAME SUB	
26-002	5SNSP0011934	ADJUSTER	
26-003	5SNSP0011935	FLAME SUB	
27-001	5SNSADF30E27	UNIT FRAME	
27-002	5SNSP0012296	FRONT SUPPORT	
27-003	5SNSP0012297	REAR SUPPORT	
27-005	5SNSP0011886	MOUNT RAIL	
27-006	5SNSP0011932	STOPPER F	
27-007	5SNSP0012298	BOTTOM SUPPORT	
27-008	5SNSP0012299	GUIDE REINFORCEMENT	
27-009	5SNSP0011933	STOPPER R	
27-010	5SNSP0011872	HINGE DOOR	



Ref No.	Part Code	Description	Quantity
03-007	5SNSP0011859	SPRING LEAF	
03-011	5SNSP0011863	SCREW	
03-014	5SNSP0011866	MICROSWITCH	
03-015	5SNSP0011867	CABLE SWITCH	
03-016	5SNSP0011868	CLIP CABLE	
03-017	5SNSP0011869	CLIP CABLE	
03-018	5SNSP0011870	CLAMP	
03-019	5SNSP0011824	PHOTO-INTERRUPTER	
03-020	5SNSP0011873	PLATE SHAFT	
03-021	5SNSP0011874	CABLE POWER	
03-022	5SNSP0011875	CABLE SENSOR	
03-023	5SNSP0011876	CONNECTOR 2P	
03-024	5SNSP0011877	CONNECTOR SNAP TIGHT	
03-029	5SNSP0011824	PHOTO-INTERRUPTER	
03-030	5SNSP0011883	CLIP CABLE	
03-031	5SNSP0011884	CLIP CABLE	
03-033	5SNSP0011888	GUIDE CABLE	
03-034	5SNSP0011889	SHAFT ROLLER PAPER FEED	
03-035	5SNSP0011890	SPRING TENSION	
03-036	5SNSP0011891	GEAR 45T/55T	
03-037	5SNSP0011893	SHAFT ROLLER 1	
03-038	5SNSP0011894	SHAFT ROLLER	
03-039	5SNSP0011895	DEFLECTOR	
03-040	5SNSP0011896	ARM DEFLECTOR	
03-041	5SNSP0011897	BELT TIMING	
03-042	5SNSP0011898	HOOK	
03-043	5SNSP0011899	ARM REVERSE	
03-044	5SNSP0011900	PLATE GROUND	
03-045	5SNSP0011901	GUIDE CENTER	
03-046	5SNSP0011902	COVER SWITCH	
03-047	5SNSP0011903	FLAG SENSOR	
03-048	5SNSP0011904	MOUNT SENSOR	
03-049	5SNSP0011907	GEAR 20T/42T	
03-050	5SNSP0011908	GEAR 24T/36T	
03-051	5SNSP0011909	GEAR 17T/27T	
03-052	5SNSP0011910	GEAT 17T/23T	
03-053	5SNSP0011911	GEAR 16T/36T	
03-054	5SNSP0011912	GEAR 18T/24T	
03-055	5SNSP0011913	GEAR 26T	
03-056	5SNSP0011914	GEAR 28T	
03-057	5SNSP0011915	GEAR 23T	
03-058	5SNSP0011916	GEAR 18T	
03-059	5SNSP0011917	GEAR 20T	
03-060	5SNSP0011918	SPRING TENSION	
03-061	5SNSP0011919	SPRING TENSION	

Ref No.	Part Code	Description	Quantity
03-062	5SNSP0011920	SPRING TENSION	
03-063	5SNSP0011921	GEAR 27T/PULLEY 48T	
03-064	5SNSP0011922	GEAR 30T	
03-066	5SNSP0011925	SOLENOID	
03-067	5SNSP0011927	COLLAR SPRING	
03-068	5SNSP0011928	BUSHING	
03-069	5SNSP0012287	SCREW RS M4*8	
03-070	5SNSP0011930	CLIP CABLE	
03-072	5SNSP0011938	CLIP CABLE	
03-073	5SNSP0011940	FRONT SIDE PLATE	
03-074	5SNSP0012300	CENTER REINFORCEMENT	
27-003	5SNSP0011929	COVER SPRING	
28-001	5SNSADF30E28	UNIT GUIDE REVERSE	
28-002	5SNSP0011924	GUIDE REVERSE	
29-001	5SNSADF30E29	UNIT PLATE REAR	
29-002	5SNSP0011939	REAR SIDE PLATE	
29-003	5SNSP0011923	MOTOR STEPPING DC24V	
29-004	5SNSP0011892	SOLENOID	
30-001	5SNSADF30E30	UNIT POWER	
30-002	5SNSP0011853	SWITCHING REGULATOR	
30-003	5SNSP0011926	COVER POWER SUPPLY ASS'Y	
52-001	5SNSADF30E52	GUIDE PAPER FEED	
52-002	5SNSP0011906	SHEET	
52-003	5SNSP0012294	SHEET	
52-004	5SNSP0011905	STAY GUIDE	




Fig.4 - Stapler Tray Main Body #3

Ref No.	Part Code	Description	Quantity
04-001	5SNSADF30E04	STAPLER TRAY MAIN BODY 2	
04-002	5SNSP0011942	BELT	
04-003	5SNSP0011943	GEAR 15T/32T	
04-004	5SNSP0011944	CLIP CABLE	
04-005	5SNSP0011945	COVER CABLE	
04-006	5SNSP0011948	CABLE SENSOR	
04-007	5SNSP0011824	PHOTO-INTERRUPTER	
04-008	5SNSP0011962	CABLE SWING UNIT	
04-009	5SNSP0011963	CONNECTOR 2P	
04-010	5SNSP0011964	CONNECTOR 3P	
04-011	5SNSP0011966	BUSHING	
04-012	5SNSP0011967	CLIP CABLE	
31-001	5SNSADF30E01	GUIDE STAPLE	
31-002	5SNSP0011955	SHEET	
31-003	5SNSP0011954	GUIDE STAPLE	
32-001	5SNSADF30E32	GUIDE BELT	
32-002	5SNSP0011968	PLATE GUIDE	
32-003	5SNSP0012290	HOOK GUIDE	
33-001	5SNSADF30E33	MICROSWITCH UNIT	
33-002	5SNSP0011946	PLATE SWING	
33-003	5SNSP0011947	CABLE SENSOR	
34-001	5SNSADF30E34	UNIT ROLLER	
34-002	5SNSP0011956	ROLLER DELIVERY	
34-003	5SNSP0011957	CAM SHUTTER	
34-004	5SNSP0011958	GEAR 22T	
34-005	5SNSP0011959	GEAR 18T	
34-006	5SNSP0011960	BUSHING	
35-001	5SNSADF30E35	UNIT GUIDE STAPLE	
35-002	5SNSP0011941	ROLLER	
35-003	5SNSP0011951	MOUNT SENSOR	
35-004	5SNSP0011953	SPRING TORSION	
35-005	5SNSP0011950	FLAG SENSOR	
35-006	5SNSP0011965	PHOTO-INTERRUPTER	




Fig.5 - Tray Drive Assembly

Ref No.	Part Code	Description	Quantity
05-001	5SNSADF30E05	TRAY DRIVE ASSY	
05-002	5SNSP0011969	BRACKET DRIVE	
05-003	5SNSP0011970	CAM	
05-004	5SNSP0011971	SHAFT TRAY	
05-005	5SNSP0011972	BUSHING	
05-006	5SNSP0011973	GEAR 48T	
05-007	5SNSP0011974	SPRING COMPRESSION	
05-008	5SNSP0011975	MOTOR DC24V	
05-009	5SNSP0011976	GEAR 22T	
05-010	5SNSP0011977	BUSHING	
05-011	5SNSP0011978	BRACKET DRIVE SMALL	
05-012	5SNSP0011979	WASHER	
05-013	5SNSP0011980	PHOTO-INTERRUPTER	
05-014	5SNSP0012310	CABLE MAIN	
05-015	5SNSP0012311	FERRITE CORE	
05-016	5SNSP0012312	CLAMP CABLE	




Fig.6 - Tray Assembly

Ref No.	Part Code	Description	Quantity
06-001	5SNSADF30E06	TRAY ASS'Y	
06-002	5SNSP0011981	GUIDE SLIDE A	
06-003	5SNSP0011982	GUIDE SLIDE B	
06-004	5SNSP0011983	CROSSMEMBER TRAY	
06-005	5SNSP0011984	FRAME TRAY FRONT	
06-006	5SNSP0011985	FRAME TRAY REAR	
06-007	5SNSP0011986	ROLLER	
06-008	5SNSP0011987	ROLLER	
06-009	5SNSP0011988	PLATE GUIDE	




Fig.7 - Swing Guide Assembly

Ref No.	Part Code	Description	Quantity
07-001	5SNSADF30E07	SWING GUIDE ASS'Y	
07-003	5SNSP0011990	LEVER SWING	
07-004	5SNSP0011991	SPRING RETAINER	
07-005	5SNSP0011992	HOLDER ROLLER	
07-006	5SNSP0011993	SHAFT	
07-007	5SNSP0011994	SHAFT ROLLER	
07-008	5SNSP0012007	GEAR 21T	
07-009	5SNSP0012008	GEAR 21T	
07-010	5SNSP0012009	ROLLER	
07-011	5SNSP0012010	ROLLER	
07-012	5SNSP0012011	SPRING COMPRESSION	
07-013	5SNSP0012012	SPRING TENSION	
07-014	5SNSP0012013	SPRING TENSION	
07-015	5SNSP0012014	BUSHING	
07-016	5SNSP0012015	SOLENOID	
07-017	5SNSP0012016	COLLAR SPRING	
07-018	5SNSP0012319	SPRING COMPRESSION	
36-001	5SNSADF30E36	ARM STOP FRONT T31	
36-002	5SNSP0012313	WEIGHT	
36-003	5SNSP0011989	ARM FRONT	
37-001	5SNSADF30E37	ARM STOP REAR	
37-002	5SNSP0011995	ARM REAR	
38-001	5SNSADF30E38	PLATE DRIVE	
38-002	5SNSP0011996	GEAR PLATE	
38-003	5SNSP0012314	GEAR	
38-004	5SNSP0012315	SHAFT 1	
38-005	5SNSP0012316	SHAFT 2	
38-006	5SNSP0012317	SHAFT 3	
39-001	5SNSADF30E39	GUIDE SWING	
39-002	5SNSP0011998	ELIMINATOR STATIC CHARGE A	
39-003	5SNSP0011999	ELIMINATOR STATIC CHARGE B	
39-004	5SNSP0012000	PLATE GROUNDING	
39-005	5SNSP0012001	PLATE GROUNDING	
39-006	5SNSP0012002	PLATE GROUNDING	
39-007	5SNSP0012003	ELIMINATOR STATIC CHARGE C	
39-008	5SNSP0011997	SWING GUIDE	
40-001	5SNSADF30E40	PLATE	
40-002	5SNSP0012005	DAMPER SHUTTER	
40-003	5SNSP0012004	DAMPER SHUTTER	
41-001	5SNSADF30E41	SHAFT	
41-002	5SNSP0012006	RUBBER	
41-003	5SNSP0012318	STAND	





Fig.8a - Stapler Tray Assembly #1

Ref No.	Part Code	Description	Quantity
08-001	5SNSADF30E08	STAPLER TRAY ASS'Y	
08-002	5SNSP0012017	SHAFT DELIVERY ROLLER	
08-003	5SNSP0012018	LINK SHUTTER A	
08-004	5SNSP0012019	LINK SHUTTER B	
08-008	5SNSP0012023	LEVER SENSOR	
08-009	5SNSP0012024	PLATE GEAR	
08-010	5SNSP0012025	LEVER STOP FRONT	
08-011	5SNSP0012026	LEVER STOP REAR	
08-012	5SNSP0012027	PLATE SUPPORT FRONT	
08-013	5SNSP0012028	PLATE SUPPORT REAR	
08-014	5SNSP0012029	CROSSBAR STOP	
08-015	5SNSP0012030	LINK	
08-017	5SNSP0012035	GEAR 15T/23T	
08-018	5SNSP0012037	GEAR 15T	
08-019	5SNSP0012038	GEAR 50T	
08-022	5SNSP0012041	SPRING TORSION	
08-023	5SNSP0012042	SPRING TORSION	
08-027	5SNSP0012049	STOP FRONT	
08-028	5SNSP0012050	STOP REAR	
08-030	5SNSP0012052	SPRING TENSION	
08-032	5SNSP0012060	BUSHING	
08-033	5SNSP0012061	BUSHING	
08-035	5SNSP0012063	SCREW	
08-036	5SNSP0012064	SPRING	
08-038	5SNSP0012067	CLIP CABLE	
08-039	5SNSP0012287	SCREW RS M4*8	
43-001	5SNSADF30E43	SPRING LEAF	
43-002	5SNSP0012054	RUBBER	
43-003	5SNSP0012053	SPRING LEAF	
44-001	5SNSADF30E44	PLATE	
44-003	5SNSP0012324	PLATE STOPPER	
44-004	5SNSP0012325	GEAR5	
44-005	5SNSP0012326	GEAR7	
44-006	5SNSP0012327	GEAR2	
44-007	5SNSP0012328	SHAFT2	
44-008	5SNSP0012329	SHAFT5	
44-009	5SNSP0012330	SHAFT6	
44-010	5SNSP0012331	SHAFT7	
44-011	5SNSP0012332	SHAFT55	
44-012	5SNSP0012277	SWING SHAFT GS	
44-013	5SNSP0012278	SHAFT3	
45-001	5SNSADF30E45	LEVER SWING	
45-002	5SNSP0012034	LEVER SWING	
45-003	5SNSP0012320	BOSS PLATE SWING	
45-004	5SNSP0012321	SHAFT	

Ref No.	Part Code	Description	Quantity
46-001	5SNSADF30E46	UNIT LEVER SWING	
46-002	5SNSP0012036	GEAR 15T/34T	
46-003	5SNSP0012031	WASHER	
46-004	5SNSP0012033	SPRING LEAF	
46-005	5SNSP0012065	SLIDER	

Ref No.	Part Code	Description	Quantity
08-005	5SNSP0012020	PLATE	
08-006	5SNSP0012021	SHUTTER	
08-007	5SNSP0012022	LEVER SHUTTER	
08-016	5SNSP0012032	MOUNT SENSOR	
08-020	5SNSP0012039	GEAR 12T/36T	
08-021	5SNSP0012040	SPRING TORSION	
08-024	5SNSP0012046	CLIP CABLE	
08-025	5SNSP0012047	SOLENOID	
08-026	5SNSP0012048	MOTOR DC24V	
08-029	5SNSP0012051	PHOTO-INTERRUPTER	
08-031	5SNSP0012059	RING RETAINING	
08-034	5SNSP0012062	WASHER	
08-038	5SNSP0012067	CLIP CABLE	
08-040	5SNSP0012066	PLATE TRAY REAR	
42-001	5SNSADF30E42	TRAY STAPLER	
42-002	5SNSP0012044	SEAL	
42-003	5SNSP0012043	STAPLER TRAY	
42-004	5SNSP0012322	PLATE HOLD	
42-005	5SNSP0012323	RUBBER	
47-001	5SNSADF30E47	UNIT MOUNT MOTOR	
47-002	5SNSP0012055	MOUNT MOTOR	
47-003	5SNSP0012056	CLIP CABLE	
47-004	5SNSP0012057	MOTOR STEPPING	
47-005	5SNSP0011824	PHOTO-INTERRUPTER	

Fig.9 - Upper Feed Assembly



Ref No.	Part Code	Description	Quantity
09-001	5SNSADF30E09	UPPER FEEDER ASS'Y	
09-002	5SNSP0012068	ROLLER A	
09-003	5SNSP0012069	ROLLER B	
09-004	5SNSP0012070	ROLLER C	
09-005	5SNSP0012071	SPRING TORSION	
09-006	5SNSP0012075	SPRING ROLLER HOLDER	
48-001	5SNSADF30E48	GUIDE UPPER	
48-002	5SNSP0012072	GUIDE UPPER	
48-003	5SNSP0012073	LABEL OPEERATION	
48-004	5SNSP0012074	LABEL 1	




Fig.10 - Center Guide Assembly

Ref No.	Part Code	Description	Quantity
10-001	5SNSADF30E10	CENTER GUIDE ASS'Y	
10-002	5SNSP0012068	ROLLER A	
10-003	5SNSP0012071	SPRING TORSION	
10-004	5SNSP0012079	SHAFT STAPLER ROLLER	
10-005	5SNSP0012080	GEAR 20T	
10-006	5SNSP0012081	GEAR 16T	
10-007	5SNSP0012082	BUSHING	
49-001	5SNSADF30E49	GUIDE CENTER	
49-002	5SNSP0012076	GUIDE CENTER	
49-003	5SNSP0012077	LABEL 2	




Fig.11 - Stapler Assembly

Ref No.	Part Code	Description	Quantity
11-001	5SNSADF30E11	STAPLER ASS'Y	
11-002	5SNSP0012083	GUIDE STAPLER	
11-003	5SNSP0012084	PLATE RACK	
11-004	5SNSP0012085	PLATE GUIDE	
11-005	5SNSP0012086	COVER SENSOR	
11-006	5SNSP0012087	BELT TIMING	
11-007	5SNSP0012088	CAM STOP	
11-008	5SNSP0012089	COVER PCB	
11-009	5SNSP0012090	SCREW STEPPED M3	
11-010	5SNSP0012091	GEAR 44T/PULLEY 16T	
11-011	5SNSP0012092	GEAR 16T/PULLEY 40T	
11-012	5SNSP0012093	ROLLER	
11-013	5SNSP0012094	ROLLER	
11-014	5SNSP0012095	FLANGE PULLEY	
11-015	5SNSP0012096	CATCH MAGNET	
11-016	5SNSP0012097	MOTOR STEPPING	
11-017	5SNSP0012098	CABLE STAPLER	
11-018	5SNSP0012099	CABLE STAPLER	
11-019	5SNSP0012100	CONNECTOR 3P	
11-020	5SNSP0011952	SCREW RS M3*6	
11-021	5SNSP0011824	PHOTO-INTERRUPTER	
11-022	5SNSP0012102	TWO-STEP SCREW M3	
11-023	5SNSP0012103	MOUNT STAPLER	
11-024	5SNSP0012104	BRACKET STAPLER	
11-025	5SNSP0012105	CLAMP CABLE	
11-026	5SNSP0012106	GROMMET CORD	
11-027	5SNSP0012107	CONNECTOR 9P	
11-028	5SNSP0012109	CONNECTOR PWB ASS'Y	
11-029	5SNSP0012287	SCREW	
11-030	5SNSP0012114	MOUNT	
11-031	5SNSP0012115	ROLLER	
11-032	5SNSP0012116	CLAMP CABLE	
50-001	5SNSADF30E50	UNIT STAPLER	
50-002	5SNSP0012110	COVER STAPLER	
50-003	5SNSP0012111	LEVER LOCK	
50-004	5SNSP0012112	STAPLER	
50-005	5SNSP0012113	PLATE GROUNDING	
50-006	5SNSP0012108	CABLE STAPLER 2	
50-007	5SNSP0012280	CATRIDGE STAPLE	




Fig.12 - PCB Assembly Location

Ref No.	Part Code	Description	Quantity
12-001	5SNSADF30E12	PCB ASSEMBLY LOCATION DIAGRAM	
12-002	5SNSP0012117	FINISHER DRIVER PCB ASS'Y	
12-003	5SNSP0012118	SWITCH PWB ASS'Y	
12-004	5SNSP0012119	CONNECTOR PCB ASS'Y	
12-005	5SNSP0012120	CONNECTOR PCB ASS'Y	
12-006	5SNSP0012078	INTERFACE PCB ASS'Y	