

# MFJ-182

## MFJ Dual Time Watch

### General Information and Operating Instructions

Thank you for purchasing the MFJ-182 Dual Time Watch. The MFJ-182 is a high-tech instrument displaying two time zones simultaneously. The self-governing movements can be independently set according to the users preference.

#### BATTERY INSTALLATION:

- The MFJ-182 already comes with the batteries installed. To begin operation remove the stoppers and press the crown in all the way. The second hand should begin to move.
- If the battery on the MFJ-182 should run down, it is suggested that you take the watch to a jeweler for battery replacement.
- The MFJ-182 uses two SR626SW coin style batteries.

#### SETTING THE MFJ-182 ,

##### Setting the Local Time

- Pull out the crown on the right side of the MFJ-182.
- Turn the crown until the desired minute and hour is reached.
- Push the crown in all the way to resume normal operation. The second hand will begin to tick.

##### Setting the UTC Time

- Pull out the crown to the left side of the MFJ-182.
- Turn the hand until the desired hour is reached (See chart below).
- Press the crown in all the way in to return to normal operation. The left dial is designed to indicate the UTC time in hours only. For minutes and seconds use the right "Local" dial.

##### Chart for setting UTC Time

| Time Zone | Offset for UTC       |               |
|-----------|----------------------|---------------|
|           | Daylight Saving Time | Standard Time |
| Pacific   | +7 hours             | +8 hours      |
| Mountain  | +6 hours             | +7 hours      |
| Central   | +5 hours             | +6 hours      |
| Eastern   | +4 hours             | +5 hours      |

#### SYNCHRONIZING WITH WWV

To synchronize the time with WWV, follow the instructions for "Setting the Local Time". When you pull out the right side crown for setting, be sure the second hand is in the desired position. The second hand will stop when you pull out the crown. Set the time to the desired time. Then press the crown in all the way at the signal. The second hand will begin to tick and your MFJ-182 is now synchronized with WWV.

#### Water Resistant Construction

The MFJ-182 is made of a water resistant construction, but it is strongly recommended that it not be submerged in liquid. The water resistant construction is designed only to withstand splashes of water.

# MFJ-182

## MFJ Dual Time Watch

### General Information and Operating Instructions

Thank you for purchasing the MFJ-182 Dual Time Watch. The MFJ-182 is a high-tech instrument displaying two time zones simultaneously. The self-governing movements can be independently set according to the users preference.

#### BATTERY INSTALLATION:

- The MFJ-182 already comes with the batteries installed. To begin operation remove the stoppers and press the crown in all the way. The second hand should begin to move.
- If the battery on the MFJ- 182 should run down, it is suggested that you take the watch to a jeweler for battery replacement.
- The MFJ-182 uses two SR626SW coin style batteries.

#### SETTING THE MFJ-182

##### Setting the Local Time

- Pull out the crown on the right side of the MFJ-182.
- Turn the crown until the desired minute and hour is reached.
- Push the crown in all the way to resume normal operation. The second hand will begin to tick.

##### Setting the UTC Time

- Pull out the crown to the left side of the MFJ-182.
- Turn the hand until the desired hour is reached (See chart below).
- Press the crown in all the way in to return to normal operation. The left dial is designed to indicate the UTC time in hours only. For minutes and seconds use the right "Local" dial.

##### Chart for setting UTC Time

| Time Zone | Offset for UTC       |               |
|-----------|----------------------|---------------|
|           | Daylight Saving Time | Standard Time |
| Pacific   | +7 hours             | +8 hours      |
| Mountain  | +6 hours             | +7 hours      |
| Central   | +5 hours             | +6 hours      |
| Eastern   | +4 hours             | +5 hours      |

#### SYNCHRONIZING WITH WWV

To synchronize the time with WWV, follow the instructions for "Setting the Local Time". When you pull out the right side crown for setting, be sure the second hand is in the desired position. The second hand will stop when you pull out the crown. Set the time to the desired time. Then press the crown in all the way at the signal. The second hand will begin to tick and your MFJ-182 is now synchronized with WWV.

#### Water Resistant Construction

The MFJ-182 is made of a water resistant construction, but it is strongly recommended that it not be submerged in liquid. The water resistant construction is designed only to withstand splashes of water.

