



MFJ-79 Remote Controller

For the MFJ-493

The MFJ-79 Remote Controller allows remote menu operation of a MFJ-493 Menu Keyer. The unit has a remote Menu button and the Function buttons F1 through F6. Having the menu buttons close to or on the paddle cuts the amount of movement involved in using the MFJ-493 in contests or other intensive operation. The MFJ-79 is designed to mount to the base of an MFJ or Bencher type iambic paddle but can be mounted to any surface. The supplied cable allows menu operation up to three feet away from the MFJ-493 unit.

To install on a paddle:

Remove the back foot from the MFJ or Bencher type paddle. Replace the screw with one of the supplied screws and mount the remote to the paddle base through the middle hole of the remote. For MFJ paddles use the other two supplied screws to further secure the remote to the paddle base. Plug the IDC plug into the back of the MFJ-493 with the bare wire to the left (exiting the bottom side of the plug). Make sure that the plug mates with all the pins of the jack.

To install on a surface:

Attach the lip of the remote with screws, double sided tape, hook and loop fastener, suction cups or sticky magnets to any surface. The remote is designed to be flush mounted to any table edge, shelf, mic stand, arm of a chair etc.. This remote can also be mounted flat. Plug the IDC plug into the back of the MFJ-493 with the bare wire to the left (exiting the bottom side of the plug). Make sure that the plug mates with all the pins of the jack.

MFJ ENTERPRISES, INC.
P.O. BOX 494, MISSISSIPPI STATE, MS 39762, USA