




OPERATING INSTRUCTIONS

MODEL : MPH601



WALL OR DESK TELEPHONE

IMPORTANT SAFETY INSTRUCTIONS

When using your telephone equipment, basic safety precautions should always be followed to reduce the risk of fire, electric shock and injury to persons, including the following :

1. Do not use this product near water, for example, near a bath tub, wash bowl, kitchen sink, or laundry tub, in a wet basement or near a swimming pool.

2. Avoid using a telephone (other than a cordless type) during an electrical storm. There may be a remote risk of electric shock from lightning.

3. Do not use the telephone to report a gas leak in vicinity of the leak.

4. Use only the power cord and batteries indicated in this manual. Do not dispose of batteries in a fire. They may explode. Check with local codes for possible special disposal instructions.

SAVE THESE INSTRUCTIONS

Consumer Information:

This equipment complies with Part 68 of the FCC rules and the requirements adopted by the ACTA. On the **bottom** of this equipment is a label that contains, among other information, a product identifier in the format **US:AAAEQ##TXXXX**. If requested, this number must be provided to the telephone company.

An applicable certification jacks Universal Service Order Codes (USOC) for the equipment is provided (i.e., **RJ11C**) in the packaging with each piece of approved terminal equipment.

A plug and jack used to connect this equipment to the premises wiring and telephone network must comply with the applicable FCC Part 68 rules and requirements adopted by the ACTA. A compliant telephone cord and modular plug is provided with this product. It is designed to be connected to a compatible modular jack that is also compliant. See installation instructions for details.

The REN is used to determine the number of devices that may be connected to a telephone line. Excessive RENs on a telephone line may result in the devices not ringing in response to an incoming call. In most but not all areas, the sum of RENs should not exceed five (5.0). To be certain of the number of devices that may be connected to a line, as determined by the total RENs, contact the local telephone company. [For products approved after July 23, 2001, the REN for this product is part of the product identifier that has the format **US:AAAEQ##TXXXX**. The digits represented by ## are the REN without a decimal point (e.g., 03 is a REN of 0.3). For earlier products, the REN is separately shown on the label.]

If this telephone causes harm to the telephone network, the telephone company will notify you in advance that temporary discontinuance of service may be

required. But if advance notice isn't practical, the telephone company will notify the customer as soon as possible. Also, you will be advised of your right to file a complaint with the FCC if you believe it is necessary.

The telephone company may make changes in its facilities, equipment, operations or procedures that could affect the operation of the equipment. If this happens the telephone company will provide advance notice in order for you to make necessary modifications to maintain uninterrupted service.

Please follow instructions for repairing if any (e.g. battery replacement section); otherwise do not alternate or repair any parts of device except specified.

Connection to party line service is subject to state tariffs. Contact the state public utility commission, public service commission or corporation commission for information.

This equipment is hearing aid compatible.

NOTICE: If your home has specially wired alarm equipment connected to the telephone line, ensure the installation of this *telephone* does not disable your alarm equipment. If you have questions about what will disable alarm equipment, consult your telephone company or a qualified installer.

Should you experience trouble with this equipment, please contact **Memorex** for repair or warranty information. If the equipment is causing harm to the telephone network, the telephone company may request that you disconnect the equipment until the problem is resolved.


[NOTICE: According to telephone company reports, AC electrical surges, typically resulting from lightning strikes, are very destructive to telephone equipment connected to AC power sources. To minimize damage from these types of surges, a surge arrester is recommended.]

[To comply with state tariffs, the telephone company must be given notification prior to connection for customer-owned coin or credit card phone. In some states, the state public utility commission, public service commission or corporation commission must give prior approval of connection.]

INSTALLATION


Install handset :

Use the coiled cord to connect the handset to the cradle. Insert either plug into either jack.




For desk top :

- Simply insert either plug into the modular jack in the telephone base.
- Tuck the cord into the prefitted slot on the underside of cradle
- Insert the other end into the wall jack




Reversible hook :

This telephone has a reversible hook to hold the handset in the cradle when the unit is wall mounted. Pull the hook out from the base and rotate it. When the hook is in the upright position it will hold the handset in the cradle.



- Pull up the Handset Hanger, reverse and replace it. This will hold the handset in place during wall use.

Description of Components



For your convenience, an index card is included for you to list your most important telephone numbers

OPERATION

A) Setting the Tone / Pulse switch

Please ask your local telephone company whether your phone service is PULSE (Rotary) dialing or TONE dialing. Set the switch at TONE position for TONE type, or set the switch at PULSE position for PULSE (Rotary) type

B) To Receive a Call

Whenever your phone rings, pick it up and use it as you would with any standard telephone

C) Dialing a Call

Pick up your telephone, and listen for dial tone, then press the keys for the number you want to call.

D) Ringer ON / OFF switch

When you don't want to be disturbed by incoming calls, slide the ringer switch on the base to the "OFF" position; you can still use the phone to make out-going calls, but any in-coming call will not activate the ringer. Remember to return the switch to the "ON" position when you are ready to receive calls.

E) Ending a Call

After you have finished your conversation just hang up the handset. If you want to make another call immediately, press the "FLASH" button once, and the line is ready for another call

F) MUTE Button

Holding down the MUTE button during a telephone call turns off the microphone. You can then talk privately to someone else in the room without the person on the phone hearing you. When you hold down the MUTE button, you can still hear the other person, but anything you say will be not heard. When you release the button, your caller will again be able to hear your voice

G) To Redial the Last number

This telephone always remembers the last number you called
If the line is busy and you wish to try again, first press the 'FLASH' button, then press the 'REDIAL' button, and the last number will be redialed again

For additional set-up or operating assistance, please visit our website at www.memorexelectronics.com or contact customer service at
PHONE:(954) 660-7100

Please keep all packaging material for at least 90 days in case you need to return this product to your place of purchase or MEMOREX.

For parts and accessories, contact FOX INT'L at 1-800-321-6993

Memcorp Inc
Weston, FL