

******* CAL. 0S1A/0S2A/0S2B SERIES MOV'T PARTS LIST *******
HIGH HAND

ORIGINAL PARTS, MADE IN JAPAN

PART NAME	0S1A	0S2A	0S2B
HOUR WHEEL	075-472	075-A38	075-A38
HOUR RECORDING WHEEL	294-805	-	-
CANON PINION WITH DRIVING WHEEL	028-283	028-A11	028-A11
MINUTE RECORDING WHEEL	291-080	291-207	291-090
SECOND CHRONOGRAPH WHEEL	251-311	251-315	251-315
SECOND WHEEL	025-105	025-997	025-114
SUPPORTOR FOR CHRONOGRAPH PLATE	720-855	720-882	720-895
24 HOUR DRIVING WHEEL	-	100-810	100-670

* Other parts are same as 0S10(=0S1A) / 0S20(=0S2A/0S2B).

***** CAL. OS SERIES MOV'T PARTS LIST *****
 ORIGINAL PARTS, MADE IN JAPAN

PART NAME	OS10/OS11	OS20
ALARM MARKING WHEEL	-	-
ALARM MARKING WHEEL GUARD	-	-
BATTERY	280-4405	280-4405
BATTERY CONNECTOR SPRING	231-345	231-345
BUZZER CONTACT SPRING	-	-
BUZZER TERMINAL PLATE	-	-
CALENDAR CORRECTOR LEVER	116-106	116-115
CALENDAR CORRECTOR WHEEL	213-380	213-440
CALENDAR PLATE	-	714-069
CANNON PINION WITH DRIVING WHEEL	028-218	028-295
CENTER WHEEL COCK	711-163	711-163
CHRONOGRAPH COIL UNIT 1	246-148	246-148
CHRONOGRAPH COIL UNIT 2	-	-
CHRONOGRAPH WHEEL	-	-
CIRCUIT INSULATOR	-	-
CLUTCH WHEEL	064-670	064-670
COIL UNIT	246-147	246-147
CONTACT SPRING	-	-
DATE DIAL	108-A0XX	108-A0XX
DATE DIAL DRIVING WHEEL	103-105	103-105
DATE DIAL GUARD (1)	293-990	293-119
DATE JUMPER	109-580	109-580
DIAL GUARD	713-107	713-138
ELECTRIC CIRCUIT UNIT	279-J17	279-J17
ELECTRIC CIRCUIT UNIT	-	-
FIFTH WHEEL AND PINION	084-640	084-640
FLY-BACK CONNECTION LEVER	270-060	270-060
FLY-BACK LEVER	260-116	260-116
FORTH WHEEL AND PINION	023-267	023-267
HOUR RECORDING WHEEL	294-710	-
HOUR WHEEL	075-392	075-523
INTERMEDIATE CHRONOGRAPH WHEEL	-	-
INTERMEDIATE DATE WHEEL 1	-	-
INTERMEDIATE DATE WHEEL 2	-	-
INTERMEDIATE DATE CORRECTING WHEEL	087-620	087-620
INTERMEDIATE DATE CORRECTING WHEEL(1)	-	087-217
INTERMEDIATE DATE CORRECTING WHEEL(2)(3)	-	087-218
INTERMEDIATE DATE CORRECTING WHEEL(4)	-	087-219
INTERMEDIATE FLY-BACK WHEEL	-	087-216
INTERMEDIATE HOUR-RECORDING WHEEL 1	087-135	-
INTERMEDIATE HOUR-RECORDING WHEEL 2	087-136	-
INTERMEDIATE HOUR-RECORDING WHEEL 3	087-137	-
INTERMEDIATE MINUTE WHEEL	087-138	087-138
INTERMEDIATE MINUTE-RECORDING WHEEL	087-134	087-135
INTERMEDIATE MINUTE-RECORDING WHEEL(2)	-	087-214
INTERMEDIATE MINUTE-RECORDING WHEEL(3)	-	087-215
INTERMEDIATE SECOND-RECORDING WHEEL	087-221	087-221
INTERMEDIATE UNLOCKING CORR. WHEEL	-	-
MINUTE RECORDING WHEEL	291-060	291-090
MINUTE WHEEL AND PINION	072-114	072-114
ROCKING BAR	-	-
ROTOR	285-223	285-223
ROTOR FOR CHRONOGRAPH	285-224	285-224
ROTOR FOR SECOND CHRONOGRAPH	-	-
SCREW FOR CENTER WHEEL COCK (X3)	923-980	923-980
SCREW FOR CHRONOGRAPH COIL UNIT 1	923-990	923-990
SCREW FOR CHRONOGRAPH COIL UNIT 2(X2)	-	-
SCREW FOR CHRONOGRAPH GURD(X4)	923-980	923-980
SCREW FOR COIL UNIT	923-990	923-990
SCREW FOR DATE DIAL GUARD (X3)	929-480	929-640
SCREW FOR ELECTRIC CIRCUIT (X2)	923-990	923-990
SCREW FOR TRAIN WHEEL BRIDGE (X3)	923-980	923-980
SECOND CHRONOGRAPH WHEEL	251-080	251-180
SECOND WHEEL	025-950	025-114
SETTING LEVER	067-993	067-993
SETTING STEM	065-453	065-453
SETTING WHEEL	076-680	076-680
SPACER FOR ELECTRIC CIRCUIT 1 (X2)	027-111	027-111
SPACER FOR ELECTRIC CIRCUIT 1 (X3)	-	-
SPACER FOR ELECTRIC CIRCUIT 2	027-112	027-112
SPACER FOR SETTING STEM	212-A54	212-A54
STATOR	190-126	190-126
STATOR FOR CHRONOGRAPH 1	190-128	190-128
STATOR FOR CHRONOGRAPH 2	-	-
STOP LEVER	204-530	204-530
SUPPORTER FOR PLATE COMPLETE	226-497	226-497
SUPPORTOR FOR CHRONOGRAPH PLATE	720-203	720-526
SWITCH LEVER ACTUATING SPRING	-	-
SWITCH SPRING FOR ALARM	-	-
SWITCH STEM FOR ALARM	-	-
24 HOUR DRIVING WHEEL	-	100-670
THIRD WHEEL AND PINION	017-142	017-142
TRAIN WHEEL BRIDGE	701-E92	701-E92
UNLOCKING CORRECTING WHEEL	-	-
UNLOCKING LEAD PLATE	-	-
UNLOCKING WHEEL	-	-
YOKE	071-128	071-128
LONGER SETTING STEM(24.00MM)		
LONG SETTING STEM(24.00MM-the length of the thread 10	065-557	065-557
LONG SETTING STEM(24.00MM the length of the thread 5.3	065-533	065-533