VPort 15-M12 series IP Camera Quick Installation Guide

This quick installation guide provides simple instructions for installing and connecting the VPort 15-M12 series of 1.3 megapixel fixed dome IP cameras. For detailed information, refer to the VPort 15-M12's user's manual.

Ethernet Connection with 802.3 af PoE Power Supply

Refer to the figures below for connecting the VPort's Ethernet cable.





M12 D-Coded Connector

ATTENTION

PoE Waterproof Switch

• M12 D-Coded Connection

Connect the IP Camera's Ethernet cable to an M12 waterproof switch, as shown above.



A PoE waterproof switch/hub must be used.

• M12 D-Coded Connector's Pin Definition




Pin 1: Rx+ Pin 2: Tx+ Pin 3: Rx-Pin 4: Tx-

Before Login

Before logging in to your VPort, make sure that

ActiveX downloading control is allowed by either changing the ActiveX Controls and plug-ins or by setting your Internet security level to "Default Level," as shown below.

Settings for ActiveX Controls and Plug-ins





VPort 15-M12 Login

The VPort 15-M12's default IP address is 192.168.127.100. To access the VPort for the first time, set the PC's IP address to 192.168.127.XXX. For example:

IP Address: 192.168.127.1

Subnet Mask: 255.255.255.0

Use the Utility to Search for the Device

- Run the Moxa Ethernet Switch and Video Server Configurator (edscfgui.exe)
- Select Broadcast Search under the List Server's menu to search for all VPort devices.

NOTE: The Moxa Ethernet Switch and Video Server Configurator (edscfgui.exe) can be downloaded from Moxa's support website or copied from the software CD.

Login

• Double click on the VPort 15-M12 being searched for or type its IP address in the web browser's URL bos and then press **Enter**.

Note: It is strongly recommended that the administrator set up an administrators password under **System Configuration** \rightarrow **System** \rightarrow **Account** after accessing the VPort 15-M12's web-based manager. The default administrator name is **admin** (this cannot be changed), and there is no default password. Once a password is set, authentication will be required for all logins.

Installing ActiveX Controls

- After connecting to the VPort, a request for installing ActiveX Controls will appear just below the URL bar.
- Right-click on the information bar, and then press "Install ActiveX Control..." to permit the installation of ActiveX Controls.
- A security warning message will appear the first time you access the VPort's web-based manager. The message is related to installing the VPort ActiveX Controls component to your PC or notebook. Click on **Install** to install this plug-in, which enables the IE web browser to view video images.



Web-based Manager

The main page of the VPort 15-M12 IP user interface:



System Configuration

Click on **System Configuration** to access the system configuration overview if you need to make changes to the configuration. For detailed information about each configuration, refer to the User's Manual on the software CD.

MOXV,	VPort15 IP Camera		www.moxa.com
Model Hame : VPort 15-N IP Address : 192,148,3,58	Server Name : VPort MAC Address : 98:84:80:64:15:01	15 IP Camera Firmware Version : 1.8 Build : 89996318	
Home ≌ Main Menu 1⊒ OverView 9⊒ System	System Configuration Welcome to the System Configuration pages. A brief description of each configuration group is given below. Click on a plus sign in t on the name of the page you would like to open.		
🖲 🧰 Network	Category	tem	Description and Content
Alam Alam Alam Alam Alam	System	General	Setting Host Name and Date/Time
		Account	Administrator, User and Demo Account Privileges Management
		Diagnosis	Self-diagnostic report with system, communication, power and IO statu
		System Log	System Log and operation information
		System Parameter	System parameters information and Import/Export function
		Firmware Upgrade	Remote Firmware Upgrade
		Factory Default	Reset to Factory Default
		Reboot	Device will reboot for restarting system
	Network	General	The IP network settings of this VPort
		SMTP Server	Set up Primary and Secondary SMTP Server and E-mail accounts
		FTP Server	Set up the Primary and Secondary FTP Server
		DDNS	Configure DONS
		Universal PnP	Enable UPnP function
		Multicast Setting	Set up Multicast (IGMP) Streaming

VPort 15-M12 IP Camera

Quick Installation Guide



First Editon, September 2009



© 2009 Moxa Inc. All rights reserved. Reproduction without permission is prohibited.

P/N: 1802000150010