














Nikon COOLPIX Accessories

The Most Comprehensive Digital Camera System






















			COOLPIX 5700	COOLPIX 5400	COOLPIX 5000	COOLPIX 4500	COOLPIX 4300/885	COOLPIX SQ	COOLPIX 3100/2100	COOLPIX 3500/2500
Converter Lenses	Fisheye Converter FC-E8 (0.21x)		-	-	● w/UR-E6	●	● w/UR-E4	-	-	-
	Fisheye Converter FC-E9 (0.2x)		● w/UR-E12	● w/UR-E10	-	-	-	-	-	-
	Wideangle Converter WC-E63 (0.63x)		-	-	-	●	● w/UR-E4	-	-	-
	Wideangle Converter WC-E68 (0.68x)		-	-	● w/UR-E5	● w/UR-E7	● w/UR-E4&UR-E7	-	-	-
	Wideangle Converter WC-E80 (0.8x)		● w/UR-E8	● w/UR-E9	-	-	-	-	-	-
	Telephoto Converter TC-E15ED (approx. 1.5x)		● w/UR-E8	● w/UR-E9	-	-	-	-	-	-
	Telephoto Converter TC-E2 (approx. 2x)		-	-	● w/UR-E6	●	● w/UR-E4	-	-	-
	Telephoto Converter TC-E3ED (approx. 3x)		-	-	● w/UR-E6	●	● w/UR-E4	-	-	-
Slide Copy Adapter	Slide Copy Adapter ES-E28		-	● w/UR-E11	● w/UR-E6	●	● w/UR-E4	-	-	-
LCD Hoods	LCD Hood HL-E5000		-	-	●	-	-	-	-	-
	LCD Hood HL-CP10		-	-	-	●	-	●	-	-
	LCD Hood HL-E885		-	-	-	-	●	-	-	-
	LCD Hood HL-E2500		-	-	-	-	-	-	-	●

Converter Adapters

											
Step-Down Ring Lens Adapter UR-E4 (for COOLPIX 4300/885)	Step-Down Ring Lens Adapter UR-E5 (for COOLPIX 5000)	Step-Down Ring Lens Adapter UR-E6 (for COOLPIX 5000)	Step-Down Ring Lens Adapter UR-E7 (for COOLPIX 4500/4300/885)	Lens Adapter UR-E8 (for COOLPIX 5700)	Step-Down Ring Lens Adapter UR-E9 (for COOLPIX 5400)	Step-Down Ring Lens Adapter UR-E10 (for COOLPIX 5400)	Step-Down Ring Lens Adapter UR-E11 (for COOLPIX 5400)	Step-Down Ring Lens Adapter UR-E12 (for COOLPIX 5700)	Lens Hood HN-E5000 (for COOLPIX 5000)	Lens Hood HR-E5700 (for COOLPIX 5700)	Lens Hood HN-CP10 (for COOLPIX 5400)

Lens Hood

Nikon COOLPIX Accessories

			COOLPIX 5700	COOLPIX 5400	COOLPIX 5000	COOLPIX 4500	COOLPIX 4300/885	COOLPIX SQ	COOLPIX 3100/2100	COOLPIX 3500/2500
Brackets	Multi-Flash Bracket Unit SK-E900 		–	–	–	●	–	–	–	–
	Bracket Set SK-9 		*2	*2	*2	*1	*2	–	*2	*2
Speed-lights	Nikon Speedlight SB-80DX 		●	●	●	● w/SK-E900	–	–	–	–
	Nikon Speedlight SB-50DX 		●	●	●	–	–	–	–	–
	Nikon Speedlight SB-30 		●	●	●	*3	*3	*3	*3	*3
Macro Light	MACRO COOL-LIGHT SL-1 		–	–	● w/UR-E6	●	● w/UR-E4	–	–	–
Power Sources	AC Adapter/Battery Charger EH-21 		●	●	●	●	●	–	–	–
	AC Adapter EH-53 		●	●	●	●	●	–	–	–
	AC Adapter EH-60 		–	–	–	–	–	–	–	●
	AC Adapter EH-61 		–	–	–	–	–	●	●	–
	Battery Charger MH-52 (for EN-EL1) 		●	●	●	●	●	–	–	–
	Battery Charger MH-53 (for EN-EL1) 		●	●	●	●	●	–	–	–
	Car Battery Charger (12V DC in) MH-53C (for EN-EL1) 		●	●	●	●	●	–	–	–
	Battery Charger MH-60 (for EN-EL2) 		–	–	–	–	–	●	–	●
	Battery Charger MH-70 (for EN-MH1) 		–	–	–	–	–	–	●	–
	Rechargeable Li-ion Battery EN-EL1 		●	●	●	●	●	–	–	–
	Rechargeable Li-ion Battery EN-EL2 		–	–	–	–	–	●	–	●
	Rechargeable Ni-MH Battery EN-MH1 		–	–	–	–	–	–	●	–
	Battery Pack MB-E5000 (six R6 [AA] size Batteries) 		–	–	●	–	–	–	–	–
Battery Pack MB-E5700 (six R6 [AA] size Batteries) 		●	–	–	–	–	–	–	–	
Remote Cord	Remote Cord MC-EU1 (0.8m) 		●	●	●	●	●	–	–	–

*1 Compatible with Nikon Speedlight SB-80DX/50DX/30 only.

*2 Compatible with Nikon Speedlight SB-30 only.

*3 Wireless Slave Flash function is available by built-in flash sensor.



NIKON CORPORATION

FUJI BLDG., 2-3, MARUNOUCHI 3-CHOME, CHIYODA-KU,
TOKYO 100-8331, JAPAN

www.nikon-image.com/eng/

Specifications and equipment are subject to change without any notice or obligation on the part of the manufacturer.

© 2002/3 NIKON CORPORATION

May 2003