

R596




Figure 10 Component Layout Diagram – Bottom




	RFC	
	RXI	
	RXQ	






	_		NHE-8/9
			—DRFC
			— DRFCGN
			— AFC
			SENA1
 		 	VXOEN
		Pa	⊂TXC ge 3A4




issue 2 11/97


Page 3-A5



Page 3-A6








GJ3 Version 09

Page 3-A8











Figure 19 Keyboard /Display interface




ſ	⇒PWRX
	I WNA
	>ROW(5:0)
[⊃COL(3:0)
F	Page3–A11




GJ3 Version 09





NHE-8/9


Page3-A13



RF IDAX
RFIPORT(6:0)
AFC
TXQP
VREF

GJ3 Version 09

Figure 23 System Connector



	TU_0UT
	XMIC_ID
	EXT_RF
	TX
	SGND
	XEAR_MUTE
J1 J1 	BTYPE
70 12J1	VBAT
GND	
	GND
	Page3-A15