

Programmes After Market Services NHM-3 Series Transceivers

Mechanical Assembly




Table of Contents

	Page No
Mechanical Assembly	1
Exploded View of Transceiver NHM-3	3

Exploded View of Transceiver NHM-3




Figure 1: Exploded view of Transceiver NHM-3

Table 1: Mechanical Component List

Item	Qty	Description	NMP Part No.
I001	1	A-cover assembly	9456854
I002	1	Speaker Gasket	9460368
I003	1	Speaker	5140067
I004	1	Speaker adapter	5400157
I005	1	Buzzer	5140195
I006	1	Rubber for buzzer	9480557
I007	1	LCD module	4850151
I008	1	RTC-battery	4700117
I009	1	Microphone boot	9460342
I010	1	Microphone	5140113
M001	1	SM4 Radio Module	0201490
I011	1	System connector	5460037
I012	1	BB-lid assembly	9517084
I013	1	SIM-lock spring	9560102
I014	1	PA shield frame	9510629
I015	1	RF-shield assy	9517051
I016	1	PIFA internal antenna	0660219
I017	1	PT-screw	6290023
I018	1	Battery connector	5400163
I019	1	Vibration motor	6800051
I020	1	B-cover assembly	9456891
I021	2	Machine screw	9480595
I022	4	PT-screw	6290111
I023	1	Type label NHM-3	9370470
I024	1	Battery cover	9456886
I025	1	Dust cap	9451756