


Backing up data



Nokia E90 Communicator

NOKIA
Eseries

Nokia E90 Communicator

Backing up data

Legal Notice

Copyright © 2007 Nokia. All rights reserved.

Nokia, Nokia Connecting People, Eseries and E90 Communicator are trademarks or registered trademarks of Nokia Corporation. Other product and company names mentioned herein may be trademarks or tradenames of their respective owners.

Reproduction, transfer, distribution or storage of part or all of the contents in this document in any form without the prior written permission of Nokia is prohibited.

Nokia operates a policy of ongoing development. Nokia reserves the right to make changes and improvements to any of the products described in this document without prior notice.

To the maximum extent permitted by applicable law, under no circumstances shall Nokia or any of its licensors be responsible for any loss of data or income or any special, incidental, consequential or indirect damages howsoever caused.

The contents of this document are provided "as is". Except as required by applicable law, no warranties of any kind, either express or implied, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose, are made in relation to the accuracy, reliability or contents of this document. Nokia reserves the right to revise this document or withdraw it at any time without prior notice.

The availability of particular products and applications and services for these products may vary by region. Please check with your Nokia dealer for details, and availability of language options.

Copyright to the Windows screenshots belongs to Microsoft.

Contents

Backing up data	4
On memory card	4
On PC	4
Restoring backup data.....	6
From memory card	6
From PC	6

Backing up data


The purpose of this support guide is to help you create backup copies of your device's contents. You can create these copies on your memory card or on a compatible PC that has the Nokia PC Suite application installed.

Before you begin creating backup files, do the following:

- Close all other applications.
- Make sure you have enough battery power.
- Check in www.nokia.com/pcsuite that you have the latest Nokia PC Suite installed.

On memory card


Before starting the backup process, make sure that a compatible (1.8/3.0V) MicroSD card is inserted in your device.

To back up information from device memory to a memory card, select  > *Tools* > *Memory* > *Options* > *Backup phone memory*.

Do not remove a memory card when the card is being accessed. Removing the card in the middle of an operation may damage the memory card as well as the device, and data stored on the card may be corrupted.

On PC

- 1 Connect your Nokia E90 Communicator to a PC that has Nokia PC Suite for the Nokia E90 Communicator installed.
- 2 Open **Nokia PC Suite** for the Nokia E90 Communicator on the PC, and click **Backup**. The **Nokia Content Copier** opens.
- 3 Make sure the application recognises your device. If the device is not correct, make sure it is connected correctly, and click **Select phone** to select the right device.
- 4 Click **Back up** to continue.




- 5 Select the content you want to back up, and click **Next** (the arrow button pointing to the right). You can back up contacts, calendar entries, messages, notes, settings, bookmarks and user files such as images, video clips, music and user documents.
- 6 Specify a folder to store the back up data file in, and click **Next**.




- 7 The backup operation begins. To stop the backup, click **Cancel**.

- 8 After the backup has finished, Nokia Content Copier displays a report message of the operation. Click **Close** to finish and close Nokia Content Copier or **View the report** to view details of the backup.



Restoring backup data

From memory card


To back up information from device memory to a memory card, select  > *Tools* > *Memory* > *Options* > *Restore from card*.

Do not remove a memory card when the card is being accessed. Removing the card in the middle of an operation may damage the memory card as well as the device, and data stored on the card may be corrupted.


From PC

- 1 Connect your Nokia E90 Communicator to a PC that has Nokia PC Suite for the Nokia E90 Communicator installed.
- 2 Open **Nokia PC Suite** for the Nokia E90 Communicator on the PC, and click **Backup**. The **Nokia Content Copier** opens.
- 3 Make sure the application recognises your device. If the device is not correct, make sure it is connected correctly, and click **Select phone** to select the right device.

- 4 Click **Restore** to continue.




- 5 Define the file that contains the backup data. When you are done, click **Next** (the arrow button pointing to the right) to continue.



- 6 Select the data you want to restore, and click **Next**.

- 7 The data is restored to your Nokia E90 Communicator. To stop the data transfer, click **Cancel**.



- 8 After the restore has finished, click **Close** to finish and close Nokia Content Copier or **View the report** to view details of the restore.