

E114_E115_E116_E117_E118_E119_E120_E121_E122_E123_E124_E125_E126_E127_E128_E129_E130_E131_E132_E133_E134_E135_E136_E137_E138_E139_E140_E141_E142_E143_E144_E145

E146_E147_E148_E149_E150_E151_E152_E153_E154_E155_E156_E157_E158_E159_E160_E161_E162_E163_E164_E165_E166_E167_E168_E169_E170_E171_E172_E173_E174_E175_E176_E177

GND

Original, 05/97







Figure 3 PDA Serial Interface – SIRU Edit 24 for layout 13a











Original, 05/97 Page 10–7



Original, 05/97

Figure 8 PDA Component Layout 13a



Original, 05/97