


GRIP STRAP




The Grip Strap ensures stability in hand-held photography with the Power Bounce Grip 2, winder or motor drive.




(To attach to Power Bounce Grip 2)






(To attach to winder (motor drive))


•Remove camera's shoulder strap ring and link the triangle ring.



*Attach winder (motor drive) to camera. Link the connecting ring.



· Attach the belt.



· Attach the belt.

