




For more Hi-Fi manuals and set-up information
please visit www.hifiengine.com

EXPLODED VIEW



REF.NO.	PART NO.	DESCRIPTION	REMARKS
2	24611607	Chassis B	NDM-177
03-1	24611608	Head plate	NDM-178
03-2	24611609	Head plate	NDM-177
4	24601282	Main motor	NDM-178
05-1	24606530	Control pc board	NDM-177
05-2	24606531	Control pc board	NDM-178
6	24611610	Clutch	NDM-177
6	24611611	Clutch	NDM-178
25	24602551	Main belt	
31	24602595	Pinch roller	
32	24602594	Pinch roller	
42	24602596	F/R belt	
07	24602485C	Cam gear	
29	24611611	Fly Wheel	
10	F765-277	Selenoid	

