


Check the parts number which on the label of motor.

Serial No.:


From 9LAGA01001 to 0EBGA11700



MCI-5U3L

Serial No.:

0FCGB11701 and later



EG-520ED3BA